

VOLT PLUS TECH F9

PRO Touch Wireless Earbuds User Manual

Model: F9 | Brand: VOLT PLUS TECH

1. INTRODUCTION

Thank you for purchasing the VOLT PLUS TECH PRO Touch Wireless Earbuds. This manual provides detailed instructions on how to set up, operate, and maintain your new earbuds. Please read this manual carefully before use to ensure optimal performance and longevity of your device.

These earbuds feature Bluetooth 5.3 connectivity, a digital LED display charging case with a 2,000mAh power bank, IPX4 water resistance, 9D noise reduction, and quad microphones for clear calls.

2. PACKAGE CONTENTS

Please check the package for the following items:

- PRO Touch Wireless Earbuds (Left and Right)
- Charging Case with Digital LED Display
- USB-C Charging Cable
- User Manual
- Ear Tips (Small, Medium, Large)

3. PRODUCT OVERVIEW

Familiarize yourself with the components of your PRO Touch Wireless Earbuds.



Figure 3.1: PRO Touch Wireless Earbuds in their charging case, displaying battery levels on the LED screen.

The charging case features a digital LED display that shows the battery percentage of the case and the individual earbuds. The earbuds are designed for a secure and comfortable fit, with touch controls for various functions.



Figure 3.2: Earbuds and case highlighting key features like Bluetooth V5.3, noise reduction, and water resistance.

The earbuds are equipped with Bluetooth 5.3 for stable connectivity, CVC 8.1 intelligent noise reduction, and an IPX4 waterproof nano-coating, making them suitable for various activities.

4. SETUP AND FIRST USE

4.1. Charging the Earbuds and Case

Before first use, fully charge the earbuds and the charging case.

1. Place both earbuds into the charging case. Ensure they are correctly seated; the LED indicators on the earbuds will light up.
2. Connect the USB-C charging cable to the charging port on the case and the other end to a USB power source (e.g., wall adapter, computer USB port).
3. The digital LED display on the case will show the charging status and battery percentage.
4. Once fully charged, the display will indicate 100%. Disconnect the charging cable.




Figure 4.1: The charging case can also function as a power bank to charge your mobile device.

The charging case has a 2,000mAh battery, providing up to 20+ hours of additional charge for the earbuds, extending total play time to 25+ hours. It can also be used to charge other small devices via its USB-C port.

4.2. Pairing with Your Device

The earbuds support automatic pairing for convenience.

1. **Power On:** Remove both earbuds from the charging case. They will automatically power on. A blue indicator light will flash to confirm. If they do not power on automatically, press and hold the touch area on each earbud for 3-5 seconds until the blue indicator light flashes.
2. **Bluetooth Activation:** On your mobile device (e.g., smartphone, tablet), go to the Bluetooth settings and ensure Bluetooth is turned on.
3. **Search and Connect:** Search for available Bluetooth devices. You should find "YD03" in the list. Select "YD03" to pair.
4. **Confirmation:** Once successfully connected, the earbuds will provide a voice prompt stating "Connected".

TAKE OUT AND CONNECT NOT COMPLEX

Say goodbye to complex manual powering on and try new technological experience brought by the new F9



Figure 4.2: Earbuds automatically connect to your device upon removal from the case.

The earbuds feature a complete binaural separation design, allowing for free switching between single or dual earbud operation.

5. OPERATING INSTRUCTIONS

The PRO Touch Wireless Earbuds utilize touch controls for various functions.




Figure 5.1: Touch control functions for music playback, call management, and voice assistant activation.

Earbud Touch Controls

Function	Action
Power On	Remove from charging case (automatic) or press and hold touch area for 3-5 seconds.
Power Off	Place back into charging case (automatic) or press and hold touch area for 5-7 seconds.
Play/Pause Music	Single touch on either earbud.
Next Song	Double touch on the right earbud.
Previous Song	Double touch on the left earbud.
Volume Up	Triple touch on the right earbud.

Function	Action
Volume Down	Triple touch on the left earbud.
Answer/End Call	Single touch on either earbud.
Reject Call	Press and hold touch area for 2 seconds.
Activate Voice Assistant (Siri/Google Assistant)	Press and hold touch area for 1 second.

The earbuds provide clear sound for music at 120Hz and phone calls at 150Hz, enhanced by CVC 8.1 noise reduction technology.

6. MAINTENANCE AND CARE

Proper care will extend the life of your earbuds.

- **Cleaning:** Use a soft, dry, lint-free cloth to clean the earbuds and charging case. Do not use harsh chemicals or abrasive materials.
- **Water Resistance:** The earbuds have an IPX4 waterproof nano-coating, protecting them from splashes and sweat. They are ideal for running, yoga, and gym activities. **Note: The charging case is NOT waterproof.** Avoid exposing the charging case to water or excessive moisture.
- **Storage:** When not in use, store the earbuds in their charging case to protect them and keep them charged. Store in a cool, dry place away from extreme temperatures.
- **Battery Care:** To preserve battery life, avoid fully discharging the earbuds and case frequently. Charge them regularly, even if not used for extended periods.

7. TROUBLESHOOTING

If you encounter issues with your earbuds, refer to the following common solutions:

Common Issues and Solutions

Problem	Possible Cause / Solution
Earbuds not powering on.	<ul style="list-style-type: none">◦ Battery is low. Place earbuds in the charging case and charge them.◦ Ensure earbuds are properly seated in the charging case.◦ Manually power on by pressing and holding the touch area for 3-5 seconds.
Earbuds not pairing with device.	<ul style="list-style-type: none">◦ Ensure Bluetooth is enabled on your device.◦ Make sure earbuds are in pairing mode (blue light flashing).◦ Forget "YD03" from your device's Bluetooth list and try pairing again.◦ Ensure earbuds are within Bluetooth range (typically 10 meters/33 feet).◦ Restart your device and the earbuds.

Problem	Possible Cause / Solution
Only one earbud is working.	<ul style="list-style-type: none">Place both earbuds back into the charging case, close the lid, wait a few seconds, then take them out again. This often re-syncs them.Ensure both earbuds are charged.Perform a factory reset (refer to advanced troubleshooting if available, or contact support).
Low volume or poor sound quality.	<ul style="list-style-type: none">Adjust volume on both your device and the earbuds.Ensure ear tips are the correct size for a good seal in your ear canal.Clean any debris from the earbud mesh.Move closer to your connected device to avoid interference.
Charging case not charging.	<ul style="list-style-type: none">Check the USB-C cable and power adapter. Try a different cable or adapter.Ensure the charging port on the case is clean and free of debris.

8. SPECIFICATIONS

Feature	Detail
Model Name	F9
Brand	VOLT PLUS TECH
Connectivity Technology	Bluetooth Wireless 5.3
Wireless Communication Technology	Bluetooth
Headphones Jack	USB-C
Compatible Devices	Xiaomi Redmi A2 (and other Bluetooth-enabled devices)
Control Type	Media Control, Touch
Noise Control	Active Noise Cancellation (CVC 8.1)
Water Resistance Level	IPX4 Water Resistant (Earbuds only)
Charging Case Battery Capacity	2,000mAh
Total Play Time	Up to 25+ Hours (with charging case)
Earbud Play Time	5+ Hours (single charge)
Frequency Response	48000 KHz
Impedance	25.94 Ohm
Item Weight	4 Ounces
Product Dimensions	1.5 x 1 x 1.5 inches

Feature	Detail
Material	Hi-Impact Plastic, Stainless Steel, Titanium
Color	Black

9. WARRANTY AND SUPPORT






For warranty information and technical support, please refer to the product packaging or contact the manufacturer directly. Keep your purchase receipt as proof of purchase for any warranty claims.

Manufacturer: VOLT PLUS TECH

For further assistance, please visit the official VOLT PLUS TECH website or contact their customer service.

© 2024 VOLT PLUS TECH. All rights reserved.
This manual is subject to change without notice.

Related Documents - F9

	<p>F9 Bluetooth Earbuds V5.2+EDR User Manual</p> <p>User manual for the F9 Bluetooth Earbuds, detailing specifications, pairing, usage, touch controls, charging, troubleshooting, and important safety warnings. Features Bluetooth V5.2+EDR for wireless audio.</p>
	<p>Bluetooth Earbuds F9 User Manual</p> <p>User manual for the F9 Bluetooth Earbuds, covering specifications, operation, pairing, care, safety, warranty, packing details, and troubleshooting.</p>
	<p>Realme Buds Air 5: User Guide, Features, and Specifications</p> <p>Discover the Realme Buds Air 5 wireless earbuds. This comprehensive guide covers setup, Bluetooth pairing, touch controls, noise reduction, charging, specifications, and warranty information for an optimal audio experience.</p>
	<p>UP-TECH FREEVOICE Wireless Lapel Mic UPT-1536: User Manual & Features</p> <p>Comprehensive guide to the UP-TECH FREEVOICE Wireless Lapel Microphone (UPT-1536). Learn about its plug-and-play functionality, AI noise reduction, compatibility, and basic operation for interviews, live streams, and vlogs.</p>
	<p>SoundPEATS TrueAir2 Wireless Earbuds User Manual</p> <p>This document provides instructions and information for the SoundPEATS TrueAir2 wireless earbuds, covering pairing, reset, wearing, button controls, game mode, Q&A, and FCC statements.</p>



[boAt Immortal 111 True Wireless Earbuds User Manual](#)

User manual for the boAt Immortal 111 True Wireless Earbuds, detailing setup, features like ENx™ Tech and BEAST™ Mode, functions, specifications, and important warnings for optimal usage.