

[Manuals.plus](#) /

› [LIGE](#) /

› LIGE BW1845A-CC Smartwatch User Manual - Bluetooth Call, 1.32" Diamond Display, Fitness Tracker

LIGE BW1845A-CC

LIGE BW1845A-CC Smartwatch User Manual

Model: BW1845A-CC

1. INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your LIGE BW1845A-CC Smartwatch. Please read this manual thoroughly before using the device to ensure proper functionality and to maximize your user experience.



Figure 1: LIGE BW1845A-CC Smartwatch with two strap options.

2. SETUP

2.1 Package Contents

Verify that all items are present in the package:

- LIGE BW1845A-CC Smartwatch
- Charging Cable
- User Manual
- Additional Strap (if included in your specific model variant)
- Strap Adjustment Tool (for metal mesh straps)

2.2 Charging the Smartwatch

Before initial use, fully charge the smartwatch. Connect the magnetic charging cable to the charging points on the back of the watch and plug the USB end into a standard USB power adapter (not included).

- Charging time: Approximately 2 hours for a full charge.
- Battery life: 3-5 days of typical use, up to 7-15 days in standby.

2.3 App Installation and Device Pairing

To utilize all features, download and install the companion application, **FitCloudPro**, on your smartphone.

1. Download the App:

Scan the QR code below or search for "FitCloudPro" in your smartphone's app store (Google Play Store for Android, Apple App Store for iOS).



Figure 2: QR code for FitCloudPro app. Alternatively, visit fitcloud.hetangsmart.com/qrcode/_cn/

2. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
3. **Open FitCloudPro:** Launch the FitCloudPro app and grant necessary permissions.
4. **Add Device:** In the app, navigate to the device section and select "Add Device" or "Search for Device". Select "BW1845A-CC" or a similar identifier from the list of available devices.
5. **Confirm Pairing:** Follow the on-screen prompts on both your phone and the smartwatch to confirm the pairing.

2.4 Bluetooth Call Function Setup

To enable Bluetooth calling, a second Bluetooth connection is required:

1. **Enable Watch Audio:** On your smartwatch, swipe down from the main screen to access quick settings and ensure the "Audio" or "Call" function is enabled (usually represented by a phone icon).
2. **Phone Bluetooth Settings:** On your smartphone, go to **Settings > Bluetooth**.
3. **Connect "Watch Call":** In the list of available devices, locate and connect to "Watch Call" or a similar name associated with your smartwatch.
4. Once connected, you can make and receive calls directly from your smartwatch.

Comprehensive Monitoring of Your Health

Continuously monitor your various health conditions to help you better understand your situation.



Figure 3: Step-by-step guide for Bluetooth call connection.

3. OPERATING INSTRUCTIONS

3.1 Basic Navigation

- **Power On/Off:** Press and hold the side button.
- **Wake Screen:** Raise your wrist or press the side button.
- **Main Screen:** Displays time, date, and other customizable information.
- **Swipe Down:** Access quick settings (brightness, DND, battery, Bluetooth call toggle).
- **Swipe Up:** View notifications.
- **Swipe Left/Right:** Access widgets (heart rate, activity data, weather, music control).
- **Press Side Button:** Return to the main screen or open the app menu.

3.2 Customizing Watch Faces

The smartwatch offers over 200 watch faces via the FitCloudPro app. You can also customize a watch face using your own photos.

1. Open the FitCloudPro app on your smartphone.
2. Navigate to the "Dial Market" or "Watch Face" section.
3. Browse and select a watch face, then tap to synchronize it with your smartwatch.
4. For custom watch faces, select the "Custom Dial" option and choose an image from your phone's gallery.

200+ Watch Face for Your Choice



Figure 4: Examples of available watch faces.

3.3 Bluetooth Calling and Notifications

- **Making Calls:** Access the dial pad or contact list on the smartwatch to initiate a call.
- **Receiving Calls:** Answer or reject incoming calls directly from the watch screen.
- **Message Notifications:** Receive alerts for SMS, WhatsApp, Facebook, and other app notifications. Ensure app notifications are enabled in the FitCloudPro app settings.

Bluetooth Make/Answer Phone Call on Your Wrist

Wake up Your Phone's Voice Assistant



Keypad



Contact List



Call Records



Make/Answer Call



Microphone



Built-in Speaker



Figure 5: Bluetooth call and notification features.

3.4 Health Monitoring

The smartwatch monitors various health metrics:

- **Sleep Monitoring:** Tracks sleep stages (awake, light sleep, deep sleep). View detailed sleep data in the FitCloudPro app.
- **Heart Rate Monitoring:** Provides continuous heart rate tracking.
- **Blood Oxygen (SpO2) Monitoring:** Measures blood oxygen levels.
- **Blood Pressure Monitoring:** Provides estimated blood pressure readings.

- **Female Menstrual Cycle Tracking:** Record and predict menstrual cycles within the app.

Note: The health data provided by this device is for reference only and should not be used for medical diagnosis or treatment.




Figure 6: Health monitoring features.

3.5 Sports Modes and Activity Tracking

The smartwatch supports over 20 sports modes and tracks daily activity:

- **Sports Modes:** Walking, Running, Cycling, Rope Skipping, Climbing, Yoga, Sit-ups, etc. Select a mode to track specific workout data.
- **Activity Tracking:** Automatically records steps, distance, and calories burned throughout the day.
- View detailed activity logs and fitness plans in the FitCloudPro app.

Keep Connected



Message Reminder

1.32" HD LCD Touchscreen
(3.5cm in diameter)



Weather Forecast

Daily Reminder



Drink Water



Sedentary



Schedule



Physiological Period



Figure 7: Sports modes and activity tracking.

3.6 Other Functions

- **AI Voice Assistant:** Activate your phone's voice assistant directly from the watch.
- **Weather Forecast:** Displays current weather conditions and forecasts.
- **Music Control:** Control music playback on your smartphone.
- **Remote Camera Control:** Use the watch as a remote shutter for your phone's camera.
- **Stopwatch, Timer, Calculator, Calendar:** Utility tools available on the watch.
- **Find Phone:** Locate your paired smartphone by making it ring.

- **Daily Reminders:** Set reminders for drinking water, sedentary alerts, and custom schedules via the app.

4. MAINTENANCE

4.1 Cleaning

- Wipe the watch screen and body with a soft, damp cloth.
- Clean the charging contacts regularly to ensure efficient charging.
- Avoid using harsh chemicals or abrasive materials.

4.2 Water Resistance (IP67)

The smartwatch is IP67 water-resistant, meaning it can withstand splashes, rain, and brief immersion in shallow water. It is suitable for hand washing, showering, and swimming.

Caution:

- Do not immerse the watch for extended periods.
- Avoid hot water, steam, or saunas, as these can compromise the water seal.
- Do not operate buttons underwater.

4.3 Strap Replacement

The straps can be replaced. Use the provided tool for metal mesh straps to adjust length or remove links if necessary.

5. TROUBLESHOOTING

Problem	Possible Solution
Watch does not turn on.	Ensure the watch is fully charged. Connect to the charger for at least 10 minutes.
Cannot pair with smartphone.	• Ensure Bluetooth is enabled on your phone. • Make sure the watch is within range of your phone. • Restart both the watch and the phone. • Check if the FitCloudPro app has necessary permissions. • Forget the device in your phone's Bluetooth settings and try pairing again.
Bluetooth call function not working.	• Ensure both "BW1845A-CC" and "Watch Call" are connected in your phone's Bluetooth settings. • Verify the "Audio" or "Call" function is enabled in the watch's quick settings. • Check app permissions for phone calls.
Notifications not received.	• Ensure notifications are enabled in the FitCloudPro app for specific applications. • Check phone settings to allow FitCloudPro to send notifications. • Disable "Do Not Disturb" mode on both the watch and phone.

Problem	Possible Solution
Inaccurate health data.	• Ensure the watch is worn snugly on your wrist, not too loose or too tight. • Clean the sensor on the back of the watch. • Avoid excessive movement during measurements.

6. SPECIFICATIONS

Feature	Detail
Model Number	BW1845A-CC
Brand	LIGE
Display Size	1.32 inches
Connectivity	Bluetooth 5.0
Battery Capacity	230 mAh Lithium-polymer
Charging Time	Approx. 2 hours
Battery Life	3-5 days (typical use), 7-15 days (standby)
Water Resistance	IP67
Compatible OS	iOS 8.4+ / Android 4.4+
Special Features	Bluetooth Call, 20+ Sports Modes, Heart Rate, SpO2, Blood Pressure, Sleep Monitor, Menstrual Cycle Tracker, AI Voice Assistant, Notifications, Music Control, Remote Camera, Weather, Stopwatch, Timer, Calculator, Find Phone.
Memory Storage	256 MB
GPS	No GPS

7. WARRANTY INFORMATION

LIGE products typically come with a standard manufacturer's warranty. Please refer to the warranty card included in your product packaging for specific terms and conditions, including warranty duration and coverage details.

This warranty generally covers manufacturing defects but does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

8. CUSTOMER SUPPORT

If you encounter any issues or have questions regarding your LIGE BW1845A-CC Smartwatch, please contact our customer support team.

- **Contact Method:** Refer to the contact information provided on the product packaging or the official LIGE website.
- **Service Hours:** 7*24 hours support is typically available.
- When contacting support, please have your product model number (BW1845A-CC) and purchase details ready.

© 2025 LIGE. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question