



[Manuals.plus](#) /

> [Targa](#) /

> Targa TG-686CPAA 6.8 Inch Single Din MP5 Media Player User Manual

Targa TG-686CPAA

Targa TG-686CPAA 6.8 Inch Single Din MP5 Media Player User Manual

Model: TG-686CPAA

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your Targa TG-686CPAA 6.8 inch Single Din MP5 Media Player. Please read this manual thoroughly before using the product to ensure proper function and to prevent damage. Keep this manual for future reference.

PRODUCT OVERVIEW

The Targa TG-686CPAA is a versatile single DIN media player designed for in-car entertainment and connectivity. It features a 6.8-inch touchscreen display, Bluetooth connectivity, MP5 playback, Apple CarPlay, and Android Auto compatibility.



Figure 1: Front view of the Targa TG-686CPAA Media Player. The unit features a large touchscreen display. On the left side of the display, there are control buttons for power, microphone, and reset, along with USB ports.

Key Features:

- 6.86" Touch Screen Display
- Single Din Form Factor
- Bluetooth Connectivity
- MP5 Media Playback
- Apple CarPlay Support
- Android Auto Support

Included Components:

- 1 x Targa TG-686CPAA Media Player
- 1 x EvoTuning 300W Super Tweeters (Accessory)
- 1 x Gel Key Holder (Accessory)
- Wiring Harness (Not pictured, typically included)
- Mounting Hardware (Not pictured, typically included)

SETUP AND INSTALLATION

Proper installation is crucial for the performance and safety of your media player. It is highly recommended to have this unit installed by a qualified professional car audio technician.

Safety Precautions:

- Disconnect the vehicle's negative battery terminal before starting installation to prevent electrical shorts.
- Ensure all wiring is correctly connected according to the wiring diagram (not provided in this manual, refer to the diagram included with your unit).
- Do not install the unit where it may obstruct the driver's view or interfere with vehicle operation.
- Securely mount the unit to prevent movement during driving.

Wiring Connections:

Connect the provided wiring harness to your vehicle's electrical system. Pay close attention to power, ground, accessory, speaker, and antenna connections. Incorrect wiring can cause damage to the unit or your vehicle's electrical system. Consult the specific wiring diagram supplied with your product for detailed instructions.

Mounting:

Install the single DIN chassis into your vehicle's dashboard opening. Use the provided mounting brackets and screws to secure the unit firmly. Ensure the unit is flush with the dashboard for a clean finish.

OPERATING INSTRUCTIONS

Power On/Off:

- To power on the unit, press the **Power button** (usually marked with a circle and vertical line) located on the left side of the display.
- To power off, press and hold the **Power button** until the unit shuts down.

Touchscreen Operation:

The unit features a responsive touchscreen. Navigate through menus, select options, and control playback by tapping or swiping on the screen. Specific gestures and button layouts will vary by function.

Bluetooth Pairing:

1. Ensure Bluetooth is enabled on your mobile device.
2. On the media player, navigate to the **Bluetooth menu**.
3. Select "**Pair Device**" or "**Search**".
4. On your mobile device, search for available Bluetooth devices and select "**TG-686CPAA**" or a similar name.
5. Confirm the pairing code if prompted.
6. Once paired, you can stream audio and make hands-free calls.

MP5 Media Playback:

Insert a USB drive containing MP5 compatible audio or video files into one of the USB ports on the unit. The player should automatically detect the media and prompt you to select the playback mode. Navigate through your files using the touchscreen.

Apple CarPlay / Android Auto:

Connect your compatible iPhone or Android smartphone to the unit via a USB cable. The unit should automatically detect the connection and launch Apple CarPlay or Android Auto. Follow the on-screen prompts on both your phone and the media

player to complete the setup. This allows access to navigation, music, messages, and other apps directly from the player's display.

MAINTENANCE

Cleaning the Display:

Use a soft, lint-free cloth slightly dampened with water or a screen cleaning solution specifically designed for electronics. Do not use abrasive cleaners, alcohol, or solvents, as these can damage the screen surface.

General Care:

- Avoid exposing the unit to extreme temperatures, direct sunlight for prolonged periods, or excessive moisture.
- Ensure proper ventilation around the unit to prevent overheating.
- Do not attempt to open the unit or perform repairs yourself, as this will void the warranty.

TROUBLESHOOTING

Problem	Possible Cause	Solution
No power	Incorrect wiring, blown fuse, vehicle battery low.	Check power and ground connections. Inspect vehicle fuses. Ensure battery is charged.
No sound	Speaker wires disconnected, volume too low, mute function active.	Check speaker connections. Increase volume. Deactivate mute.
Bluetooth not connecting	Device not in pairing mode, incorrect pairing code, interference.	Ensure both devices are in pairing mode. Re-enter pairing code. Try pairing in a different location.
Touchscreen unresponsive	Software glitch, screen dirty.	Press the RESET button (small pinhole, use a thin object like a paperclip). Clean the screen.
Apple CarPlay/Android Auto not launching	Incorrect USB cable, phone not compatible, software issue.	Use a high-quality, data-enabled USB cable. Ensure your phone's OS is up to date. Restart both phone and media player.

SPECIFICATIONS

- **Model:** TG-686CPAA
- **Display:** 6.86 inch Touch Screen
- **Form Factor:** Single Din
- **Connectivity:** Bluetooth, USB
- **Features:** MP5 Playback, Apple CarPlay, Android Auto
- **UPC:** 745853358716

WARRANTY AND SUPPORT

This Targa TG-686CPAA Media Player comes with a **6-month warranty** from the date of purchase. This warranty covers

manufacturing defects under normal use. It does not cover damage caused by improper installation, misuse, accidents, unauthorized repairs, or normal wear and tear.

For warranty claims or technical support, please contact your retailer or the manufacturer's customer service. Please have your proof of purchase and product model number ready when contacting support.