

[Manuals.plus](#) /

› [Magic Bullet](#) /

› Magic Bullet Combo Blender MBF50200 Instruction Manual

## Magic Bullet MBF50200

# Magic Bullet® Combo Blender MBF50200 Instruction Manual

Model: MBF50200

## INTRODUCTION

The Magic Bullet® Combo Blender is a versatile kitchen appliance designed for blending, puréeing, emulsifying, chopping, and creating various recipes. This manual provides essential information for safe and effective use of your blender, including setup, operation, maintenance, and troubleshooting.



Image: The Magic Bullet Combo Blender in silver and black, featuring both the 48oz pitcher and a 16oz personal cup, ready for blending various ingredients.

## WHAT'S INCLUDED

Your Magic Bullet® Combo Blender package includes the following components:

- **(1) 600W Motor Base:** The main power unit for blending.
- **(1) Stainless Steel Cross Blade:** A sharp blade designed for both the pitcher and personal cup.
- **(1) 48 oz Pitcher:** For larger batches of blends.
- **(1) Pitcher Lid with Removable Cap:** Secures the pitcher and allows for ingredient addition during blending.
- **(1) Tall Cup (16 oz):** For single-serve blending.
- **(1) To-Go Lid:** For the Tall Cup, allowing easy transport of your blended drinks.
- **(1) User Guide:** This instruction manual.

# what's included.



Pitcher Lid with  
Removable  
Cap



Stainless Steel  
Cross Blade




48oz  
Tritan Pitcher



Tall Cup with  
To-Go Lid



600W  
Motor Base



User Guide

Image: A visual representation of all included parts of the Magic Bullet Combo Blender, clearly labeled for identification.

## SETUP

1. **Unpack Components:** Carefully remove all parts from the packaging.
2. **Clean Before First Use:** Wash the pitcher, tall cup, lids, and cross blade with warm, soapy water. Rinse thoroughly and dry. The pitcher, lids, and blade are top-rack dishwasher-safe. The motor base should be wiped clean with a damp cloth.
3. **Place Motor Base:** Position the 600W Motor Base on a clean, dry, and stable surface. Ensure the suction feet on the bottom are securely attached to prevent movement during operation.

Your browser does not support the video tag.

Video: Official Magic Bullet Combo Blender overview, demonstrating the components and basic assembly. This video is provided by Capital Brands Distribution, LLC.

## OPERATING INSTRUCTIONS

## Using the 48 oz Pitcher

1. **Attach Blade:** Securely twist the Stainless Steel Cross Blade onto the bottom of the 48 oz Pitcher.
2. **Add Ingredients:** Place your desired ingredients into the pitcher. Ensure the liquid level does not exceed the "MAX" line.
3. **Secure Lid:** Place the Pitcher Lid with Removable Cap onto the pitcher and ensure it is securely sealed. The removable cap allows for adding ingredients while blending or ventilating hot blends.
4. **Place on Motor Base:** Carefully place the assembled pitcher onto the 600W Motor Base.
5. **Select Speed:** Use the dial control to select your desired blending speed:
  - **LOW:** For softer ingredients or gentle blending.
  - **HIGH:** For tougher ingredients, frozen fruits, or ice.
  - **PULSE:** For short bursts of power to chop or control consistency. Hold the dial at "PULSE" for desired duration.
6. **Blend:** Begin blending. For optimal results with thick mixtures, use the pulse function or add more liquid.
7. **Pour:** Once blending is complete, turn the dial to "OFF", remove the pitcher, and pour your mixture using the integrated spout.



## fully covered.

Keep it all contained with the heavy-duty pitcher Lid. Its detachable cap ventilates hot blends and lets you add ingredients as you go.

Image: The 48oz pitcher in use, showing the removable cap for adding ingredients during operation.

## Using the 16 oz Tall Cup

1. **Add Ingredients:** Fill the 16 oz Tall Cup with your ingredients. Do not exceed the "MAX LIQUID" line.
2. **Attach Blade:** Twist the Stainless Steel Cross Blade onto the open end of the Tall Cup until securely fastened.
3. **Place on Motor Base:** Invert the Tall Cup and place it onto the 600W Motor Base, ensuring it snaps into place.
4. **Blend:** Use the dial control (LOW, HIGH, PULSE) to blend your ingredients to the desired consistency.
5. **Enjoy:** Once blended, turn the dial to "OFF", remove the cup, and replace the blade with the To-Go Lid for convenient transport.



# big pitcher.

The 48oz pitcher attachment handles multiple servings of your favorite blends – from pureed soups to party drinks.

Image: The 16oz Tall Cup being used to prepare a personal smoothie, highlighting its convenience.

## CLEANING AND MAINTENANCE

Proper cleaning ensures the longevity and hygiene of your Magic Bullet® Combo Blender.

- **Unplug Before Cleaning:** Always unplug the motor base from the power outlet before cleaning.

- **Dishwasher Safe Parts:** The 48 oz Pitcher, 16 oz Tall Cup, Pitcher Lid, To-Go Lid, and Stainless Steel Cross Blade are top-rack dishwasher-safe. For best results and to prevent warping, place them on the top rack only.
- **Hand Washing:** For hand washing, use warm, soapy water and a non-abrasive sponge or brush. Rinse thoroughly.
- **Motor Base:** Wipe the 600W Motor Base clean with a damp cloth. **Never immerse the motor base in water or any other liquid.**
- **Storage:** Store the blender and its components in a clean, dry place.



## base power.

A 600-Watt power base makes this our most powerful magic bullet<sup>®</sup> ever, supplying major brawn for all your blends.

Image: The pitcher and blade being placed in the top rack of a dishwasher, demonstrating easy cleaning.

### TROUBLESHOOTING

| Problem                   | Possible Cause                                                   | Solution                                                                                                                                      |
|---------------------------|------------------------------------------------------------------|-----------------------------------------------------------------------------------------------------------------------------------------------|
| Blender does not turn on. | Not plugged in;<br>cup/pitcher not properly assembled or seated. | Ensure the unit is plugged into a working outlet. Make sure the cup or pitcher is twisted securely onto the motor base and locked into place. |

| Problem                                | Possible Cause                                                      | Solution                                                                                                                                                                   |
|----------------------------------------|---------------------------------------------------------------------|----------------------------------------------------------------------------------------------------------------------------------------------------------------------------|
| Ingredients are not blending smoothly. | Too many solid ingredients; insufficient liquid; ingredients stuck. | Reduce the amount of solid ingredients. Add more liquid. Use the PULSE function or remove the cup/pitcher, shake, and re-attach to redistribute ingredients.               |
| Unit leaks during blending.            | Lid not properly sealed; ingredients exceed MAX line.               | Ensure the lid is securely fastened. Do not fill ingredients past the MAX line indicated on the cup or pitcher.                                                            |
| Burning smell from motor.              | Overheating due to prolonged use or heavy load.                     | Unplug the unit immediately. Allow the motor to cool down for at least 15-20 minutes before attempting to use it again. Avoid continuous operation for more than 1 minute. |

## SPECIFICATIONS

- **Brand:** Magic Bullet
- **Model Number:** MBF50200
- **Power:** 600W Motor Base
- **Capacity:** 48 oz Pitcher, 16 oz Tall Cup
- **Control Type:** Dial Control (Low, High, Pulse)
- **Special Feature:** Dishwasher Safe (removable parts)
- **Material:** Stainless Steel (blade), Plastic (containers)
- **Product Dimensions:** 6"D x 6.5"W x 14.12"H
- **Item Weight:** 6.85 pounds
- **Power Source:** Corded Electric
- **Electrical Standards:** North American & Canadian

## WARRANTY AND SUPPORT

The Magic Bullet® Combo Blender MBF50200 comes with a **1-year limited warranty**. For warranty claims, product support, or additional information, please refer to the contact details provided in your original purchase documentation or visit the official Magic Bullet website.

Always refer to the user manual before use for detailed safety instructions and operational guidelines.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question