

Infinix Hot 20 5G X666

User Manual

GENERIC WALLET CASE FOR INFINIX HOT 20 5G X666

Model: Infinix Hot 20 5G X666 Wallet Case | **Brand:** Generic

1. Introduction

Thank you for choosing the Generic Wallet Case for your Infinix Hot 20 5G X666. This case is designed to provide comprehensive protection, convenient card storage, and a versatile kickstand function, enhancing your device's usability and safeguarding it from daily wear and tear. Please read this manual carefully to ensure proper installation and use of your new phone case.

2. Product Features

- **Durable Construction:** Made from high-quality PU Leather and an integrated TPU soft shell for robust protection.
- **Wallet Functionality:** Features built-in card slots and a cash pocket, allowing you to carry essential cards and currency.
- **Magnetic Kickstand:** Easily converts into a stand for hands-free viewing of videos or video calls.
- **Precision Cutouts:** Ensures full access to all ports, buttons, sensors, and the camera without removing the case.
- **Enhanced Protection:** Offers protection against drops, splashes, fingerprints, and scratches.
- **Convenient Answering:** Designed to allow phone calls with the cover closed.

3. Setup: Installing Your Phone Case

Follow these steps to correctly install your Infinix Hot 20 5G X666 into the wallet case:

1. **Verify Compatibility:** Ensure your phone is the Infinix Hot 20 5G X666 model. This case is specifically designed for this device.
2. **Prepare the Case:** Open the wallet case. You will see the flexible TPU soft shell inside.
3. **Insert Phone:** Gently align your Infinix Hot 20 5G X666 with the TPU soft shell. Start by inserting one side of the phone into the shell, then carefully press the other side until the phone is fully seated within the soft shell.
4. **Check Alignment:** Confirm that all ports, buttons, and the camera lens are perfectly aligned with the

case's cutouts. The TPU shell is designed to fit snugly around your device.



Built-in TPU soft case with specialized shells according to model

Image: The flexible TPU soft shell, ready for phone insertion.

4. Operating Instructions

Maximize the utility of your wallet case with these operational guidelines:

4.1. Using the Card Holder and Wallet

The case features multiple slots for cards and a larger pocket for cash. Simply slide your cards into the designated slots and place folded bills into the cash pocket. The magnetic closure will help keep your valuables secure.



Image: Interior view of the wallet case showing card slots and a pocket for cash.

4.2. Utilizing the Kickstand Function

To use the kickstand, simply fold the front cover backward and secure it with the magnetic flap to form a triangular stand. This allows for comfortable horizontal viewing of your screen, ideal for watching videos or making video calls.



Image: The phone case positioned as a kickstand for media viewing.

4.3. Convenient Call Answering

The case is designed with precise cutouts for the earpiece, allowing you to answer calls with the front cover closed. This provides added privacy and protection during phone conversations.



Splash Proof
Material



Fingerprint-Proof



Scratch Proof



Image: Demonstrating the ability to answer calls with the case cover closed.

5. Maintenance and Care

To ensure the longevity and appearance of your wallet case, follow these care instructions:

- **Cleaning:** Wipe the case gently with a soft, slightly damp cloth. Avoid using abrasive cleaners, solvents, or harsh chemicals, as these can damage the PU leather and TPU material.
- **Avoid Extreme Conditions:** Do not expose the case to extreme temperatures, direct sunlight for prolonged periods, or high humidity, which can cause material degradation.
- **Prevent Scratches:** While the case offers scratch protection for your phone, avoid placing the case with sharp objects that could scratch its exterior.



CONENIENT ANSWER

Built-in handset design

Image: Visual representation of the case's splash-proof, fingerprint-proof, and scratch-proof properties.

6. Troubleshooting

If you encounter any issues with your phone case, please refer to the following common solutions:

- **Case Does Not Fit:** Double-check that your phone model is indeed the Infinix Hot 20 5G X666. This case is designed for a precise fit.
- **Buttons or Ports Not Accessible:** Ensure your phone is correctly seated within the TPU soft shell and aligned with all cutouts. Gently adjust the phone's position if necessary.
- **Magnetic Closure Not Holding:** Check if there are too many cards or items in the wallet section, which might prevent the magnetic flap from closing properly. Remove excess items if needed.

7. Specifications

Compatible Phone Model	Infinix Hot 20 5G X666
Material	PU Leather + TPU Soft Shell

Color	Pink
Features	Card Holder, Kickstand, Magnetic Closure, Enhanced Protection, Precision Cutouts, Splash-Proof, Fingerprint-Proof, Scratch-Proof
Water Resistance Level	Not Water Resistant

8. Warranty and Support

For any questions, concerns, or support regarding your Generic Wallet Case, please contact the seller directly through your purchase platform. Please refer to your purchase documentation for specific warranty details, if applicable.
