

Manuals.plus /

› LUDOMIDE /

› LUDOMIDE Ceiling Fan with Lights User Manual

LUDOMIDE 1105-MINI



User Manual for LUDOMIDE Ceiling Fan with Lights

MODEL: 1105-MINI

Introduction

Thank you for choosing the LUDOMIDE Low Profile Ceiling Fan with Lights. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read this manual thoroughly before installation and keep it for future reference.

Safety Information

WARNING: To reduce the risk of fire, electric shock, or personal injury, always follow these basic precautions:

- Ensure the power is turned off at the circuit breaker before installation or maintenance.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code.
- Consult a qualified electrician if you are unsure about wiring or installation.
- Mount the fan only to an outlet box marked "Acceptable for Fan Support of 35 lbs (15.9 kg) or less" and use the mounting screws provided with the outlet box.
- Do not insert objects into the path of the fan blades.
- Do not operate the fan if any part is damaged.

Package Contents

Verify that all components are present before beginning installation:

- Ceiling Fan Unit
- Remote Control

- Light Kit (integrated)
- Mounting Hardware
- User Manual (this document)



Image: The LUDOMIDE ceiling fan unit with its remote control, showcasing its modern design and integrated lighting.

Setup and Installation

The LUDOMIDE ceiling fan is designed for easy installation, with most components pre-assembled. For detailed step-by-step instructions, please refer to the official Installation Manual PDF provided with your product or available for download from the manufacturer's website.

General Installation Steps:

1. **Prepare for Installation:** Turn off power at the main circuit breaker. Ensure the mounting surface is structurally sound.
2. **Mount the Bracket:** Secure the mounting bracket to the ceiling outlet box.
3. **Connect Wiring:** Connect the fan's electrical wires to your household wiring according to the wiring diagram in the

detailed manual.

4. **Attach Fan Unit:** Secure the fan unit to the mounting bracket.
5. **Test Functionality:** Restore power and test the fan and light functions using the remote control.



Image: Diagram showing the dimensions of the ceiling fan (15.7" diameter, 5.5" height) and highlighting features like 2H Timer, Natural Breeze, Night Light, and Smart Fan Light.

This flush mount ceiling fan is especially suitable for rooms with low ceilings, such as bedrooms, living rooms, kitchens, and offices, providing optimal airflow and light coverage for spaces between 100-215 square feet.

SUITABLE SPACE



ROOM SIZE
100-215 sq.ft

Image: A visual representation of the ceiling fan installed in a bedroom, indicating its suitability for rooms sized 100-215 square feet.

Operating Instructions

Remote Control Operation

The included remote control allows full functionality of your LUDOMIDE ceiling fan. Ensure batteries are correctly inserted (not included).

- **Power On/Off:** Press the power button to turn the fan and light on or off.
- **Fan Speed Adjustment:** Cycle through 6 wind speeds to find your preferred airflow.
- **Light Brightness:** Adjust the light brightness from 10% to 100%.
- **Color Temperature:** Change the light color temperature from warm white (3000K) to cool white (6500K).
- **Timer Function:** Set a 2-hour timer for automatic shut-off.
- **Natural Air Mode:** Activates a varying fan speed to simulate a natural breeze.
- **Night Light Mode:** Provides a soft, low-level illumination.

- **Reverse Fan:** Change the direction of fan rotation for summer (downward airflow) or winter (upward airflow) use.



Image: Illustration showing the three control modes: Remote Control, APP Control, and Wall Control (not included).



Image: A family using the remote control to adjust the fan and light settings while watching television.

APP Control Operation

Download the dedicated app to control your ceiling fan from your smartphone. The app offers comprehensive control over all fan and light functions, including a timer function from 1 to 8 hours.

- **Download App:** Scan the QR code in the detailed manual or search for the app name (usually specified in the manual) in your device's app store.
- **Pairing:** Follow the in-app instructions to pair your device with the ceiling fan via Bluetooth.
- **Full Control:** Adjust brightness, color temperature, fan speed, set timers, and activate special modes directly from your phone.




Image: A hand holding a smartphone displaying the fan control app interface, showing various customizable settings.

Stepless Dimming & Color Temperature

The integrated LED light offers stepless dimming and adjustable color temperature, allowing you to customize the ambiance of your room.

- **Brightness:** Adjust from 10% (dimmiest) to 100% (brightest) to suit your lighting needs.
- **Color Temperature:** Transition smoothly between warm light (3000K), neutral light, and white light (6500K).
- **Memory Function:** The fan remembers your last light brightness and color temperature settings when turned off via the remote control.

ADJUSTABLE LED LIGHT



Image: Visual representation of the adjustable LED light, showing brightness from 10% to 100% and three color temperature options: Warm Light, Neutral Light, and White Light.

3-COLOR STEPLESS DIMMING



Image: A graphic illustrating the 3-color stepless dimming feature, showing transitions between Warm Light, Neutral Light, and White Light, with a brightness slider from 10% to 100%.

Reversible Motor & 6 Speeds Wind

The quiet DC motor offers 6 speed settings and a reversible function for year-round comfort.

- **6 Wind Speeds:** Choose from a gentle breeze to a powerful airflow.
- **Summer Mode:** Downward airflow creates a cooling effect.
- **Winter Mode:** Upward airflow circulates warm air, helping to save energy.




Image: An exploded view of the fan motor, illustrating the 6 wind speed settings with corresponding RPM ranges (e.g., 1-2 Speed: 649-802 RPM, 5-6 Speed: 1093-1240 RPM).

CEILING FAN FOR ALL-SEASON COMFORT



Image: A visual demonstrating the all-season comfort feature, showing downward airflow for a cool breeze in summer and upward airflow for enhanced air circulation in winter.

SUPER QUIET DC MOTOR

Enjoy a quiet evening



Image: An illustration highlighting the super quiet DC motor, indicating a noise level of 35dB, suitable for a quiet evening.

Maintenance

Regular maintenance ensures the longevity and optimal performance of your ceiling fan.


- **Cleaning:** Use a soft, damp cloth to clean the fan's exterior. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Blade Cleaning:** The enclosed design protects the blades from dust accumulation, but occasional wiping of the exterior housing is recommended.
- **Check Connections:** Periodically check all connections and mounting screws to ensure they are secure.

SUPERIOR DURABILITY


Modern exterior design and firm structural design



Acrylic Lampshade



ABS Fan Blades



Iron Frame

Image: Close-up views of the fan's components, highlighting the Acrylic Lampshade, ABS Fan Blades, and Iron Frame, indicating superior durability and modern design.

Troubleshooting

If you encounter issues with your LUDOMIDE ceiling fan, refer to the following common problems and solutions:

| Problem | Possible Cause | Solution |
|----------------------------|---|--|
| Fan does not operate | No power to the fan; Remote control battery low/dead; Incorrect wiring. | Check circuit breaker; Replace remote control batteries; Verify wiring connections. |
| Light does not turn on | No power to the light; Light setting too dim; Incorrect wiring. | Check power supply; Increase brightness via remote/app; Verify wiring. |
| Fan makes noise | Loose screws; Mounting bracket not secure. | Tighten all screws; Ensure mounting bracket is firmly attached to the ceiling. |
| Remote control not working | Batteries are dead or inserted incorrectly; Remote not paired. | Replace batteries, ensuring correct polarity; Refer to the detailed manual for pairing instructions. |

If the problem persists after attempting these solutions, please contact customer service for further assistance.

Specifications

| Feature | Detail |
|--------------------|--|
| Brand | LUDOMIDE |
| Model Name | 1105-MINI |
| Color | White01 |
| Material | Iron, Acrylonitrile Butadiene Styrene, Acrylic |
| Style | Modern |
| Light Fixture Form | Ceiling |
| Product Dimensions | 17"L x 17"W x 7"H |
| Power Source | DC |
| Installation Type | Flush Mount |
| Control Method | App, Remote |
| Light Source Type | LED |
| Wattage | 38 watts |
| Brightness | 100 lumen (adjustable) |
| Special Features | Remote Controlled, Adjustable Color Temperature, Dimmable, Timer, Color Changing |
| Item Weight | 3.7 Pounds |

Warranty and Support

LUDOMIDE is committed to providing high-quality products. This product comes with a reliability guarantee. If you have any questions or require assistance during the use of the product, please do not hesitate to contact our customer service team through Amazon. We aim to provide a satisfactory solution within 24 hours.

Optional protection plans are available for purchase to extend coverage beyond the standard warranty. Please refer to

your purchase details for more information on available protection plans.

For additional resources, you may visit the official LUDOMIDE store on Amazon:[LUDOMIDE Store](#)