

[Manuals.plus](#) /

› [LocoLee](#) /

› LocoLee LED Light Kit Instruction Manual for LEGO NASA Artemis Space Launch System 10341 (Standard Version)

LocoLee 10341

LocoLee LED Light Kit Instruction Manual

FOR LEGO NASA ARTEMIS SPACE LAUNCH SYSTEM 10341 (STANDARD VERSION)

Introduction

Thank you for choosing the LocoLee LED Light Kit for your LEGO NASA Artemis Space Launch System 10341. This kit is designed to enhance your model with vibrant lighting, bringing it to life. This manual provides essential information for the setup, operation, maintenance, and troubleshooting of your light kit. Please read these instructions carefully before installation and use.

Note: This product is an LED light kit only. The LEGO NASA Artemis Space Launch System 10341 building model is not included and must be purchased separately or already owned.

Safety Information

- Keep small parts away from children to prevent accidental ingestion.
- The light kit operates on low voltage (less than 5V). Do not connect to higher voltage power sources.
- Handle wires and components gently. Do not pull wires too hard to avoid damage.
- Ensure all connections are secure before powering on the kit.
- Do not modify the components of the light kit. Unauthorized modifications may void the warranty and pose safety risks.

Package Contents

The LocoLee LED Light Kit for LEGO NASA Artemis Space Launch System 10341 (Standard Version) includes the

following components:

- LED Light Kit components (various lights, connecting cables, expansion boards)
- Instruction Manual (online access via QR code/website)
- Power Supply (USB cable, battery box - batteries not included)

LED Light Make Legos Glow **NO LEGOS** What Package Included?

1.LED Light Kit

2.Instruction



💡 Lights




Image: Contents of the LocoLee LED Light Kit package, showing the light kit box, instruction manual, and individual light component bags.

Package List (NO LEGOS)



1 x Light-30CM Cyan



2 x Flash Light-30CM Red



2 x Light Strip-Warm White-28



1 x Light Strip-Blue-Red



1 x Connecting Cable 20CM



2 x Connecting Cable 50CM



1 x 2 Expansion Board



2 x 4 Expansion Board



1 x 6 Expansion Board



1 x Power Supply

Image: A visual breakdown of the specific parts included in the light kit, such as light strips, connecting cables, and power components.

Setup and Installation

The installation process involves integrating the LED components into your LEGO model. Detailed step-by-step instructions are provided online to guide you through the process.

1. **Access Instructions:** Locate the QR code or website address provided in the booklet included with your kit. Scan the QR code or visit the website.
2. **Enter Model Number:** Input the LEGO serial number (10341) or the code found on the packing box to access the specific instructions for your model.
3. **Follow Guide:** Choose between video or PDF installation instructions. Follow the steps carefully. The instructions are designed to show you how to disassemble minimal bricks for light placement.

4. **Test Components:** Before fully assembling, it is recommended to test each light part to ensure it is functioning correctly.
5. **Connect Power:** Once all lights are installed, connect the power supply (USB or battery box). The lights will be brighter when powered by USB.



Image: Visual guide on how to access the online installation instructions using a QR code or website and model number.

Important Installation Tips:

- Parts are small and not fragile, but avoid pulling wires too hard.
- Ensure wires are neatly tucked and hidden to maintain the aesthetic of your model.
- The light kit is designed to be compatible with LEGO blocks, allowing for perfect concealment.

Operating Instructions

Once the LocoLee LED Light Kit is installed and connected to a power source, the lights will illuminate, bringing your LEGO NASA Artemis Space Launch System 10341 to life. This standard version typically operates by simply connecting to power.

Powering the Light Kit:

- **USB Power:** Connect the provided USB cable to a USB power adapter (not included) or a USB port on a computer/power bank. Ensure the voltage is less than 5V. USB power generally provides brighter illumination.
- **Battery Box Power:** Insert the required batteries (not included) into the battery box and connect it to the light kit.




Image: The LEGO NASA Artemis Space Launch System 10341 model with the LocoLee LED Light Kit installed, demonstrating the illuminated details.

Visual Upgrade Details About Lights




Image: Detailed views of the light kit's effects, showing individual LED placements and their illumination on the model.



Image: A collection of different light accessories that make the LEGO blocks glow, emphasizing the variety of lighting options.

Demonstration Videos:

Below are videos demonstrating the light kit's effects and installation process. Please note that some videos may feature the RC (Remote Control) version, which offers additional control features not present in the Standard Version Light Kit.

Your browser does not support the video tag.

Video: Demonstration of the LED Light Kit for LEGO NASA Artemis Space Launch System, showcasing the illuminated model.

Your browser does not support the video tag.

Video: Light My Brick demonstration for the LEGO NASA Artemis Space Launch System 10341.

Your browser does not support the video tag.

Video: BrickBling Lighting demonstration for the RC Version Light Kit for LEGO Artemis Space Launch System. Note: This video features the Remote Control version.

Your browser does not support the video tag.

Video: BRIKSMAX LED Lighting Kit for LEGO 10341 NASA Artemis Space Launch System, showing installation and effects.

Your browser does not support the video tag.

Video: GEAMENT Light Kit for LEGO NASA Artemis Space Launch System 10341 demonstration.

Your browser does not support the video tag.

Video: LIGHTAILING Light for LEGO 10341 NASA Artemis Space Launch System Display Video.

Maintenance

- **Cleaning:** Use a soft, dry cloth to gently wipe dust from the LED components and wires. Avoid using liquids or abrasive cleaners.
- **Storage:** If storing the model for an extended period, disconnect the power supply. If using a battery box, remove the batteries to prevent leakage.
- **Handling:** Always handle the illuminated model with care to avoid dislodging or damaging the delicate wiring and LED components.

Troubleshooting

If your LocoLee LED Light Kit is not functioning as expected, please refer to the following common issues and solutions:

- **Lights do not turn on:**
 - Check the power source: Ensure the USB cable is securely connected to a working USB port or adapter, or that fresh batteries are correctly installed in the battery box.
 - Verify all connections: Make sure all light components are properly plugged into the expansion boards and that the expansion boards are connected to the main power cable.
 - Inspect for damage: Carefully check for any broken wires or damaged LED components. If a single strip or light is not working, it may indicate a faulty component or connection.
- **Lights are dim:**
 - Ensure you are using a stable power source. USB power typically provides brighter illumination than batteries.
 - Check battery levels if using a battery box. Replace with fresh batteries if needed.
- **Flickering lights:**

- Check all connections for looseness. Secure any loose plugs.
- Ensure the power source is stable and providing consistent voltage.

If you continue to experience issues after following these steps, please contact customer support for further assistance.

Specifications

Feature	Detail
Product Dimensions	6.06 x 3.98 x 1.26 inches
Item Weight	4.6 ounces
Item Model Number	10341
Manufacturer Recommended Age	16 years and up
Power Input	USB (Voltage less than 5V) or Battery Box (batteries not included)
Material	High-quality copper lines and ABS plastic

Warranty and Quality Guarantee

LocoLee is committed to providing high-quality products. This LED Light Kit is made of high-quality copper lines and ABS plastic, ensuring durability and perfect compatibility with LEGO blocks. We conduct thorough quality checks to ensure product performance.

If you encounter any issues with your product, please contact our customer support team. We are dedicated to improving our service and providing the best lighting kit experience.

Customer Support

For any questions, concerns, or assistance with your LocoLee LED Light Kit, please do not hesitate to contact us. Our support team is available to help you.

Contact Method: Please send us an email anytime through the platform where you purchased the product.

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question