

SIMPLEWAY TB330FU/TB330XU

SIMPLEWAY Kid Case Instruction Manual

For Lenovo Tab M11 / Tab K11 LTE 2024 Release 11 Inch Model (TB330FU/TB330XU)

Brand: SIMPLEWAY | Model: TB330FU/TB330XU

1. INTRODUCTION

Thank you for choosing the SIMPLEWAY Kid Case for your Lenovo Tab M11 or Tab K11 LTE 2024 tablet. This case is designed to provide robust protection and enhanced usability for children, featuring a lightweight, shockproof EVA material, a multi-angle foldable handle, and precise cutouts for full access to all tablet functions. Please read this manual carefully to ensure proper installation and optimal use of your new tablet case.

2. PRODUCT FEATURES

- **Compatible Models:** Specifically designed for Lenovo Tab M11 2024 (Model TB-330FU/TB330XU) and Lenovo Tab K11 LTE 2024.
- **Premium Material:** Crafted from safe, non-irritating, and environmentally friendly EVA material, ensuring durability and health safety.
- **Shockproof Protection:** Provides effective protection against scratches, dirt, grime, and accidental drops.
- **Precise Cutouts:** Accurately cut openings for easy access to all buttons, speakers, cameras, earphones, and charging ports. Raised bezel edges protect the screen.
- **Rotating Handle/Stand:** Features a versatile handle with an anti-slip textured surface for a firm grip, easy for children to carry. The handle rotates to convert into a multi-angle stand for comfortable typing and hands-free viewing.

3. COMPATIBILITY CHECK

Ensure your tablet model matches the compatible models listed below before installation. This case is designed exclusively for:

- **Lenovo Tab M11 2024** (Model TB-330FU)

- Lenovo Tab K11 LTE 2024 (Model TB-330XU)

This case is not suitable for any other tablet models.

COMPATIBILITY

Only Fit Lenovo Tab M11 11 inch 2024 Model:TB330FU/TB330XU



Image: Visual confirmation of tablet compatibility with model numbers TB330FU/TB330XU.

4. INSTALLATION GUIDE

Follow these steps to correctly install your SIMPLEWAY Kid Case onto your Lenovo Tab M11/K11 LTE tablet:

1. **Remove Inner Frame (if applicable):** Some cases may come with a black support frame inside. Gently remove this frame before inserting your tablet.
2. **Align Tablet:** Carefully align your tablet with the case, ensuring the camera hole and all ports match the case's cutouts.

3. **Insert Tablet:** Start by inserting one corner of the tablet into the case, then gently work your way around, pressing the edges of the tablet into the case until it is fully seated.
4. **Check Fit:** Ensure all edges of the tablet are securely covered by the case and that all buttons and ports are accessible and functional.



Image: Step-by-step visual instructions for inserting the tablet into the protective case.

Video: Installation Method


Video: A demonstration of how to install the EVA shockproof case onto the tablet, showing the process of fitting the device securely.

5. USAGE AND ADJUSTABLE ANGLES

The SIMPLEWAY Kid Case features a versatile handle that doubles as a stand, offering multiple viewing and typing angles for various activities.

- **Carrying Handle:** Use the integrated handle for easy and secure portability, especially for children.
- **Viewing Stand:** Fold the handle outwards to create a stand. Adjust the angle to suit your needs for watching videos, playing games, or video calls.
- **Typing Stand:** Position the tablet at a lower, more ergonomic angle for comfortable typing.

BUILT-IN HANDLE CAN BE FOLDED INTO A STAND



Anti slip handle



Foldable stand

Image: The case features a built-in handle that can be folded to function as a stable stand for the tablet.

MULTIPLE VIEWING ANGLE



WatchingAngle



TypingAngle



Image: The case allows for multiple viewing angles, including a watching angle and a typing angle, by adjusting the integrated stand.

Video: Case Features Overview

Video: An overview of the Kids EVA Shockproof Case, highlighting its design, handle, and stand functionality.

6. PROTECTION FEATURES

The SIMPLEWAY Kid Case is engineered to safeguard your tablet from daily wear and tear, as well as accidental impacts.

- **Shockproof Design:** The thick EVA foam material absorbs shocks and impacts, protecting the tablet from drops and bumps.
- **Raised Bezel Edges:** The edges around the screen are raised to prevent direct contact with surfaces when placed face down, guarding against scratches and shattering.
- **Full Coverage:** The case provides comprehensive coverage for the tablet's body, ensuring all vulnerable areas are

protected.

STRONG SHOCKPROOF & FULL PROTECTION



Image: The case is designed for strong shockproof capabilities and offers full protection for the tablet, as depicted by a tablet in the case falling.

Precise Openings



Image: Close-up views of the precise openings on the case, ensuring full access to the charger port, speakers, cameras, and buttons.

7. CARE & MAINTENANCE

To keep your SIMPLEWAY Kid Case in excellent condition, follow these simple care instructions:

- **Cleaning:** Wipe the case with a damp cloth and mild soap if necessary. Avoid harsh chemicals or abrasive cleaners.
- **Drying:** Allow the case to air dry completely before re-installing the tablet.
- **Storage:** Store the case in a cool, dry place away from direct sunlight when not in use.

8. TROUBLESHOOTING

If you encounter any issues with your SIMPLEWAY Kid Case, please refer to the following common solutions:

- **Case Not Fitting:** Double-check your tablet model number against the compatible models (TB-330FU/TB330XU).

Ensure the tablet is inserted correctly, starting from one corner and gently pressing around the edges.

- **Buttons/Ports Not Accessible:** Verify that the tablet is properly aligned within the case. Remove and re-install the tablet, ensuring all cutouts match perfectly.
- **Stand Instability:** Ensure the foldable handle is fully extended and locked into position when used as a stand.

If problems persist, please contact SIMPLEWAY customer support for further assistance.

9. SPECIFICATIONS

Feature	Detail
Product Dimensions	11.25 x 10.5 x 1.12 inches
Item Weight	0.76 ounces
Material	Ethylene Vinyl Acetate (EVA) Foam
Special Features	Anti-slip Textured Sides, Comfortable Hand Grip, Lightweight, Sturdy, Multi-Kickstand
Form Factor	Case
Color	Blue
Manufacturer	SIMPLEWAY

10. WARRANTY & SUPPORT

SIMPLEWAY stands behind the quality of its products. For any questions regarding your Kid Case, including warranty information or support needs, please contact the manufacturer directly through their official channels or the retailer where the product was purchased.

Please retain your proof of purchase for any warranty claims.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for

conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question