

Aroepurt U683s

Aroepurt Hybrid Case and Tempered Glass Screen Protector for Energizer U683s

User Instruction Manual

INTRODUCTION

This manual provides instructions for the proper installation and use of your Aroepurt Hybrid Case and Tempered Glass Screen Protector for the Energizer U683s smartphone. Please read these instructions carefully to ensure optimal protection and functionality for your device.

SETUP AND INSTALLATION

Package Contents:


- 1 x Aroepurt Hybrid Phone Case
- 1 x Tempered Glass Screen Protector

Installing the Tempered Glass Screen Protector:


1. **Clean the Screen:** Ensure your Energizer U683s screen is completely clean and free of dust, smudges, or fingerprints. Use a microfiber cloth for best results.
2. **Align the Protector:** Carefully align the tempered glass screen protector with your phone's screen, paying attention to cutouts for the camera and sensors.
3. **Apply Gently:** Once aligned, gently lower the protector onto the screen. It will adhere automatically.
4. **Remove Bubbles:** If any bubbles appear, gently push them towards the edges of the screen using a soft cloth or your finger.





9H High Hardness



Shatterproof



99.9% Super Transparency



Perfect Adhesion



Case Friendly



Anti-fingerprint

Image: Features of the Tempered Glass Screen Protector. This image illustrates the key attributes of the screen protector, such as its 9H high hardness, perfect adhesion, shatterproof design, case-friendly compatibility, 99.9% super transparency, and anti-fingerprint coating.



Scratch Proof

Scratch proof screen effectively avoids sharp objects scratching or abrasion



Image: Scratch Proof Screen Protector. This image shows the screen protector's resistance to scratches, with a hammer impact demonstrating its durability against sharp objects and abrasion.

Installing the Hybrid Phone Case:

1. **Insert Phone:** Gently place your Energizer U683s into the soft silicone frame of the case.
2. **Secure Fit:** Ensure all edges of the phone are securely seated within the case, and the cutouts align with ports and buttons.

OPERATING INSTRUCTIONS

Multi-function Stand:

The case features a folding support mechanism that allows for multi-angle viewing. Extend the integrated stand from the back of the case and adjust it to your desired viewing angle for hands-free media consumption or video calls.

Magnetic Support:

The case is designed with magnetic properties, allowing it to securely attach to compatible magnetic car mounts or other magnetic surfaces for convenient use.

Wristband for Secure Holding:

Utilize the integrated wristband for a more secure grip on your device, reducing the risk of accidental drops during one-hand operation.





Image: Multi-function Stand Case. This collage demonstrates the versatility of the case, showing a user holding the phone securely with the wristband, the case functioning as a stand on a desk, and the phone propped up for hands-free viewing.

Wristband

Slip-proof & drop-proof
Stay carefree

One-Hand Operation

Touch more spots on the screen
Effectively prevent accidental drops of cell phones



Magnetic Fit car magnetic mount



Image: Wristband and Magnetic Features. This image highlights the wristband for improved one-hand operation and the strong magnetic capability for use with car mounts, ensuring the phone stays secure.

MAINTENANCE AND CARE

Cleaning the Case:

To clean your Aroepurt Hybrid Case, gently wipe it with a soft, damp cloth. Avoid using harsh chemicals or abrasive materials, as these may damage the case's finish or material. The frosted surface is designed to resist fingerprints, requiring minimal cleaning.

Cleaning the Screen Protector:

For the tempered glass screen protector, use a microfiber cloth to remove smudges and fingerprints. For stubborn marks, a small amount of screen cleaner can be applied to the cloth (not directly to the screen) and then wiped clean.

TROUBLESHOOTING

Screen Protector Bubbles:

If bubbles appear after installation, gently lift the nearest edge of the screen protector and reapply, pushing the bubble out with a soft cloth. Ensure the screen is completely clean before reapplication.

Case Fit Issues:

If the case does not fit correctly, ensure you have the correct model (Energizer U683s). Remove the phone and reinsert it, making sure all corners and edges are properly seated within the case's frame.

Magnetic Mount Instability:

If the case does not securely attach to a magnetic mount, ensure the mount itself is strong enough and properly installed. The case's integrated magnetic feature is designed for standard magnetic mounts.

SPECIFICATIONS

Feature	Description
Compatible Phone Models	Energizer U683s
Material	Polyurethane (PC hard back panel + soft silicone frame)
Color	Black
Special Features	Fingerprint-resistant frosted surface, Folding support, Magnetic fastening, Thickened anti-drop + Card Function (Note: Card function not explicitly detailed in product features, but listed in specs)
Item Weight	2.46 ounces
Product Dimensions	0.39 x 0.39 x 0.39 inches

Drop Protection

Protects your phone when dropping and keeps it secure at all times



Image: Drop Protection Features. This image provides a detailed view of the case's reinforced corners and shock airbags, illustrating its design for enhanced drop protection.

WARRANTY INFORMATION

Specific warranty details for Aroepurt products may vary. Please refer to the product packaging or the retailer's website for the most accurate and up-to-date warranty information regarding your purchase.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Aroepurt Hybrid Case and Tempered Glass Screen Protector, please contact the retailer or the manufacturer directly through their official support channels. Contact information is typically available on the product packaging or their official website.

