



[Manuals.plus](#) /

> [Supersonic](#) /

> Supersonic SAV-101B 2.1 Bluetooth Soundbar and Wired Subwoofer User Manual

Supersonic SAV-101B

Supersonic SAV-101B 2.1 Bluetooth Soundbar and Wired Subwoofer User Manual

Model: SAV-101B | Brand: Supersonic

1. INTRODUCTION

Thank you for purchasing the Supersonic SAV-101B 2.1 Channel Bluetooth Soundbar and Wired Subwoofer. This system is designed to provide an immersive audio experience for your home theater. Please read this manual carefully before operating the device to ensure proper use and to maximize its performance.

2. SAFETY INFORMATION

- Do not expose the unit to rain, moisture, or extreme temperatures.
- Do not open the casing. Refer all servicing to qualified personnel.
- Ensure proper ventilation around the unit.
- Keep away from heat sources and direct sunlight.
- Use only the power cables provided.

3. PACKAGE CONTENTS

Please check that all items listed below are included in your package:

- 1 x Supersonic Bluetooth Soundbar
- 1 x Wired Subwoofer
- 1 x Set of Power Cables
- 1 x Full Remote Control
- 1 x Instruction Manual (this document)

4. PRODUCT OVERVIEW

The Supersonic SAV-101B system includes a soundbar and a wired subwoofer, designed for enhanced audio output. It features multiple connectivity options and sound modes.



Image: The Supersonic SAV-101B soundbar positioned below a television, accompanied by its wired subwoofer.

Key Features:

- 2.1 Channel Audio System
- Bluetooth Functionality for wireless streaming
- Multiple input options: USB, AUX, OPTICAL, COAXIAL
- Touch button controls on the soundbar
- LED display for status indication
- Built-in FM Radio
- Wired subwoofer for rich bass
- Full-function remote control
- 3D Sound Mode and EQ Modes (Music, Movies, Vocals)

Breaking Size Limitations Achieving Sound Revolution



Image: An exploded view illustrating the internal speaker components of the soundbar, highlighting its design for sound optimization.

5. SETUP

5.1 Connecting the Subwoofer

Connect the wired subwoofer to the soundbar using the dedicated subwoofer cable. Ensure the connection is secure.

5.2 Power Connection

Connect the power cables to the soundbar and subwoofer, then plug them into a suitable power outlet.

5.3 Audio Input Connections

The soundbar supports various audio input methods. Choose the one that best suits your device:



Image: Visual representation of the four primary connection methods: Aux, Coaxial, USB, and Bluetooth, for connecting the soundbar to various devices.

- **AUX (Auxiliary) Input:** Connect your device using a 3.5mm audio cable.
- **Coaxial Input:** Connect your device using a coaxial audio cable.
- **Optical Input:** Connect your device using an optical audio cable.
- **USB Input:** Insert a USB drive containing audio files into the USB port.
- **Bluetooth:** Pair your Bluetooth-enabled device wirelessly. (Refer to Operating Instructions for details)

6. OPERATING INSTRUCTIONS

6.1 Power On/Off

Press the Power button on the soundbar or remote control to turn the unit on or off.

6.2 Selecting Input Mode

Press the "Input" or "Source" button on the soundbar or remote control to cycle through available input modes: Bluetooth, AUX, USB, Optical, Coaxial, FM Radio.

6.3 Bluetooth Pairing

1. Select Bluetooth mode on the soundbar. The LED display will indicate "BT" and flash, signifying pairing mode.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "SAV-101B" from the list of devices.
4. Once paired, the LED display will stop flashing and show "BT" steadily.

6.4 USB Playback

Insert a USB flash drive into the USB port. The soundbar will automatically switch to USB mode and begin playing compatible audio files. Use the remote control for playback functions (play, pause, skip tracks).

6.5 FM Radio Operation

1. Select FM Radio mode.
2. Press the "Play/Pause" button on the remote to initiate an automatic station scan. The soundbar will save available stations.
3. Use the "Next/Previous" buttons to navigate through saved stations.

6.6 Sound Modes (EQ and 3D Sound)

Use the remote control to select different sound modes:

- **EQ Mode:** Cycle through preset equalizer settings optimized for Music, Movies, and Vocals.
- **3D Sound Mode:** Activate 3D sound technology for an immersive audio experience.

Sound Optimized for Each Scene



Image: Examples of sound optimization for different content types: Movie, Music, and Game, illustrating the system's versatility.

7. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the soundbar and subwoofer. Do not use liquid cleaners or aerosols.
- **Storage:** If storing the unit for an extended period, disconnect it from power and store it in a cool, dry place.
- **Ventilation:** Ensure that the ventilation openings are not blocked to prevent overheating.

8. TROUBLESHOOTING

No Power:

- Check if the power cables are securely connected to the soundbar, subwoofer, and power outlet.
- Ensure the power outlet is functional.

No Sound:

- Verify that the correct input mode is selected (e.g., Bluetooth, AUX).
- Increase the volume on both the soundbar and the connected device.
- Check all audio cables for secure connections.
- If using Bluetooth, ensure the device is properly paired.

Remote Control Not Working:

- Ensure there are no obstructions between the remote and the soundbar.
- Replace the batteries in the remote control.

9. SPECIFICATIONS

Specifications

- USB /AUX / OPTICAL / COAXIAL
- Bluetooth Function
- Touch Button Control
- LED Display
- FM Radio
- Wired Subwoofer
- Full Remote Control

Carton Dimension: 337x297x195mm

SUPERSONIC
nfinite innovation
DYNAMIC BASS BOOST - VIGOROUS STEADY
LEVEL-RICH BASS

FM Digital

MADE IN CHINA

6 0 0 9 7 8 3 1 8 8 4 0 2 3

Image: A view of the product packaging, displaying key specifications and features such as USB/AUX/OPTICAL/COAXIAL compatibility, Bluetooth, touch controls, LED display, FM Radio, wired subwoofer, and full remote control.

Feature	Description
Model Name	SAV-101B

Brand	Supersonic
Speaker Type	Soundbar with Wired Subwoofer
Connectivity	Bluetooth, USB, AUX, Optical, Coaxial
Additional Features	FM Radio, LED Display, Touch Button Control, Full Remote Control, 3D Sound Technology, EQ Modes
Dimensions (Product)	<i>Refer to product packaging for precise unit dimensions. (Source data indicates 1.92D x 2.97W x 2H metres, likely packaging)</i>
Power Output	1000W (P.M.P.O - Peak Music Power Output)
Number of Items	2 (Soundbar, Subwoofer)
Country of Origin	China

Note: Product dimensions provided in the source data (1.92D x 2.97W x 2H metres) appear to be for packaging or shipping and not the actual unit. Please refer to the product packaging for precise unit dimensions.

10. WARRANTY AND SUPPORT

Warranty Information:

This Supersonic SAV-101B product comes with a **6 Months Warranty** from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects and does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support:

For technical assistance, troubleshooting, or warranty inquiries, please contact Supersonic customer support. Contact details can typically be found on the official Supersonic website or on your product packaging.