

Manuals.plus /

› Skullcandy /

› Skullcandy Dime Evo Wireless Earbuds User Manual

## Skullcandy S2DTW-S740

# Skullcandy Dime Evo Wireless Earbuds User Manual

Model: S2DTW-S740

## INTRODUCTION

---

The Skullcandy Dime Evo Wireless Earbuds are designed for convenience and high-quality audio on the go. Featuring a compact design with a clip-anywhere case, these earbuds offer up to 36 hours of total battery life, noise isolation, and sweat and water resistance. They are compatible with both iPhone and Android devices, providing a seamless listening experience for music, movies, and podcasts.





Image: Skullcandy Dime Evo Wireless Earbuds with their charging case, featuring a clip for easy portability.

## SETUP

---

### What's Included

- Dime® Evo True Wireless Earbuds
- Charging Case
- Ear Gels (S, M, L)
- USB-C Charging Cable
- User Manual

### Charging Your Earbuds

Before first use, fully charge your Skullcandy Dime Evo earbuds and charging case. The earbuds provide up to 8 hours of listening time, with an additional 28 hours available from the charging case, totaling up to 36 hours. A rapid charge feature provides 2 hours of listening from just a 10-minute charge.

1. Place the earbuds into the charging case. Ensure they are properly seated.
2. Connect the USB-C charging cable to the charging port on the case and plug the other end into a compatible USB power source.
3. The indicator lights on the case will show charging status.



Image: Skullcandy Dime Evo earbuds securely placed inside their charging case, ready for charging or storage.

## Pairing Your Earbuds

The Dime Evo earbuds feature Google Fast Pair for quick setup and multipoint pairing for connecting to multiple devices simultaneously.

1. Remove both earbuds from the charging case. They will automatically enter pairing mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for "Dime Evo" in the list of available devices.
3. Select "Dime Evo" to complete the pairing process. A voice prompt will confirm successful connection.
4. For multipoint pairing, ensure the first device is connected, then put the earbuds back into pairing mode to connect to a second device.

## OPERATING YOUR EARBUDS

---

### Basic Controls

The Skullcandy Dime Evo earbuds feature intuitive media controls directly on the earbuds. Refer to the quick start guide for

specific tap and hold functions for play/pause, track skipping, volume adjustment, and call management.

## Skullcandy App Customization

Enhance your listening experience by downloading the Skullcandy App. The app allows you to:

- Customize EQ settings or choose from preset audio profiles.
- Configure button settings to personalize controls.
- Adjust the levels of Stay-Aware Mode.

## Noise Isolation and Stay-Aware Mode

The Dime Evo earbuds provide a noise-isolating fit to block out unwanted ambient noise, allowing for an immersive audio experience. For situations where you need to be aware of your surroundings, activate Stay-Aware Mode. This feature allows you to hear what's happening around you without removing your earbuds, with adjustable levels via the Skullcandy App.




Image: Graphic illustrating key features of the Skullcandy Dime Evo, including 36 hours battery, noise isolating fit, multipoint pairing, sweat and water resistance, Stay-Aware Mode, and Skullcandy App customization.

## MAINTENANCE

---

### Cleaning Your Earbuds

To maintain optimal sound quality and hygiene, regularly clean your earbuds and charging case. Use a soft, dry, lint-free cloth to wipe down the surfaces. For the ear gels, you can gently remove them and clean with a damp cloth, ensuring they are completely dry before reattaching.

### Water Resistance

The Skullcandy Dime Evo earbuds are rated IPX4 for sweat and water resistance. This means they are protected against splashing water from any direction, making them suitable for workouts and light rain. However, they are not designed for submersion in water. Avoid exposing them to excessive moisture or harsh chemicals.

## TROUBLESHOOTING

---

### Common Issues and Solutions

- **Earbuds not pairing:** Ensure both earbuds are out of the case and in pairing mode. Turn off and on your device's Bluetooth. Try forgetting the device in your Bluetooth settings and re-pairing.
- **No sound from one earbud:** Place both earbuds back in the case, close the lid, wait a few seconds, then remove them. This often re-syncs them.
- **Charging issues:** Check the USB-C cable and power source. Ensure the charging contacts on the earbuds and inside the case are clean and free of debris.
- **Poor sound quality:** Ensure the ear gels provide a secure and comfortable fit for optimal noise isolation. Try different sized ear gels if necessary.

For more detailed troubleshooting or persistent issues, please refer to the official Skullcandy support website or contact customer service.

## SPECIFICATIONS

---

Feature	Detail
Model Name	Dime Evo
Model Number	S2DTW-S740
Connectivity Technology	Wireless (Bluetooth 5.0)
Noise Control	Sound Isolation
Battery Life (Earbuds)	Up to 8 Hours
Battery Life (Total with Case)	Up to 36 Hours
Rapid Charge	10 min charge = 2 hours playtime
Water Resistance Level	IPX4 (Sweat and Water Resistant)
Control Type	Media Control, App Control
Compatible Devices	Cellphones, iPhone, Android
Item Weight	0.06 Kilograms (2.11 ounces)
Product Dimensions	5.71 x 3.15 x 1.46 inches

## WARRANTY AND SUPPORT

---

The Skullcandy Dime Evo Wireless Earbuds come with a **1-Year USA Limited Warranty**. This warranty covers manufacturing defects and ensures your product performs as expected under normal use.

For warranty claims, technical support, or additional product information, please visit the official Skullcandy support website or contact their customer service team. Keep your proof of purchase for warranty validation.

**Online Support:** [www.skullcandy.com/support](http://www.skullcandy.com/support)