Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Hendari G3

Hendari Bluetooth Headset V5.3 (Model G3) User Manual

Model: G3

Introduction

Thank you for choosing the Hendari Bluetooth Headset V5.3. This manual provides essential information for the safe and efficient use of your new headset. Please read it thoroughly before use and retain it for future reference.

Package Contents

Ensure all items are present in the package:

- Hendari Bluetooth Headset (Model G3)
- Wireless Charging Case
- USB Type-C Charging Cable
- Earbuds (S/M/L sizes)
- User Manual

Product Overview

The Hendari Bluetooth Headset V5.3 (Model G3) is designed for clear communication and immersive audio, featuring advanced noise cancellation and long-lasting battery life. Its ergonomic design ensures comfort for extended use.




Figure 1: The charging case features an LED display showing the remaining battery percentage for both the case and the headset.



Figure 2: The portable charging case provides up to 100 hours of total playtime, with 20 hours of playtime from a single headset charge and a 1.5-hour charging time via Type-C.



Figure 3: Equipped with ENC Dual-Mic Noise Cancellation and CVC 8.0 Call Noise Cancellation, the headset effectively reduces background noise by 90% and enhances voice clarity by 67% for clear calls.



Figure 4: The headset features a multi-angle adjustable swivel arm for stable wear, liquid silicone earplugs for comfort, and an extended microphone with noise cancellation for clear calls.

Setup

1. Charging the Headset and Case

Before first use, fully charge the headset and its charging case. Connect the provided USB Type-C cable to the charging port on the case and a compatible power source. The LED display on the case will indicate the charging status and battery level. A full charge takes approximately 1.5 hours.

2. Pairing with Your Device

1. Ensure the headset is charged.
2. Open the charging case or remove the headset from the case. The headset will automatically enter pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth.
4. Search for available Bluetooth devices and select "G3" from the list.
5. Once connected, the headset will indicate successful pairing.



Figure 5: The headset offers immediate pairing upon removal from its charging case, connecting quickly and stably to your device.

3. Dual Device Connectivity

The Hendari G3 headset supports simultaneous connection to two Bluetooth devices. After pairing with the first device, disable Bluetooth on that device. Pair the headset with the second device. Then, re-enable Bluetooth on the first device, and the headset should connect to both. This allows seamless switching between devices for calls and media.



Figure 6: Connect your Hendari headset to two Bluetooth devices simultaneously, such as a phone and a tablet, for seamless switching between calls and media.

Operating Instructions

The Hendari G3 headset features intuitive physical buttons for easy control.



Figure 7: Detailed diagram of the headset's physical buttons for power, volume control, call management, music playback, and voice assistant activation.

1. Power On/Off

- **Power On:** Remove the headset from the charging case, or press and hold the Multi-function Button for approximately 4 seconds.
- **Power Off:** Place the headset back into the charging case, or press and hold the Multi-function Button for approximately 4 seconds.

2. Call Management

- **Answer/End Call:** Press the Multi-function Button once.
- **Reject Call:** Press and hold the Multi-function Button for 2 seconds.
- **Adjust Volume:** Use the dedicated Volume Up (+) and Volume Down (-) buttons.

3. Music Playback

- **Play/Pause:** Press the Multi-function Button once.
- **Next Track:** Press and hold the Volume Up (+) button for 2 seconds.
- **Previous Track:** Press and hold the Volume Down (-) button for 2 seconds.
- **Adjust Volume:** Use the dedicated Volume Up (+) and Volume Down (-) buttons.

4. Voice Assistant

- **Activate Voice Assistant (Siri/Google Assistant):** Double-press the Multi-function Button.

Maintenance

Proper maintenance ensures the longevity and optimal performance of your headset.

- **Cleaning:** Use a soft, dry cloth to clean the headset and charging case. Avoid using abrasive cleaners or solvents.
- **Storage:** Store the headset in its charging case when not in use to protect it from dust and damage. Keep it in a cool, dry place away from extreme temperatures.

- **Water Resistance:** The headset has an IPX7 waterproof rating, meaning it is protected against splashes and sweat. However, it is not recommended for swimming or prolonged submersion. Ensure the charging port is dry before charging.



Figure 8: The headset features an IPX7 waterproof rating, providing protection against water splashes and sweat.

Troubleshooting

If you encounter any issues with your Hendari Bluetooth Headset, please refer to the following common problems and solutions:

Problem	Solution
Headset does not power on	Ensure the headset is fully charged. Place it in the charging case for a few minutes, then try again.
Cannot pair with device	Make sure Bluetooth is enabled on your device and the headset is in pairing mode. Forget previous pairings on your device and try pairing again. Ensure the headset is within 10 meters of your device.
No sound or low volume	Check the volume levels on both the headset and your connected device. Ensure the headset is properly seated in your ear. Reconnect the headset to your device.
Charging case not charging	Verify the USB Type-C cable is securely connected to both the case and the power source. Try a different cable or power adapter.
Intermittent connection	Ensure there are no obstructions between the headset and your device. Move closer to your device. Avoid environments with strong Wi-Fi or other wireless interference.

Specifications

Feature	Description

Feature	Description
Brand	Hendari
Model Number	G3
Bluetooth Version	5.3
Wireless Technology	Bluetooth
Connectivity Technology	Wireless
Bluetooth Range	10 Meters
Noise Control	Passive Noise Reduction (CVC 8.0, ENC)
Audio Driver Type	Dynamic
Audio Driver Size	13 Millimeters
Frequency Range	20 Hz - 20,000 Hz
Impedance	32 Ohms
Ear Placement	Over-Ear (Ear Hook)
Form Factor	In-Ear
Control Type	Physical Buttons
Voice Assistant	Siri, Google Assistant compatible
Battery Life (Total with Case)	Up to 100 hours
Charging Time	1.5 hours (Type-C)
Water Resistance Level	IPX7 (Waterproof)
Compatible Devices	Bluetooth-enabled devices
Recommended Uses	Daily use, business calls, office work, driving, outdoor activities

Warranty and Support

Hendari is committed to providing high-quality products and excellent customer service. For any questions, issues, or suggestions regarding your Hendari Bluetooth Headset, please contact our customer service team.

How to Contact Support:

- Go to your Amazon order page.
- Find your product's order number.
- Contact the seller directly through the listing.

We offer a comprehensive product warranty system and a dedicated after-sales team to ensure your satisfaction.

© 2024 Hendari. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D44H33RS

More documents and user manuals: **https://manuals.plus/**