**Saved from manuals.plus.**
**Open the live page for links to other documents and user manuals.**



## Salutrobusto 009-4D

# Salutrobusto Office Chair 009-4D Instruction Manual

Model: 009-4D

### 1. Introduction

The Salutrobusto Office Chair 009-4D is an ergonomic mesh desk chair designed for heavy-duty use, supporting individuals up to 500 pounds. It features a wide, thick seat cushion, 4D adjustable armrests, an adjustable headrest, and lumbar support to provide enhanced comfort and promote proper posture during extended periods of sitting.




*Image 1.1: Salutrobusto Office Chair 009-4D. This image displays the full ergonomic office chair with its mesh back, thick seat, and adjustable components.*

## 2. Safety Information

**WARNING:** This chair requires assembly. Always follow the assembly instructions carefully to ensure stability and safety. Be cautious when adjusting the headrest, lumbar support, and armrests to avoid injury. Keep the chair away from open flames or high heat sources to prevent fire hazards. Always use the chair within its maximum weight capacity of 500 pounds to maintain stability and prevent accidents.

## 3. Package Contents

Before beginning assembly, please verify that all components listed below are present in your package:

- Chair Backrest (Mesh)
- Seat Cushion
- Armrests (4D Adjustable, Left and Right)
- Gas Lift Cylinder
- Chair Base (5-star aluminum alloy)
- Casters (5 pieces)
- Mechanism Plate
- Headrest Assembly
- Lumbar Support Assembly
- Hardware Kit (Screws, Washers, Allen Wrench)
- Instruction Manual

## 4. Setup and Assembly

Assembly of the Salutrobusto Office Chair 009-4D is required. Please refer to the detailed, step-by-step assembly guide included in your package. It is recommended to assemble the chair on a soft, clean surface to prevent damage to components or flooring. Ensure all connections are secure before use.




*Image 4.1: Assembled Salutrobusto Office Chair in a typical office environment.*

## 5. Operating Instructions (Adjustments)

The Salutrobusto Office Chair 009-4D offers multiple adjustment features to customize your seating experience:

### 5.1. Chair Height Adjustment

- To raise the chair: While seated, lift the lever located under the right side of the seat. The chair will rise. Release the lever at the desired height.
- To lower the chair: While seated, lift the lever located under the right side of the seat. The chair will lower. Release the lever at the desired height.

### 5.2. Recline and Rocking Function

- **Recline Angle:** The chair backrest can recline between 90° and 135°. Use the lever on the left side of the seat to unlock and lock the recline angle.
- **Rocking Tension:** Adjust the tension of the rocking mechanism by turning the round knob located under the front of the seat. Turn clockwise to increase tension (firmer rock) and counter-clockwise to decrease tension (looser rock).

### 5.3. 4D Armrest Adjustment

The armrests offer four dimensions of adjustment:

- **Height Adjustment:** Press the button on the side of the armrest and move it up or down. Release the button to lock.
- **Fore and Aft Adjustment:** Slide the armrest pad forward or backward.
- **Rotary Adjustment:** Rotate the armrest pad inward or outward.
- **Side-to-Side Adjustment:** Slide the armrest pad left or right.




*Image 5.3: Illustration of the 4D armrest adjustment capabilities, including up/down, fore/aft, and rotary movements.*

### 5.4. 3D Adjustable Headrest

The headrest can be adjusted in three ways:

- **Height Adjustment:** Grasp the headrest and slide it up or down to your preferred height.
- **Forward & Backward Adjustment:** Push or pull the headrest to adjust its depth relative to your head.
- **Tilt Angle:** Adjust the angle of the headrest by tilting it forward or backward up to 60 degrees.




*Image 5.4: Illustration of the 3D headrest adjustment capabilities, including up/down, forward/backward, and tilt.*

### 5.5. Adjustable Lumbar Support

The lumbar support system helps maintain the natural curve of your spine:

- **Height Adjustment:** Turn the knob on the back of the chair to move the lumbar support up or down.
- **Depth Adjustment:** Push or pull the lumbar support forward or backward to achieve the desired pressure.




*Image 5.5: Illustration of the adjustable lumbar support, showing forward/backward and up/down adjustments.*

## 6. Maintenance

To ensure the longevity and optimal performance of your Salutrobusto Office Chair 009-4D, follow these maintenance guidelines:

- **Cleaning:** Clean the mesh backrest and fabric seat cushion with a dry cloth. For deeper cleaning, dry cleaning is recommended. Avoid using abrasive cleaners or harsh chemicals that may damage the materials.
- **Hardware Check:** Periodically inspect all bolts, screws, and connections to ensure they are tight. Re-tighten if necessary to maintain stability and prevent wobbling.
- **Caster Care:** Regularly check the casters for accumulated hair, dust, or debris that may hinder smooth movement. Clean them as needed.



*Image 6.1: Detail of the smooth-rolling casters, designed for floor protection.*

## 7. Troubleshooting

If you encounter any issues with your chair, refer to the following common troubleshooting steps:

- **Chair Wobbles:** Ensure all assembly screws are fully tightened. Check the stability of the chair base on a flat surface.
- **Gas Lift Not Adjusting:** Verify that the height adjustment lever is fully engaged or disengaged. If the issue persists, the gas lift cylinder may need replacement. Contact customer support.
- **Casters Not Rolling Smoothly:** Inspect casters for debris (hair, lint, etc.) and clean them thoroughly. Ensure the floor surface is clear.
- **Adjustments (Armrest, Headrest, Lumbar) Not Holding:** Check if the locking mechanisms for each adjustment are properly engaged. Ensure no foreign objects are obstructing the movement.

## 8. Specifications

| | |
|---|---|
| **Brand** | Salutrobusto |
| **Model Name** | 009-4D |
| **Color** | Black |
| **Product Dimensions (D x W x H)** | 26"D x 26"W x 42"H |
| **Maximum Weight Recommendation** | 500 Pounds |
| **Seat Height** | 20 Inches |
| **Seat Depth** | 20.5 Inches |
| **Seat Length** | 20.5 Inches |
| **Arm Height** | 20 Inches |
| **Chair Backrest Width** | 19.7 Inches |
| **Item Weight** | 37.4 pounds |
| **Special Features** | Adjustable Headrest, Adjustable Height, Adjustable Lumbar, 4D Arm Rests, Ergonomic, Tilting |
| **Materials** | Mesh back, Foam seat cushion, Aluminum alloy base |




*Image 8.1: Detailed dimensions of the Salutrobusto Office Chair 009-4D.*

## 9. Warranty and Support

The Salutrobusto Office Chair 009-4D comes with a 1-year warranty from the date of purchase. This warranty covers manufacturing defects and material failures under normal use. For warranty claims, technical support, or to inquire about replacement parts, please contact Salutrobusto customer service. Refer to your purchase documentation or the Salutrobusto official website for current contact information.


### Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

**Name**

Anonymous

**Email**

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

**Question**

Example: How do I reset this device or fix this error?

**Details**

Model number, symptoms, what you tried, or the section of the manual you are using.

**Submit question**

---

**Open the live page**

**https://manuals.plus/asin/B0D44RG44K**

More documents and user manuals: **https://manuals.plus/**