

[Manuals.plus](#) /

› [AFEXOA](#) /

› AFEXOA MX 1 Sunrise Simulation Wake-Up Light User Manual

AFEXOA MX 1

AFEXOA MX 1 Sunrise Simulation Wake-Up Light User Manual

Model: MX 1

INTRODUCTION

This manual provides detailed instructions for the setup, operation, maintenance, and troubleshooting of your AFEXOA MX 1 Sunrise Simulation Wake-Up Light. Please read this manual thoroughly before using the product to ensure proper function and longevity.

SETUP

1. Package Contents

Verify that all components are present:

- AFEXOA MX 1 Sunrise Simulation Wake-Up Light (1 unit)
- User Manual (1 unit)
- Power Adapter (1 unit)

2. Power Connection

Connect the provided power adapter to the device and plug it into a standard electrical outlet. The device will power on automatically.

3. Battery Installation (Backup)

The device includes a CR2032 battery for time and setting backup during power outages. Locate the battery compartment, insert the CR2032 battery with the correct polarity, and close the compartment.

4. Initial Time Setting

Upon first power-up or after a prolonged power loss without backup battery, you may need to set the current time. Refer to the "Operating Instructions" section for detailed time setting procedures.



Image: The AFEXOA MX 1 Wake-Up Light displaying different light colors and its control panel.

OPERATING INSTRUCTIONS

1. Setting the Time

Press the **Time Set** button (refer to diagram in manual for exact button location). Use the **+/-** buttons to adjust hours and minutes. Press **Time Set** again to confirm.

2. Sunrise Simulation Alarm

The sunrise simulation feature gradually brightens the light before your set alarm time, mimicking a natural sunrise.

- **Setting Alarm Time:** Press the **Alarm Set** button. Use **+/-** to set the desired wake-up time. Press **Alarm Set** to confirm.
- **Sunrise Duration:** The light will begin to brighten 5 to 90 minutes before the set alarm time. This duration can typically be adjusted in the settings menu. The light transitions from a soft red to a warm white.

- **Alarm Sound:** Choose from 7 pre-set alarm sounds, including gentle music and natural sounds. Volume is adjustable from 1 to 15 levels (up to 110 dB). An "OFF" option allows for light-only wake-up.

SUNRISE SIMULATION WAKE UP LIGHT

Wake gently with a gradual increasing light and soothing sound



- 5-90 Mins Sunrise Duration
- 0-100% Gradient Brightness
- 1-15 Levels Volume Adjustable




Image: A person waking up in a bedroom, illuminated by the gradual brightening of the AFEXOA MX 1 Wake-Up Light, demonstrating the sunrise simulation feature.

3. Snooze Function

When the alarm sounds, press the central button on the top of the device to activate the snooze function. This provides an additional 9 minutes of sleep. The snooze can be activated multiple times.

PRACTICAL ALARM & SNOOZE FUNCTION

Snooze feature allows 9 extra minutes of sleep,
ease into your morning



7 Soothing Alarm Sounds



1-15 Volume Level/OFF



Wake-up Light ON/OFF

Image: A hand reaching to press the top button of the AFEXOA MX 1 Wake-Up Light, illustrating the snooze function.

4. White Noise Machine & Sleep Timer

The device offers a white noise machine with a sleep timer to aid relaxation and sleep.

- **Sound Selection:** Choose from 16 soothing sounds, including various white noises, natural sounds (e.g., insect, water flow, fire, bird, waves, raining, wind), and lullabies.
- **Sleep Timer:** Set a timer for 15, 30, 60, 90, or 120 minutes. The selected sounds and lights will automatically turn off once the timer expires.

16 SOOTHING SOUNDS & SLEEP TIMER

Sleep timer duration: 15/30/60/90/120mins



Image: The AFEXOA MX 1 Wake-Up Light on a nightstand, with graphics illustrating the 16 soothing sounds and sleep timer durations available.

5. Colored Lights (RGB & Night Light)

The device offers various lighting options for ambiance and night light functionality.

- **RGB Dynamic Mode:** Activate this mode for a continuous cycle through various color combinations, offering up to 6 types of ambient light effects.
- **Monochromatic Night Light:** Select from 8 distinct colors to suit your mood or preference.
- **Brightness Adjustment:** Rotate the central knob on the top of the device to adjust the light brightness from 0% to 100%.

RGB COLOR AMBIENT LIGHTS & 16 MILLION COLORS

Adjust the light color according to different scenes and moods



Image: Several AFEXOA MX 1 Wake-Up Lights arranged to show the range of RGB dynamic color ambient lights.

STEPLESS DIMMING & 8 MONOCHROMATIC LIGHTS

Just turn the center knob to adjust the brightness of the light


0%  100%



Image: A hand adjusting the brightness knob on the AFEXOA MX 1 Wake-Up Light, with a visual representation of 8 monochromatic light color options.

6. Bluetooth Speaker Functionality

The device can function as a Bluetooth speaker for audio playback.

- **Pairing Mode:** Press the **Bluetooth** button (indicated by a 'BT' icon) to enter pairing mode. The 'BT' indicator on the display will flash.
- **Connect Device:** On your smartphone or other Bluetooth-enabled device, search for "AFEXOA MX 1" (or similar name) in the Bluetooth settings and select it to pair.
- **Audio Playback:** Once paired, audio from your connected device will play through the wake-up light's speaker.

HIFI STEREO SPEAKER

Super high quality sound without noise,
enjoy your music flawlessly



Image: The AFEXOA MX 1 Wake-Up Light on a desk, wirelessly connected to a smartphone via Bluetooth, demonstrating its speaker functionality.

MAINTENANCE

1. Cleaning

Wipe the device with a soft, dry cloth. Do not use abrasive cleaners, solvents, or immerse the device in water. Ensure the device is unplugged before cleaning.

2. Battery Replacement

If the time and settings are lost frequently during power outages, the CR2032 backup battery may need replacement. Follow the battery installation steps in the "Setup" section.

TROUBLESHOOTING

- **Device does not power on:**
 - Ensure the power adapter is securely connected to both the device and a working electrical outlet.
 - Check if the outlet is functional by plugging in another device.
- **Alarm does not sound or light up:**
 - Verify that the alarm time is correctly set and activated.
 - Check the alarm volume settings; ensure it is not set to "OFF" if you desire sound.
 - Ensure the light intensity is not set to 0%.
- **Bluetooth connection issues:**
 - Ensure the device is in Bluetooth pairing mode (flashing 'BT' icon).
 - Make sure Bluetooth is enabled on your external device and it is within range.
 - Try unpairing and re-pairing the device.
 - Ensure no other devices are currently connected to the wake-up light.
- **Time/settings are lost after power outage:**
 - The CR2032 backup battery may be depleted. Replace it as described in the "Maintenance" section.

SPECIFICATIONS

Brand	AFEXO A
Model Number	MX 1
Dimensions (L x W x H)	10 x 10 x 15 cm
Weight	660 g
Material	Acrylonitrile Butadiene Styrene (ABS), Plastic
Light Source Type	LED
Power Source	Corded Electric
Backup Battery	1 x CR2032 (included)
Special Features	Loud Alarm/Snooze/Sunrise Simulation/Bluetooth Speaker/White Noise Machine/Sleep Timer/Ambient Light/Adjustable Brightness/Adjustable Volume
Energy Efficiency Rating	F
EPREL QR Code	View EPREL Information




Image: The EU Energy Label for the AFEXOA MX1, indicating its energy efficiency rating.

WARRANTY INFORMATION

This product is covered by a manufacturer's warranty. Please refer to the warranty card included in your package or contact AFEXOA customer support for specific details regarding warranty duration and terms.

CUSTOMER SUPPORT

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact AFEXOA customer support. Contact details can typically be found on the product packaging, the official AFEXOA website, or through your retailer.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D452NC4Q>

More documents and user manuals: <https://manuals.plus/>