

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [ckpsms](#) /

> [CKPSMS Brand - Left and Right Side Edge Guide Presser Foot #GCGL269+GCGR269 Compatible with/Replacement for Durkopp Adler Brand 67,167,267,69,269 Sewing Machines \(4MM\)](#)

ckpsms GCGL269+GCGR269 4MM

Instruction Manual

CKPSMS Left and Right Side Edge Guide Presser Foot

Model: GCGL269+GCGR269 (4MM)

1. INTRODUCTION

This manual provides comprehensive instructions for the CKPSMS Left and Right Side Edge Guide Presser Foot set. These presser feet are precision tools designed to assist in achieving consistent and accurate seam allowances on industrial sewing machines. Understanding the proper installation and usage will ensure optimal performance and extend the lifespan of the product.

2. PRODUCT OVERVIEW

The set includes two distinct presser feet: the #GCGL269 Left Edge Guide Presser Foot and the #GCGR269 Right Edge Guide Presser Foot. Both are designed with an integrated edge guide to help maintain a straight and even stitch line relative to the fabric edge. This specific model is sized at 4MM, indicating the distance from the needle to the edge guide.



Figure 2.1: The Left and Right Side Edge Guide Presser Feet, illustrating their design and adjustable components.

3. COMPATIBILITY

This high-quality Left and Right Side Edge Guide Presser Foot replacement set is compatible with a range of industrial sewing machines. Please verify your machine's compatibility before installation.

- Compatible with/Replacement for Durkopp Adler brand models: 67, 167, 267, 69, 269
- Compatible with/Replacement for JUKI brand models: LS-1342, LS-1342-7

Important Notice: Always pay attention to the size of the product (4MM) to ensure it matches your specific sewing requirements and machine setup.

4. SETUP AND INSTALLATION

Installing the edge guide presser foot requires careful attention to ensure proper function and safety. Always refer to your sewing machine's specific manual for detailed instructions on changing presser feet.

1. **Power Off:** Ensure your sewing machine is turned off and unplugged from the power source before attempting any installation or removal of parts.

2. **Remove Existing Foot:** Loosen the screw that holds the current presser foot in place and carefully remove it.
3. **Attach New Foot:** Align the new CKPSMS edge guide presser foot (either left or right, depending on your need) with the presser foot bar. Ensure the pin on the presser foot fits into the clamp.
4. **Secure:** Tighten the screw firmly to secure the presser foot in position. Do not overtighten.
5. **Test:** Manually lower the presser foot and check for any obstructions or misalignment before powering on the machine.



Figure 4.1: A closer view of the presser feet, showing the guide bars that assist in maintaining a consistent seam.

5. OPERATING INSTRUCTIONS

The edge guide presser feet are designed to simplify the process of sewing straight seams with a consistent allowance. The guide bar on the foot runs along the edge of your fabric, ensuring the needle maintains a precise distance from that edge.

- **Select Foot:** Choose the Left Edge Guide Foot for guiding the fabric on the left side of the needle, or the Right Edge Guide Foot for guiding on the right side.
- **Position Fabric:** Place your fabric under the presser foot, aligning the edge of the fabric with the guide bar.
- **Sew:** Begin sewing, keeping the fabric edge gently pressed against the guide bar. The guide will help you maintain a straight line without constant visual measurement.
- **Adjustments:** For different seam allowances, you may need to adjust your needle position if your machine allows, or use a different size of edge guide presser foot.

6. MAINTENANCE

Proper maintenance ensures the longevity and performance of your presser feet.

- **Cleaning:** Regularly wipe the presser feet with a soft, dry cloth to remove lint, dust, and fabric fibers. Avoid using harsh chemicals that could damage the metal finish.
- **Storage:** Store the presser feet in a clean, dry place, preferably in their original packaging or a dedicated storage box, to prevent scratches or damage.
- **Inspection:** Periodically inspect the guide bars and the foot's surface for any signs of wear or damage that could affect stitching quality.



Figure 6.1: The presser feet neatly stored in their protective clear plastic case.

7. TROUBLESHOOTING

If you encounter issues while using the presser feet, consider the following common solutions:

- **Inconsistent Seams:** Ensure the fabric edge is consistently pressed against the guide bar. Check if the presser foot is securely attached and not loose.
- **Foot Not Fitting:** Double-check the compatibility list and the size (4MM) of your presser foot against your sewing machine model. Incorrect size or model will prevent proper installation.
- **Stitching Issues:** If stitching quality degrades, ensure the presser foot is clean and free of lint. Also, verify that your machine's needle and tension settings are appropriate for your fabric and thread.

8. SPECIFICATIONS

Attribute	Detail
-----------	--------

Attribute	Detail
Part Number	GCGL269+GCGR269
Part Name	Left and Right Edge Guide Presser Foot
Size	4MM (Also available in 3MM, 5MM, 6MM)
Manufacturer	CKPSMS
Item Model Number	GCGL269+GCGR269 4MM
Package Dimensions	15 x 12 x 1 inches

9. TECHNICAL SUPPORT

For further assistance or inquiries, CKPSMS offers comprehensive technical support:

- **Sewing Machine Parts Recommendation:** Our team can recommend the most suitable and compatible parts according to your specific machine model and needs.
- **Installation Guidance:** Installing sewing machine parts can sometimes be a complex task. Our team can guide you through the process, ensuring that every part is installed correctly and securely.
- **Usage Assistance:** Our team can provide guidance on how to correctly use these parts, helping you make the most out of your sewing machine and achieve desired results.

For support, please visit the official CKPSMS store or contact their customer service channels.

[Visit the CKPSMS Official Store](#)