Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Govee H70C4

Govee Christmas Lights 2 User Manual

Model: H70C4

INTRODUCTION

The Govee Christmas Lights 2 are advanced RGBWIC string lights designed to bring vibrant and customizable illumination to your holiday decorations and year-round ambiance. Featuring upgraded RGBW lamp beads with built-in IC chips for individual control, these lights offer enhanced color accuracy and a natural warm white. With smart features like shape mapping, AI-generated lighting effects, and extensive preset scenes, you can create a truly personalized lighting experience. Control is seamless via the Govee Home App, voice commands through Alexa and Google Assistant, and Matter compatibility.



Image: Govee Christmas Lights 2 product packaging, showing the lights, controller, and the Govee Home app interface on a smartphone.




Image: Close-up view of the Govee RGBWIC string lights, highlighting the individual LED beads and their vibrant colors.

What's in the Box

Verify that all components are present before beginning installation.

- Govee Christmas Lights 2 (66ft/200LEDs)
- Controller Box
- Power Adapter (IP44 rated)
- User Manual
- Quick Start Guide



Image: All components included in the Govee Christmas Lights 2 package, laid out neatly.

Setup

1. **Unpack the Lights:** Carefully unroll the string lights from their packaging. Ensure the wire is not tangled or damaged.

2. **Connect Power:** Connect the string lights to the controller box, and then connect the controller box to the power adapter. Plug the power adapter into a standard electrical outlet.
3. **Download Govee Home App:** Scan the QR code in the Quick Start Guide or search for "Govee Home" in your smartphone's app store (App Store for iOS, Google Play for Android).
4. **Register/Log In:** Open the Govee Home App and register for a new account or log in if you already have one.
5. **Add Device:** In the Govee Home App, tap the "+" icon in the top right corner to add a new device. Search for "H70C4" or allow the app to auto-scan for nearby Govee devices.
6. **Pairing:** Follow the in-app instructions to pair the lights with your smartphone via Bluetooth and connect them to your Wi-Fi network. This enables full smart control features.
7. **Placement:** Strategically place the lights on your Christmas tree, around your home, or in your desired outdoor location. Ensure the IP44 adapter is protected from direct water immersion.

Operating Instructions

The Govee Christmas Lights 2 offer multiple ways to control your lighting experience.

1. Govee Home App Control

The Govee Home App provides the most comprehensive control over your lights.

- **Color Selection:** Choose from millions of colors and adjust brightness.
- **Preset Scenes:** Access over 130 pre-programmed lighting effects for various occasions (Christmas, Rainbow, Thanksgiving, Easter, etc.).
- **DIY Mode:** Create custom lighting effects by selecting individual LED colors and patterns.
- **Shape Mapping:** Use the app's shape mapping function to precisely map the layout of your lights on a tree or other structure. This allows for dynamic effects that flow along the mapped shape.
- **AI Light Show:** Utilize the Govee AI Lighting Bot within the app to generate unique lighting effects based on text prompts or uploaded images.
- **Music Sync:** Synchronize your lights with music playing in your environment.
- **Timer & Schedule:** Set schedules for your lights to turn on/off automatically.




Image: A smartphone displaying the Govee Home app's shape mapping feature, allowing users to customize light patterns on a Christmas tree.



Image: A family using the Govee Home app to interact with the AI Lighting Bot, generating custom light effects for their Christmas tree.



Image: An illustration highlighting the availability of over 130 dynamic light effects for various occasions.

2. Voice Control (Alexa & Google Assistant)

Integrate your Govee Christmas Lights 2 with Amazon Alexa or Google Assistant for hands-free control.

1. **Enable Govee Skill/Action:** In the Alexa or Google Home app, search for and enable the "Govee" skill or action.
2. **Link Account:** Link your Govee Home account to your Alexa or Google account.

3. **Discover Devices:** Ask your voice assistant to "Discover devices" or manually add them.
4. **Voice Commands:** Use commands such as:
    - "Alexa, turn on Christmas lights."
    - "Hey Google, set Christmas lights to red."
    - "Alexa, dim Christmas lights to 50%."
    - "Hey Google, turn off Christmas lights."



Image: A woman and child in a living room, demonstrating hands-free control of the Govee Christmas Lights using voice commands with Alexa.

3. Manual Control (Controller Box)

The physical controller box provides basic functionality:

- **Power Button:** Press to turn the lights on or off.

- **Mode Button:** Cycle through pre-set lighting modes.
- **Brightness Buttons:** Adjust the brightness level.

Maintenance

- **Cleaning:** Disconnect power before cleaning. Wipe the lights and controller with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** When not in use, carefully coil the string lights and store them in their original packaging or a suitable container in a cool, dry place away from direct sunlight. This prevents tangling and damage.
- **Weather Resistance:** The lights are IP65 waterproof and dustproof, suitable for outdoor use in various weather conditions (-20°C to 40°C). However, the IP44 power adapter is not waterproof and must not be immersed in water or exposed to heavy rain/snow without proper protection.




Image: Govee Christmas Lights on a snow-covered tree, illustrating their IP65 waterproof and dustproof rating and suitable operating temperature range.

Troubleshooting

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, faulty adapter.	Check power outlet. Ensure all connections are secure. Try a different outlet.
Cannot connect to Govee Home App.	Bluetooth/Wi-Fi off, incorrect pairing mode, app issue.	Ensure Bluetooth is enabled. Restart the app and lights. Check Wi-Fi connection (2.4GHz only). Reset lights if necessary (refer to Quick Start Guide for reset procedure).
Lights flicker or display incorrect colors.	Loose connection, software glitch, damaged LED.	Check all physical connections. Restart the lights. Update Govee Home App. If a specific LED is damaged, contact support.
Voice control not working.	Govee skill/action not enabled, account not linked, device not discovered.	Verify Govee skill/action is enabled and accounts are linked in Alexa/Google Home app. Ask voice assistant to "Discover devices" again.

Specifications

Feature	Detail
Model Number	H70C4
Length	66ft (200 LEDs)
Light Type	RGBWIC LED
Control Methods	Govee Home App, Voice Control (Alexa, Google Assistant), Controller Box
Connectivity	Bluetooth, Wi-Fi (2.4GHz), Matter
Waterproof Rating	IP65 (Lights), IP44 (Adapter)
Operating Temperature	-20°C to 40°C (-4°F to 104°F)
Power Source	Corded Electric




Image: Govee Christmas String Lights size chart, illustrating recommended light lengths for various tree heights and wreath sizes.

Warranty and Support

Govee products typically come with a limited warranty. Please refer to the warranty card included in your product packaging or visit the official Govee website for the most up-to-date warranty information specific to your region.

For technical support, troubleshooting assistance, or warranty claims, please contact Govee Customer Service:

- **Govee Official Website:** www.govee.com
- **Govee Home App:** Access support directly through the app's "Feedback" or "Help" section.
- **Email Support:** Check the Govee website for specific support email addresses.

Please have your model number (H70C4) and purchase information ready when contacting support.

© 2024 Govee. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D45LSPHR

More documents and user manuals: **https://manuals.plus/**