

[Manuals.plus](#) /

› [Motorola](#) /

› Motorola All-New A10 Dual Sim Keypad Phone User Manual

Motorola Moto A10V

Motorola All-New A10 Dual Sim Keypad Phone

USER MANUAL

Introduction

Thank you for choosing the Motorola All-New A10 Dual Sim Keypad Phone. This manual provides essential information to help you set up, operate, and maintain your device. Please read it carefully to ensure optimal performance and longevity of your phone.

The Moto A10V is designed for reliable communication, featuring a durable polycarbonate body, dual SIM support, and an 800 mAh battery for extended standby time. It includes convenient features such as auto call recording, wireless FM radio, and Bluetooth connectivity.

Package Contents

- Motorola All-New A10 Keypad Phone
- Power Adapter
- Battery (pre-installed or separate)
- User Manual (this document)

Please check all items are present and in good condition. If any item is missing or damaged, contact your retailer immediately.

Safety Information

- **Battery Safety:** Use only Motorola-approved batteries and chargers. Do not disassemble, crush, or puncture the battery. Avoid exposing the battery to high temperatures or direct sunlight.
- **Hearing Protection:** Avoid prolonged listening at high volume levels to prevent hearing damage.
- **Driving Safety:** Do not use your phone while driving. Always prioritize safe driving.
- **Medical Devices:** Maintain a safe distance between your phone and medical devices like pacemakers. Consult your physician and the medical device manufacturer for specific guidelines.
- **Disposal:** Dispose of the phone and battery responsibly according to local regulations. Do not dispose of with household waste.

Setup

Follow these steps to prepare your phone for first use:

1. **Insert SIM Card(s):** Locate the SIM card slot(s) on your phone. Carefully insert your standard or micro SIM card(s) into the designated slots. Ensure the gold contacts face downwards.
2. **Insert Battery:** If the battery is not pre-installed, align the battery contacts with the terminals inside the battery compartment and gently press down until it clicks into place.
3. **Charge the Battery:** Connect the power adapter to your phone's charging port and plug it into a power outlet. Charge the phone fully before first use. The battery indicator will show charging status.
4. **Power On/Off:** Press and hold the Power/End Call key to turn the phone on or off.



Figure 1: Motorola A10 Keypad Phone (Teal Blue)

This image displays the Motorola A10 keypad phone in Teal Blue, showcasing its front and side profile. The phone features a clear display, a standard keypad, and a durable casing.

Operating Your Phone

Basic Functions

- **Making Calls:** Enter the phone number using the keypad and press the Call key.

- **Receiving Calls:** Press the Call key when the phone rings to answer an incoming call.
- **Sending SMS:** Navigate to the 'Messages' menu, select 'Write message', type your text, and send it to the desired recipient.
- **Keypad Lock:** To lock the keypad, press the Left Soft key (Menu) then the '*' key. To unlock, press the Left Soft key (Menu) then the '*' key again.

Special Features

The Moto A10V comes equipped with several useful features:

- **Voice Feature:** This feature provides hands-free navigation by speaking out menu options, call notifications, and more. To activate or deactivate, navigate to the phone settings and look for 'Voice Feature' or 'Talk Aloud' options.



Figure 2: Voice Feature Interface

This image illustrates the Voice Feature on the Motorola A10, showing the 'Voice' icon on the display and indicating support for both Hindi and English languages.

- **Wireless FM with Recording:** Enjoy your favorite radio stations without needing a headset. You can also record

FM broadcasts. Access this feature from the 'Multimedia' or 'Entertainment' menu.



Figure 3: Wireless FM Radio Interface

This image shows the Motorola A10's display with the Wireless FM radio interface, indicating the frequency and controls for playback and recording.

- **Auto Call Recording:** This function allows you to automatically record your phone conversations. To enable or disable, go to 'Call Settings' or 'Recorder' in the phone's menu.
- **Bluetooth Connectivity:** Pair your phone with other Bluetooth-enabled devices like headsets or speakers. Navigate to 'Settings' > 'Bluetooth' to turn on Bluetooth, search for devices, and pair.
- **Instant Torch:** The phone includes a built-in torch for convenience. Typically, this can be activated by a long press on a specific key (e.g., '0' or a dedicated torch key) or found in the 'Tools' menu.

Instant Torch

Shining Light in the Dark



Figure 4: Instant Torch Feature

This image highlights the Instant Torch feature of the Motorola A10, showing the phone's top edge emitting a bright light in a dark environment.

Display and Battery

- **1.8" Big Display:** The phone features a clear 1.8-inch display for easy viewing of menus, contacts, and messages.




Figure 5: 1.8" Display View

This image showcases the 1.8-inch display of the Motorola A10, demonstrating its size and clarity for viewing content.

- **Powerful 800 mAh Battery:** The 800 mAh battery provides up to 7 days of standby time, ensuring long-lasting performance.

Powerful Battery

Upto 7 Days of Backup



Figure 6: Battery Indicator

This image visually represents the powerful battery of the Motorola A10, showing a glowing battery icon to signify its long-lasting capacity.

Maintenance

- **Cleaning:** Use a soft, dry cloth to clean the phone's surface. Avoid using liquid cleaners or abrasive materials.
- **Battery Care:** To prolong battery life, avoid overcharging and fully discharging the battery regularly. Store the phone in a cool, dry place when not in use for extended periods.
- **Storage:** Keep the phone away from extreme temperatures, direct sunlight, and moisture.

Troubleshooting

If you encounter issues with your Motorola A10, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Phone does not turn on	Low battery; Battery not inserted correctly	Charge the battery; Reinsert the battery properly
No network signal	SIM card not inserted; Out of network coverage	Ensure SIM card is correctly inserted; Move to an area with network coverage
Cannot make/receive calls	No network; SIM card issue; Call barring enabled	Check network signal; Reinsert SIM; Disable call barring in settings
Battery drains quickly	High usage; Background features active	Reduce usage; Turn off unused features like Bluetooth/FM
Keypad unresponsive	Keypad locked; Software glitch	Unlock keypad (Menu + *); Restart the phone

If the problem persists, please contact customer support.

Specifications

Feature	Specification
Model Number	Moto A10V
Operating System	RTOS
Product Dimensions	5.4 x 7 x 12.2 cm
Item Weight	160 g
Battery Capacity	800 mAh Lithium Ion
Phone Standby Time	Up to 240 Hours (10 days)
Display Resolution	720 x 1280 (Note: This resolution seems high for a 1.8" feature phone, likely a generic value. Actual display resolution for a 1.8" screen is typically much lower.)
Connectivity	Bluetooth
Special Features	Wireless FM with Recording, Voice Feature, Auto Call Recording, Instant Torch
Audio Jack	2.5 mm
Form Factor	Bar
Color	Teal Blue
CPU Model	MediaTek Helio
Memory Storage Capacity	32 GB (Note: This likely refers to expandable memory support, not internal storage for a feature phone.)

Warranty and Support

Your Motorola All-New A10 Keypad Phone comes with a**2 Years Replacement Warranty**. This warranty covers

manufacturing defects and ensures peace of mind for your purchase.

For warranty claims, technical support, or any other inquiries, please contact Motorola customer service or the retailer from whom you purchased the device. Keep your purchase receipt as proof of purchase for warranty purposes.

You can also visit the official Motorola store on Amazon for more information and support:[Motorola Store](#)

© 2024 Motorola. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D45MQ8RY>

More documents and user manuals: <https://manuals.plus/>