



Manuals.plus /

› ACCOHOHO /

› ACCOHOHO Farmhouse 9-Drawer Dresser User Manual

ACCOHOHO LM055-529DBK

ACCOHOHO Farmhouse 9-Drawer Dresser User Manual

Model: LM055-529DBK

Brand: ACCOHOHO

1. SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Anti-Topping Device:** This dresser is equipped with an anti-topping device. It is crucial to install this device securely to a wall stud to prevent the dresser from tipping over, especially in households with children or pets. Failure to install this device can result in serious injury or death.
- **Heavy Item:** This product is heavy (approximately 125 pounds). Exercise caution when lifting or moving. It is recommended that two or more people handle the dresser during assembly and relocation.
- **Assembly:** Follow all assembly steps precisely. Do not skip steps or use incorrect hardware. Ensure all connections are tight before use.
- **Children Safety:** Do not allow children to climb on or play with the dresser or its drawers. Keep small parts and hardware away from children during assembly.
- **Weight Capacity:** Do not overload drawers. Distribute weight evenly. The top surface can support up to 75 lbs.

PRODUCT DIMENSIONS




Image: Illustration showing the dresser dimensions (52"W x 16"D x 36"H) and the importance of the anti-topping device for stability. It also shows drawer dimensions and weight capacity.

2. PRODUCT OVERVIEW

The ACCOHOHO Farmhouse 9-Drawer Dresser is a versatile furniture piece designed for various rooms, including bedrooms, living rooms, and hallways. It features a classic farmhouse design with metal hardware and a rustic wood finish, providing ample storage with nine spacious drawers.

Dimensions: 16"D x 52"W x 36"H

Color: Black

Material: Engineered Wood with Oak finish

Storage: Nine drawers for organizing personal essentials and household items.

Features: Waterproof surface, stable support base, and an anti-topping device for enhanced safety.



Image: The ACCOHOHO Farmhouse 9-Drawer Dresser, black, positioned in a bedroom setting, showcasing its design and size relative to other furniture.

3. PACKAGE CONTENTS

Upon opening the package, verify that all components and hardware are present and undamaged. A detailed list of parts and hardware is included within the packaging. If any parts are missing or damaged, please contact customer support immediately.

Typical contents include:

- Dresser panels (top, bottom, sides, back)
- Drawer panels and bottoms
- Drawer slides and hardware
- Drawer handles and screws
- Anti-topping device and wall mounting hardware
- Assembly hardware (screws, dowels, cam locks, etc.)

- Assembly instruction manual

4. ASSEMBLY INSTRUCTIONS (SETUP)

Assembly is required for this dresser. Step-by-step instructions and the necessary hardware pack are included in your product package. Please follow these instructions carefully for proper assembly.

1. **Preparation:** Clear a spacious area for assembly. Lay out all parts and hardware. Identify each part using the labels provided.
2. **Tools:** A screwdriver is typically sufficient. While power tools are not strictly necessary, if used, exercise extreme caution to avoid overtightening screws or damaging components.
3. **Frame Assembly:** Begin by assembling the main frame of the dresser according to the diagrams. Ensure all connections are secure.
4. **Drawer Assembly:** Assemble each drawer individually. Pay close attention to the orientation of drawer slides to ensure smooth operation.
5. **Drawer Installation:** Carefully insert the assembled drawers into the dresser frame. Test each drawer for smooth opening and closing.
6. **Anti-Topping Device Installation:** This is a critical safety step. Securely attach the anti-topping device to the back of the dresser and then to a wall stud using the provided hardware. This prevents accidental tipping.



**AMPLE
STORAGE SPACE**



WATERPROOF
SURFACE



EASY
ASSEMBLY



HIGH-GRADE
QUALITY

Image: An overhead view of the dresser with several drawers open, illustrating the depth and width of the storage compartments suitable for various items.



**AMPLE
STORAGE SPACE**



WATERPROOF
SURFACE



EASY
ASSEMBLY



HIGH-GRADE
QUALITY

Image: A closer front view of the dresser with drawers open, demonstrating the practical storage capacity for folded clothes and other personal items.



Unique Sturdy Construction

With hidden extra protection building for long-term use



Stable Support Base

The wooden pedestal ensures stability and no wobbling



Image: Detailed view of the dresser's base and corner construction, highlighting the hidden reinforced protection and stable wooden pedestal designed for long-term durability.

5. OPERATION (USAGE)

The ACCOHOHO Farmhouse 9-Drawer Dresser is designed for practical storage and can serve multiple functions within your home.

- **Drawer Use:** Gently pull and push drawers to open and close. Avoid forcing drawers, especially if they feel stuck, as this may indicate an obstruction or misalignment.
- **Storage:** Utilize the nine drawers to store clothing, linens, accessories, or other household items. Organize contents to maximize space and maintain drawer functionality.
- **Multifunctional Placement:** This dresser is suitable for various rooms:
 - **Bedroom:** Ideal for clothes storage.
 - **Living Room:** Can serve as a stylish storage unit or a TV stand (ensure TV weight is within limits, typically up to 75 lbs for the top surface).

- **Hallway/Entryway:** Provides convenient storage for items like keys, mail, or seasonal accessories.

6. MAINTENANCE AND CARE

Proper care will help maintain the appearance and longevity of your dresser.

- **Cleaning:** Wipe the surface with a dry, soft cloth. The dresser features a waterproof surface, making it easy to clean dust. Avoid abrasive cleaners or harsh chemicals, which can damage the finish.
- **Spills:** Immediately wipe up any spills with a clean, dry cloth to prevent staining or damage to the wood finish.
- **Sunlight and Heat:** Avoid placing the dresser in direct sunlight or near heat sources (e.g., radiators, heating vents) to prevent fading, warping, or cracking of the wood.
- **Regular Checks:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.
- **Moving:** When moving the dresser, always lift it rather than dragging it to prevent damage to the base and floor.

7. TROUBLESHOOTING

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Dresser wobbles or feels unstable.	Loose connections; uneven floor; anti-topping device not installed.	Ensure all screws are tightened. Place on a level surface or use shims. Install the anti-topping device securely to a wall stud.
Drawers do not slide smoothly or are misaligned.	Incorrect drawer slide installation; obstruction in the drawer track; drawer overloaded.	Review assembly instructions for correct drawer slide orientation. Check tracks for debris. Reduce drawer contents.
Surface shows minor scratches or marks.	Normal wear and tear; impact during handling or use.	Use a furniture marker or touch-up pen matching the finish. Use coasters or protective pads for items placed on top.
Missing or damaged parts upon delivery.	Shipping damage; packaging error.	Do not proceed with assembly. Contact ACCOHOHO customer support immediately with your purchase details.

If the issue persists after attempting these solutions, please contact ACCOHOHO customer support for further assistance.

8. SPECIFICATIONS

Brand	ACCOHOHO
Model Name	LM055-529DBK
Product Dimensions	16"D x 52"W x 36"H
Color	Black
Room Type	Bedroom, Living Room, Hallway
Furniture Finish	Oak
Product Care Instructions	Wipe with Dry Cloth
Assembly Required	Yes
Item Weight	125 Pounds
Number of Drawers	9
Target Audience	Adult
Manufacturer	ACCOHOHO
ASIN	B0DSV7KYB5
Date First Available	January 12, 2025

9. WARRANTY AND SUPPORT

This ACCOHOHO dresser comes with a Limited Warranty. For specific details regarding the warranty coverage and duration, please refer to the documentation included with your product or contact ACCOHOHO customer support.

Customer Support: If you have any questions, concerns, or require assistance with assembly, parts, or product functionality, please do not hesitate to contact ACCOHOHO customer service. We are committed to providing support before and after your purchase.

For support, please visit the [ACCOHOHO Store on Amazon](#) or refer to the contact information provided in your product packaging.