

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [VINABTY](#) /

› [VINABTY RG94A/BGEF RG94 Remote Control User Manual for York AC Units](#)

VINABTY RG94A/BGEF RG94

VINABTY RG94A/BGEF RG94 Remote Control User Manual

Model: RG94A/BGEF RG94

Compatible with York Mini Split-Type Room AC Air Conditioners

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your VINABTY RG94A/BGEF RG94 remote control. This remote is designed as a replacement for various York Mini Split-Type Room AC Air Conditioner models, including RG93A/BGCEF and RG93A/BGEF series, and specific High Wall Inverter models such as YHKE09ZJ6AMBORX, YHKE12ZJ6AMBORX, YHKE18ZJ6AMBORX, YHKE24ZJ6AMBORX, YHKE36ZJ6AMBORX, YHJE09ZT6AMHORX, YHJE12ZT6AMHORX, YHJE18ZT6AMHORX, YHJE23ZT6AMHORX, YHKE09ZT6AMHORX, YHKE12ZT6AMHORX, YHKE18ZT6AMHORX, and YHKE24ZT6AMHORX. Please read this manual thoroughly before using the remote control to ensure proper function and longevity.

PRODUCT OVERVIEW

The VINABTY RG94A/BGEF RG94 is an infrared remote control designed for ease of use with compatible York air conditioning units. It features an ergonomic design and a total of 20 buttons for comprehensive control over your AC unit's functions.



Image: Front view of the VINABTY RG94A/BGEF RG94 remote control, showing its white casing and button layout.

SETUP

Battery Installation

1. Locate the battery compartment on the back of the remote control.
2. Slide open the battery compartment cover.
3. Insert two AAA batteries (not included) according to the polarity indicators (+ and -) inside the compartment. Ensure correct orientation.
4. Close the battery compartment cover securely.

Note: Always use new batteries and replace both batteries at the same time. Do not mix old and new batteries or different types of batteries.

OPERATING INSTRUCTIONS

Point the remote control directly at the indoor unit of your air conditioner. Ensure there are no obstructions between the remote and the unit.

Common Button Functions (Example Layout)

- **POWER:** Turns the AC unit ON or OFF.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP ▲ / ▼:** Adjusts the temperature setting up or down.
- **FAN:** Adjusts fan speed (e.g., Auto, Low, Medium, High).
- **SWING:** Controls the louver swing function.
- **TIMER:** Sets the ON/OFF timer for the unit.
- **SLEEP:** Activates or deactivates sleep mode for energy saving and comfort during sleep.
- **LIGHT:** Turns the display light on the indoor unit ON or OFF.
- **I FEEL / FOLLOW ME:** Activates a sensor in the remote to measure ambient temperature for more precise control.
- **TURBO / JET:** Activates maximum cooling or heating for rapid temperature change.

Note: Specific button labels and functions may vary slightly depending on your York AC unit model. Refer to your AC unit's original manual for detailed function descriptions.

MAINTENANCE

Battery Replacement

When the remote control's operating range decreases or it becomes unresponsive, it is time to replace the batteries. Follow the battery installation steps outlined in the "Setup" section.

Cleaning

To clean the remote control, wipe it gently with a soft, dry cloth. Do not use liquid cleaners, abrasive cleaners, or chemical solvents, as these may damage the remote's surface or internal components.

TROUBLESHOOTING

- **Remote not responding:**
 - Check if the batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new AAA batteries.
 - Ensure there are no obstructions between the remote control and the AC unit's receiver.
 - Confirm the remote is pointed directly at the AC unit.
- **Short operating range:**
 - Replace the batteries.
 - Ensure the remote control is within the maximum range of 33 feet (10 meters) from the AC unit.
 - Check for strong light sources (e.g., direct sunlight, fluorescent lights) that might interfere with the infrared signal.
- **AC unit not performing desired function:**
 - Verify that the remote control model (RG94A/BGEF RG94) is compatible with your specific York AC unit model.
 - Ensure the AC unit is powered on and functioning correctly.

SPECIFICATIONS

Brand	VINABTY
Model Number	RG94A/BGEF RG94
Compatible Devices	York Mini Split-Type Room AC Air Conditioner
Connectivity Technology	Infrared
Maximum Range	33 Feet (approx. 10 meters)
Battery Type	2 x AAA (not included)
Button Quantity	20
Item Weight	2.3 Ounces
Dimensions (L x W x H)	5"L x 2"W x 0.55"H
Special Feature	Ergonomic

WARRANTY AND SUPPORT

Warranty Information

This VINABTY remote control comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact VINABTY customer support through your retailer or the official VINABTY website. Provide your product model number (RG94A/BGEF RG94) and purchase details when contacting support.

