

[Manuals.plus](#) /

> [KEMEI](#) /

> KEMEI 2269 Professional Hair Clipper User Manual

KEMEI KEMEI-2269-TY

KEMEI 2269 Professional Hair Clipper

User Manual

INTRODUCTION

Thank you for choosing the KEMEI 2269 Professional Hair Clipper. This cordless electric hair and beard trimmer is designed for precision and ease of use, featuring a powerful motor, long-lasting battery, and an intelligent LED display. This manual provides essential information for safe operation, maintenance, and optimal performance of your device. Please read it thoroughly before first use.



Image: The KEMEI 2269 Hair Clipper, highlighting its user-friendly design suitable for beginners.

PACKAGE CONTENTS

Please check the package contents upon unboxing to ensure all items are present:

- 1 x KEMEI 2269 Professional Electric Hair Clipper
- 4 x Guide Combs (1mm, 3mm, 5mm, 7mm)
- 1 x Barber Comb
- 1 x USB Charging Cable (Type-C)
- 1 x Cleaning Brush
- 1 x Lubricating Oil Bottle
- 1 x Velvet Pouch



Image: All components included in the KEMEI 2269 Hair Clipper package, including the clipper, guide combs, oil, brush, USB cable, and comb.

PRODUCT FEATURES

Precision Powder Metallurgy Blades

The KEMEI 2269 features new precision powder metallurgy blades, designed for sharpness and safety. These blades ensure easy, fast, and comfortable cutting, ideal for fine trimming, fading, gradient styles, and artistic sculpting.

DLC Carbon Steel Blades

Steel precision hair trimmer



Image: Detailed view of the DLC Carbon Steel blades, emphasizing their precision and sharpness.

Large Capacity Lithium Battery & USB Type-C Fast Charging

Equipped with a built-in 2000 mAh lithium battery, the clipper offers up to 300 minutes of continuous operation after a 3-hour charge. The universal USB Type-C charging allows for convenient charging anywhere.

Large Capacity Lithium Battery

USB Fast Charging



Image: The KEMEI 2269 clipper being charged via USB, illustrating its 2000mAh battery, 3-hour charging time, and 300-minute working time.

Intelligent LED Display

The smart LED screen clearly displays the remaining power percentage, lubrication tips, and charging status, ensuring you are always aware of the device's condition.



Image: A detailed view of the clipper's LED display, indicating battery percentage, lubrication reminders, and charging status.

Powerful and Durable Motor

Equipped with a new high-speed motor, the KEMEI 2269 is powerful enough to cut all hair types smoothly and efficiently, operating with low noise for a comfortable experience.

More efficiency professional motor

Powerful high speed motor



Image: An illustration of the clipper's powerful 7500 MAX RPM motor, highlighting its efficiency.

Versatile Use with Guide Combs

The kit includes four guide combs (1mm, 3mm, 5mm, 7mm) allowing for precise control over hair length, making it suitable for various hairstyles and beard trimming.

4 Types of Guide Combs

FOUR LENGTH GUIDE COMBS DESIGN YOUR HAIR IN ALL DIRECTIONS




Image: The four included guide combs (1mm, 3mm, 5mm, 7mm) and examples of hairstyles achievable with them.

SETUP

1. **Initial Charge:** Before first use, fully charge the clipper for approximately 3 hours. The LED display will indicate charging progress and full charge.
2. **Attach Guide Comb:** Select the desired guide comb (1mm, 3mm, 5mm, or 7mm) and securely attach it to the clipper head. Ensure it clicks into place.
3. **Lubricate Blades:** Apply a few drops of the included lubricating oil to the blades before each use to ensure smooth operation and prolong blade life.

OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the power button to turn the clipper on. Press it again to turn it off.
2. **Hair Trimming:**

- For an even cut, always move the clipper against the direction of hair growth.
 - Start with a longer guide comb if you are unsure of the desired length, and gradually switch to shorter combs if needed.
 - Use the barber comb to guide hair and ensure a consistent cut.
3. **Detailing and Edging:** Remove the guide comb for precise detailing, outlining, and creating sharp lines around the neckline, sideburns, and beard.
 4. **Beard Trimming:** Use appropriate guide combs for beard length. For shaping, use the clipper without a comb, being careful around sensitive areas.

MAINTENANCE

Regular maintenance ensures the longevity and optimal performance of your KEMEI 2269 Hair Clipper.

1. **Cleaning Blades:** After each use, turn off the clipper and use the cleaning brush to remove any hair clippings from the blades. For a more thorough clean, the blades can be rinsed under running water (ensure the clipper body does not get wet). Allow blades to air dry completely before reattaching.
2. **Lubrication:** Apply 1-2 drops of the provided lubricating oil to the blades after every few uses, or when the LED display indicates "Lubrication Tips". Turn the clipper on for a few seconds to distribute the oil evenly.
3. **Storage:** Store the clipper and its accessories in the velvet pouch in a cool, dry place, away from direct sunlight and moisture.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper not turning on.	Battery is depleted.	Charge the clipper fully using the USB Type-C cable.
Blades pulling hair or cutting poorly.	Blades are dirty or not lubricated.	Clean the blades thoroughly and apply lubricating oil.
Clipper making unusual noise.	Blades might be misaligned or need lubrication.	Check blade alignment and apply lubricating oil. If problem persists, contact support.
LED display not working.	Device malfunction.	Ensure the device is charged. If still not working, contact customer support.

SPECIFICATIONS

- Model:** KEMEI-2269-TY
- Power Source:** Battery Powered
- Battery Type:** Lithium-ion (2000 mAh)
- Charging Time:** Approximately 3 hours
- Run Time:** Up to 300 minutes (5 hours)
- Blade Material:** Powder Metallurgy / Carbon Steel
- Motor Speed:** Up to 7500 RPM
- Guide Comb Sizes:** 1mm, 3mm, 5mm, 7mm
- Dimensions:** 15cm (Length) x 4.1cm (Blade Width) x 3cm (Body Width)
- Weight:** Approximately 450 grams

Country of Origin: China



Image: Diagram showing the physical dimensions of the KEMEI 2269 Hair Clipper.

WARRANTY AND SUPPORT

Your KEMEI 2269 Professional Hair Clipper is covered by a standard return policy. For specific warranty details, returns, or technical support, please refer to your purchase documentation or contact the seller directly. For further assistance, please visit the KEMEI official website or contact their customer service.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D46G7F32>

More documents and user manuals: <https://manuals.plus/>