

Shine LUEST 75468361-3f8d-4ee1-9379-bc51c9de095d

Modern LED Ceiling Light User Manual

Model: 75468361-3f8d-4ee1-9379-bc51c9de095d

INTRODUCTION

Thank you for choosing the Modern LED Ceiling Light from Shine LUEST. This manual provides important information regarding the installation, operation, maintenance, and troubleshooting of your new LED ceiling light. Please read this manual thoroughly before installation and retain it for future reference.

This modern LED ceiling light features a dimmable function with adjustable color temperature, designed for flush mount installation in various indoor settings such as bedrooms and living rooms. It is available in Square White 8 Rings and Square White 4 Rings configurations.

IMPORTANT SAFETY INSTRUCTIONS

- **WARNING:** Risk of electric shock. Disconnect power at the fuse box or circuit breaker before installation or servicing.
- Installation must be performed by a qualified electrician in accordance with all local electrical codes.
- Ensure the mounting surface can support the weight of the fixture.
- Do not connect this fixture to a dimmer switch other than the included remote control, as it is already dimmable.
- This product is for indoor use only. Do not expose to water or moisture.
- Do not attempt to modify the fixture. Any modifications may void the warranty and create a safety hazard.

WHAT'S IN THE BOX

Please check the contents of your package. If any items are missing or damaged, contact customer support immediately.

- LED Ceiling Light Fixture (Square White 8 Rings or Square White 4 Rings, depending on model)
- Remote Control
- Mounting Hardware (screws, wire nuts, etc.)
- User Manual (this document)



Image: The complete LED ceiling light fixture, showcasing its modern design with multiple square rings.

SETUP AND INSTALLATION

Tools Required (Not Included):

- Phillips Head Screwdriver
- Wire Strippers
- Electrical Tape
- Ladder
- Voltage Tester

Installation Steps:

1. **Turn Off Power:** Locate the circuit breaker or fuse box and turn off the power to the junction box where the fixture will be installed. Verify power is off using a voltage tester.

2. **Prepare Mounting Surface:** Ensure the ceiling junction box is securely mounted and capable of supporting the fixture's weight.
3. **Attach Mounting Bracket:** Secure the mounting bracket (usually included with hardware) to the junction box using the provided screws.
4. **Wire Connections:**
 - Connect the **black** wire from the fixture to the **black** (live) wire from the junction box.
 - Connect the **white** wire from the fixture to the **white** (neutral) wire from the junction box.
 - Connect the **ground** wire from the fixture to the **ground** wire from the junction box (bare copper or green).
 - Secure all connections with wire nuts and electrical tape.
5. **Mount the Fixture:** Carefully lift the fixture and align it with the mounting bracket. Secure the fixture to the bracket using the provided screws. Ensure no wires are pinched.
6. **Restore Power:** Turn the power back on at the circuit breaker or fuse box.



Image: A diagram illustrating the dimensions of the 8-ring ceiling light fixture and indicating compatibility with the remote control, while

showing incompatibility with standard dimmable wall switches.




Image: A diagram illustrating the dimensions of the 4-ring ceiling light fixture and indicating compatibility with the remote control, while showing incompatibility with standard dimmable wall switches.

OPERATING INSTRUCTIONS

Your LED ceiling light is operated using the included remote control. It features adjustable color temperature and brightness.

Remote Control Functions:

- **Power On/Off:** Press the **ON/OFF** button to turn the light on or off.
- **Brightness Adjustment:** Use the **+** and **-** buttons to adjust brightness from 10% to 100%.
- **Color Temperature Adjustment:** Use the **CCT+** and **CCT-** buttons to cycle through color temperatures from 3000K (warm white) to 6000K (cool white).

- **Preset Modes:** Some remotes may include preset buttons for specific color temperatures (e.g., 3000K, 4000K, 6000K) or brightness levels.



Image: A hand holding the remote control, demonstrating its use to operate the 8-ring LED ceiling light.

COLOR TEMPERATURE AND BRIGHTNESS

Color Temperature:3000K-6000K



Brightness control:10%-100%




Image: Visual representation of the adjustable color temperature (3000K warm white, 4000K neutral white, 6000K cool white) and brightness levels (10% to 100%) of the LED ceiling light.

CARE AND MAINTENANCE

- **Cleaning:** Always turn off the power before cleaning. Use a soft, dry cloth to wipe the fixture. Do not use abrasive cleaners, solvents, or polishes as they may damage the finish or electrical components.
- **Bulb Replacement:** This fixture uses integrated LED strips. Individual LED strips are designed for easy replacement if needed. Contact customer support for replacement parts and instructions.
- **Inspection:** Periodically check the fixture for any loose connections or signs of damage. If any issues are found, disconnect power and contact a qualified electrician or customer support.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Light does not turn on.	No power to the fixture. Loose wire connection. Remote control battery is dead. Fixture defect.	Check circuit breaker/fuse. Verify all wire connections are secure (power off first). Replace remote control battery. Contact customer support.
Light flickers or dims unexpectedly.	Loose wire connection. Incompatible wall dimmer switch (if used). Fixture defect.	Check wire connections (power off first). Ensure no external dimmer switch is used; only the provided remote control. Contact customer support.
Remote control not working.	Dead battery. Obstruction between remote and fixture. Remote not paired (if applicable).	Replace battery. Ensure clear line of sight. Refer to remote control pairing instructions (if provided separately).
Some rings did not light up.	Faulty LED strip.	Contact customer support for replacement parts.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Shine LUEST
Model Number	75468361-3f8d-4ee1-9379-bc51c9de095d
Style	Square White 8 Rings + Square White 4 Rings
Color	White
Material	Acrylic, Metal
Light Source Type	LED (Integrated)
Wattage	Max. 108 watts
Brightness	8000 lumens
Color Temperature	3000K - 6000K (Dimmable)
Voltage	110-220V
Control Method	Remote Control
Installation Type	Flush Mount

Feature	Detail
Indoor/Outdoor Usage	Indoor Only
8-Ring Fixture Dimensions	39.4" x 31.5" (100cm x 80cm), Ceiling Plate: 16.53" (42cm), Height: approx. 5.5" (14cm)
4-Ring Fixture Dimensions	26" x 26" (66cm x 66cm), Ceiling Plate: 5.9" (15cm), Height: approx. 2.76" (7cm)

WARRANTY INFORMATION

This product is covered by a limited warranty against defects in materials and workmanship. For specific warranty terms and conditions, please refer to the documentation included with your purchase or contact customer support. The warranty typically covers manufacturing defects but does not cover damage caused by improper installation, misuse, accidents, or unauthorized modifications.

If some rings did not light up, replacements can be provided under warranty. Please contact customer support for assistance.

CUSTOMER SUPPORT

For technical assistance, replacement parts, or any questions regarding your Shine LUEST LED Ceiling Light, please contact our customer support team.

Please have your model number (**75468361-3f8d-4ee1-9379-bc51c9de095d**) and purchase date ready when contacting support.

You can visit the [Shine LUEST Store on Amazon](#) for more information or to contact the seller directly.

© 2024 Shine LUEST. All rights reserved.

Related Documents

	<p>Shine LUEST Modern Rings Ceiling Light Installation Manual</p> <p>Comprehensive installation manual for the Shine LUEST Modern Rings Ceiling Light (Model SL-CL-801/2), covering safety, parts, assembly, installation, troubleshooting, care, and warranty information.</p>
---	---