

Umarex 2251526-P

Umarex Synergis Elite Multi-Shot Underlever .22 Caliber Pellet Gun Air Rifle User Manual

Model: 2251526-P

1. INTRODUCTION

Thank you for choosing the Umarex Synergis Elite Multi-Shot Underlever .22 Caliber Pellet Gun Air Rifle. This manual provides essential information for the safe and effective operation, maintenance, and care of your air rifle. Please read this manual thoroughly before using the air rifle and keep it for future reference. Proper understanding and adherence to these instructions will ensure optimal performance and longevity of your product.

2. SAFETY INFORMATION

Always prioritize safety when handling any air rifle. Failure to follow these safety guidelines can result in serious injury or death.

- **Treat every air rifle as if it were loaded.** Never assume an air rifle is unloaded.
- **Always point the muzzle in a safe direction.** A safe direction is one where an accidental discharge will not cause injury or damage.
- **Keep your finger off the trigger until ready to shoot.** Rest your finger outside the trigger guard.
- **Be sure of your target and what is beyond it.** Know what you are shooting at and what is behind it.
- **Wear eye protection.** Always wear safety glasses when shooting an air rifle.
- **Wear hearing protection.** While air rifles are generally quieter than firearms, hearing protection is recommended.
- **Store air rifles and pellets separately and securely.** Keep them out of reach of children and unauthorized users.
- **Never shoot at hard surfaces or water.** Pellets can ricochet.
- **Do not alter or modify your air rifle.** Any modifications can compromise safety and performance.
- **Read and understand all warnings and instructions.**

3. SETUP

3.1 Unpacking and Initial Inspection

Carefully remove your air rifle from its packaging. Inspect the air rifle for any signs of damage that may have occurred during shipping. If you find any damage, do not attempt to use the air rifle and contact Umarex customer support immediately.

3.2 Loading Pellets

The Umarex Synergis Elite features a multi-shot mechanism. Use only .22 caliber pellets. Refer to the specific instructions below for loading your magazine:

1. Ensure the air rifle is unloaded and the safety is engaged.
2. Locate the magazine release mechanism, typically near the breech.
3. Remove the magazine from the air rifle.
4. Carefully insert .22 caliber pellets into each chamber of the magazine, ensuring they are seated correctly and flush with the magazine surface. Do not force pellets.
5. Reinsert the loaded magazine into the air rifle until it clicks securely into place.

4. OPERATING THE AIR RIFLE

4.1 Cocking the Underlever

To cock the air rifle and prepare it for firing:

1. Ensure the air rifle is pointed in a safe direction.
2. Locate the underlever beneath the barrel.
3. Pull the underlever down and back towards the stock in a smooth, continuous motion until it locks into place. This action compresses the mainspring and indexes the next pellet from the magazine into the breech.
4. Return the underlever to its original position, ensuring it latches securely. The safety mechanism will typically engage automatically upon cocking.

4.2 Aiming and Firing

Once the air rifle is cocked and loaded:

1. Disengage the safety only when you are ready to shoot and your target is clear.
2. Assume a stable shooting position.
3. Align your sights with the target.
4. Place your finger on the trigger and apply steady, even pressure until the shot breaks.
5. After firing, re-engage the safety if you are not immediately taking another shot.

5. MAINTENANCE

Regular maintenance is crucial for the longevity and performance of your air rifle.

5.1 Cleaning the Barrel

The barrel should be cleaned periodically to remove lead fouling and debris.

- Use a .22 caliber cleaning kit designed for air rifles.
- Push cleaning pellets or patches through the barrel from the breech end (if possible) to the muzzle.
- Do not use harsh solvents or wire brushes, as they can damage the barrel's rifling.

5.2 Lubrication and Storage

Apply a light coat of silicone-based airgun oil to external metal parts to prevent rust. Store your air rifle in a cool, dry place, preferably in a gun case, and unloaded.

6. TROUBLESHOOTING

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Pellet not firing or low power	Not fully cocked; damaged pellet; worn seal	Ensure full cocking stroke; use undamaged pellets; contact support for seal replacement.
Inaccurate shots	Loose scope/sights; dirty barrel; inconsistent pellets; improper hold	Check and tighten sights; clean barrel; use quality, consistent pellets; practice proper shooting technique.
Magazine not feeding	Incorrectly loaded pellets; damaged magazine; debris in mechanism	Ensure pellets are seated correctly; inspect magazine for damage; clean magazine and feeding area.

7. SPECIFICATIONS

Please note: The following specifications are typical for a .22 caliber multi-shot underlever air rifle. Specific performance data for the Umarex Synergis Elite was not available in the provided product information, which contained details for a different model.

Feature	Detail
Caliber	.22 (5.5mm)
Action	Underlever, Multi-shot
Power Source	Spring-Piston or Gas Ram (typical for underlever)
Ammunition Type	Lead Pellets
Muzzle Velocity (approx.)	Up to 900-1000 FPS (with lightweight alloy pellets)
Energy (approx.)	Up to 20-25 FPE (Foot Pounds Energy)
Safety	Automatic
Overall Length (approx.)	43-47 inches
Weight (approx.)	7-9 lbs

8. PRODUCT IMAGES AND VIDEOS

No relevant product images or official product videos were available in the provided data for direct embedding in this manual.

9. WARRANTY AND SUPPORT

Umarex products are manufactured to high standards and are backed by a limited warranty. For specific warranty details,

please refer to the warranty card included with your product or visit the official Umarex website. For technical support, parts, or service, please contact Umarex customer service.

You can find more information and contact details on the official Umarex store page:[Umarex Store on Amazon](#)

© 2024 Umarex. All rights reserved.

This manual is for informational purposes only. Specifications are subject to change without notice.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question