

Kuulaa KL-YD59

Kuulaa Magnetic Power Bank 5000mAh User Manual

Model: KL-YD59 | Brand: Kuulaa

INTRODUCTION

Thank you for choosing the Kuulaa Magnetic Power Bank 5000mAh. This wireless portable charger is designed to provide convenient and efficient power for your compatible devices, featuring a built-in stand and magnetic wallet functionality. Please read this manual carefully before use to ensure optimal performance and safety.

WHAT'S IN THE BOX

- Magnetic Power Bank 5000mAh x 1
- USB-C Charging Cable x 1
- User Manual x 1

PRODUCT FEATURES

- **Mag-Safe Compatibility:** Works with iPhone 15/14/13/12 Plus/Pro/Max/Mini series. Compatible with MagSafe certified phone cases or without cases.
- **Smart Card Storage:** Dynamic tension spring securely holds one or two cards with an easy-access cutout.
- **Foldable Stand & Magnetic Wallet:** Equipped with a flexible, foldable zinc alloy stand for horizontal or vertical phone viewing while charging.
- **Fast Charging:** Supports wireless charging up to 15W and PD USB-C output/input up to 20W. Capable of charging two devices simultaneously.
- **High-Quality Design:** Robust aluminum alloy and zinc alloy construction with rounded corners and textured finish for durability and comfortable handling. Metal casing aids in heat dissipation.
- **Compact & Portable:** Weighs only 114g (4.1*2.7*0.41in), ultra-light design fits perfectly in a pocket.

SETUP

1. Charging the Power Bank

Before first use, fully charge the power bank using the provided USB-C charging cable. Connect the USB-C cable to the power bank's USB-

C port and the other end to a compatible USB power adapter (not included). The LED display will show the exact remaining battery percentage.



Image: Kuulaa Magnetic Power Bank showing its sleek design and foldable stand.

2. Attaching to iPhone (MagSafe)

Align the magnetic power bank with the MagSafe area on the back of your compatible iPhone (iPhone 15/14/13/12 series). The magnets will automatically snap the power bank into place. Ensure a secure connection for optimal wireless charging. For best results, use without a case or with a MagSafe-certified case.



Image: Illustration of the strong magnetic connection between the power bank and an iPhone, highlighting the internal magnetic coil.

3. Using the Foldable Stand

The integrated zinc alloy stand can be unfolded from the back of the power bank. Once unfolded, it allows you to prop up your iPhone in either horizontal (landscape) or vertical (portrait) orientation for hands-free viewing while charging.



Image: Demonstrates the power bank's fully adjustable stand being used to support an iPhone in both portrait and landscape orientations.

4. Using the Magnetic Wallet

The power bank features a smart card storage slot. Gently slide one or two cards into the designated slot. The dynamic tension spring will hold them securely. To remove cards, use the easy-access cutout.




Image: Illustrates the ease of storing and retrieving cards from the Kuulaa power bank's wallet feature compared to other designs.

OPERATING INSTRUCTIONS

1. Wireless Charging

Once the power bank is securely attached to your iPhone via MagSafe, wireless charging will begin automatically. The power bank supports up to 15W wireless charging. The LED display will indicate charging status.

2. Wired Charging

For wired charging, connect your device to the power bank's USB-C port using a compatible cable. The power bank supports PD 20W output for fast charging. You can charge two devices simultaneously (one wirelessly, one wired).




Image: Illustrates the two ways to charge devices using the power bank: wired via USB-C (Max 20W PD) and magnetic wireless charging (Max 15W/7.5W).

3. Checking Battery Level

The LED display on the power bank shows the precise remaining battery percentage. A green PD fast charging sign will also be visible when fast charging is active.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the power bank. Avoid using harsh chemicals or abrasive materials.
- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, fully charge the power bank at least once every three months if not in regular use. Avoid completely draining the battery frequently.
- **Handling:** Do not drop, disassemble, or attempt to repair the device yourself. This may void the warranty and cause damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Power bank not charging.	Cable or adapter issue; power bank fully discharged.	Ensure the USB-C cable and power adapter are working correctly. Allow sufficient time for charging if fully depleted.
Device not charging wirelessly.	Misalignment; non-MagSafe case; incompatible device.	Ensure the power bank is correctly aligned with the MagSafe area. Remove non-MagSafe cases or use a MagSafe-certified case. Verify device compatibility.
Weak magnetic attachment.	Non-MagSafe case; thick case.	Ensure you are using a MagSafe-compatible iPhone or a MagSafe-certified case. Avoid cases thicker than 3mm.
Cards difficult to insert/remove.	Too many cards; card type.	The wallet is designed for one or two standard-sized cards. Do not force more cards than recommended.
Power bank gets warm during use.	Normal operation; excessive load.	It is normal for the power bank to warm up during charging. If it becomes excessively hot, disconnect it and allow it to cool down. Ensure proper ventilation.

SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Model Number	KL-YD59
Battery Capacity	5000 Milliamp Hours (mAh)
Wireless Charging Output	Max. 15W
USB-C Output/Input	Max. 20W (PD)
Product Dimensions	4.17 x 2.75 x 0.4 inches (10.6 x 7 x 1 cm)
Item Weight	3.84 ounces (114g)
Battery Cell Composition	Lithium Ion
Color	Black
Special Features	Auto Shut-Off, LED Indicator Lights, Slim Design, Fast Charging, Wireless Charging, Foldable Stand, Magnetic Wallet

WARRANTY AND SUPPORT

Every Kuulaa product undergoes a series of quality control procedures to ensure reliability. While specific warranty terms are not detailed in this manual, if you have any questions regarding the compatibility or functionality of your wireless power bank, please contact Kuulaa customer support. We are committed to providing the best solution within 24 hours.

For support, please refer to the contact information provided on the product packaging or the official Kuulaa website.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question