Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

AODK B0D47CYVJG

AODK Electric Standing Desk User Manual

Model: B0D47CYVJG

Introduction

Thank you for choosing the AODK Electric Standing Desk. This manual provides essential information for the safe and efficient operation of your new desk. Designed for ergonomic comfort and enhanced productivity, this desk allows you to seamlessly switch between sitting and standing positions, reducing sedentary time and improving overall well-being. Please read this manual thoroughly before assembly and use.

Safety Information

WARNING: Always follow the assembly instructions carefully. Keep fingers and other body parts away from moving parts when adjusting the desk height. Ensure the desk is properly anchored to the floor to prevent tipping.

- Do not overload the desk. Refer to specifications for maximum weight capacity.
- Ensure all cables are properly managed and secured to prevent entanglement during height adjustments.
- Keep children and pets away from the desk during operation.
- Only use the desk on a flat, stable surface.
- Unplug the desk from the power outlet before cleaning or maintenance.

Setup and Assembly

The AODK Electric Standing Desk is designed for straightforward assembly. Please refer to the separate assembly guide included with your packaging for detailed, step-by-step instructions. Ensure all components are present before beginning assembly. It is recommended to assemble the desk with at least two people for safety and ease.
Key assembly steps typically include:

1. Unpacking all components and verifying against the parts list.
2. Attaching the desk legs to the desktop.
3. Installing the control panel and motor.
4. Securing the keyboard tray and fabric drawers.

5. Connecting the power outlets and cable management system.

For visual guidance, please refer to the detailed assembly instructions provided in the box.

Operating Instructions

Height Adjustment

Your AODK Electric Standing Desk features an intuitive control panel for height adjustment. The desk can be adjusted from 30.7 inches to 47.6 inches.

- **Up/Down Buttons:** Use the ▲ (Up) and ▼ (Down) buttons to manually adjust the desk to your desired height. The current height will be displayed on the LED screen.
- **Memory Presets (1, 2, 3):** The desk allows you to save up to three preferred heights. To save a height, adjust the desk to the desired position, then press the 'S' (Save) button followed by the number (1, 2, or 3) you wish to assign it to. To recall a saved height, simply press the corresponding number button.
- **Lock Function:** The control panel may include a lock button to prevent accidental adjustments. Refer to your specific control panel for details.



Image: Desk illustrating adjustable height range.

Built-in Power Outlets

The desk is equipped with convenient built-in power outlets to charge your devices directly on your workspace.

- It includes 3 AC outlets, 1 USB port, and 1 Type-C port.
- Simply plug your devices into the available ports. Ensure the desk is connected to a power source.




Image: Detail of the integrated power and USB outlets.

Drawers and Keyboard Tray

The desk features two cloth drawers and a pull-out keyboard tray for organized storage and an optimized workspace.

- **Keyboard Tray:** Slide the tray out to use your keyboard and mouse, freeing up desktop space. Slide it back in when not in use.
- **Cloth Drawers:** Use the two fabric drawers to store office accessories, notebooks, chargers, and other essentials, keeping your desktop clutter-free.



Image: View of the desk's storage features, including drawers and keyboard tray.

Cable Management

The desk includes a hidden under-desk tray to help you manage and organize your cables, ensuring a clean and tidy workspace.

- Route your power cords and device cables through the designated openings and into the hidden tray.
- This system prevents cables from tangling and ensures smooth height adjustments without snagging.



Image: Illustration of the cable management system.

Maintenance

- **Cleaning:** Wipe the desk surface with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Regular Checks:** Periodically check all screws and connections to ensure they are tight and secure.
- **Motor Care:** Do not attempt to disassemble the motor or control unit. If issues arise, contact customer support.

Troubleshooting

Problem	Possible Cause	Solution
Desk not moving	Power cable disconnected; Overload; Motor error.	Check power connection; Reduce weight on desk; Unplug for 30 seconds and replug.

Problem	Possible Cause	Solution
Uneven height adjustment	Obstruction; Uneven load.	Clear any obstructions; Distribute weight evenly.
Control panel unresponsive	Power issue; Control panel malfunction.	Check power; Reset desk by unplugging for 30 seconds.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact AODK customer support.

Specifications



Image: Product dimensions overview.

- **Brand:** AODK
- **Model:** B0D47CYVJG
- **Product Dimensions:** 21"D x 47"W x 31"H

- **Color:** Rustic Brown
- **Style:** Modern
- **Base Material:** Metal
- **Finish Type:** Wood
- **Special Feature:** Power Outlets & USB
- **Room Type:** Office
- **Mounting Type:** Floor Mount
- **Included Components:** Keyboard Tray, Built-in Power Outlets, Cable Management Tray
- **Number of Drawers:** 2 (Cloth)
- **Size:** 47 Inch
- **Maximum Height:** 47.6 Inches
- **Minimum Height:** 30.7 Inches
- **Is Electric:** Yes

Warranty and Support

Your AODK Electric Standing Desk comes with a**Limited Warranty**. Please refer to the warranty card included in your packaging for specific terms and conditions.
For any questions, concerns, or support needs regarding your AODK product, please contact the seller, AODK-US. They are committed to providing professional customer support and will assist you within 24 hours for issues such as damaged or missing parts.
Additionally, the product is eligible for **30-day easy returns**, ensuring your satisfaction.

© 2025 AODK. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D47CYVJG

More documents and user manuals: **https://manuals.plus/**