Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

ChooChoo ST2401-1TWL

ChooChoo 47" Farmhouse Console Table User Manual

Model: ST2401-1TWL

Product Overview

The ChooChoo 47" Farmhouse Console Table is designed to blend modern farmhouse aesthetics with practical storage solutions. Featuring a charming combination of natural brown and soft white finishes, this table includes three spacious drawers and an open slatted shelf, making it a versatile addition to various home settings such as living rooms, entryways, hallways, or behind a couch.



Figure 1: The ChooChoo 47" Farmhouse Console Table, showcasing its soft white frame, brown top, three drawers, and slatted lower shelf, positioned in an entryway.

Important Safety Information

Warning: This product is heavy and may tip over if not properly assembled or anchored. Always ensure the product is stable before use. Be cautious of pinch points when using the drawers and open shelf.

- Always place the console table on a flat, stable surface.
- Do not overload drawers or shelves to prevent tipping.
- Keep small children away from the unit during assembly and ensure all parts are securely fastened.
- Regularly check all fasteners to ensure they remain tight.

Setup and Assembly

Assembly of the ChooChoo Console Table is designed to be straightforward. It is recommended to have a Phillips head screwdriver for assembly. Please follow the steps below carefully to ensure proper construction and stability.

Before You Begin:

- Unpack all components and hardware from the box.
- Verify all parts are present against the included parts list (not provided in this manual, refer to original packaging).
- Clear a spacious, clean area for assembly to prevent loss of small parts and damage to the furniture.
- Keep children and pets away from the assembly area.

Assembly Steps:

1. **Attach Side Frames:** Connect the top and bottom crossbars to the side leg frames using the provided hardware. Ensure all connections are snug but do not overtighten initially.
2. **Install Lower Shelf:** Secure the slatted lower shelf into the designated slots on the side frames.
3. **Assemble Drawers:** Construct the three drawers by attaching the front, back, and side panels. Insert the drawer bottoms and attach the vintage handles to the drawer fronts.
4. **Insert Drawers:** Slide the assembled drawers into their respective compartments. Ensure they glide smoothly.
5. **Final Tightening:** Once all components are in place and aligned, carefully tighten all screws and fasteners to ensure the table is sturdy and stable.



Figure 2: Detailed dimensions of the console table: 11.8"D x 47.2"W x 31.5"H, illustrating its compact yet functional design.



Figure 3: Visual breakdown of the console table's features, including the spacious tabletop, three large drawers, thickened legs, open shelf, unique slats design, and retro handles.

Operating and Usage

The ChooChoo Console Table is designed for versatile use across various areas of your home, offering both decorative display space and practical storage.

Storage and Display:

- **Spacious Tabletop:** Ideal for displaying decorative items such as lamps, vases, photo frames, or other personal touches.
- **Three Drawers:** Provide concealed storage for smaller items like keys, wallets, mail, or personal accessories, helping to keep your space tidy.
- **Open Slatted Shelf:** Perfect for larger items such as storage baskets, books, magazines, or even small plants. The slatted design adds to the farmhouse aesthetic.

Placement Recommendations:

- **Entryway:** Use as a welcoming piece to hold essentials like keys and mail, and to display decor.
- **Living Room:** Place behind a sofa to provide extra surface area for drinks, remotes, or decorative accents.
- **Hallway:** Its narrow design makes it suitable for hallways, offering storage without obstructing traffic flow.
- **Dining Room/Study:** Can function as a display table for collectibles or additional storage.



Figure 4: The console table with its three drawers partially open, illustrating the internal storage space suitable for various small items.



Figure 5: The console table positioned behind a sofa, demonstrating its utility as a sofa table for decor and storage in a living room setting.

Maintenance

Proper care and maintenance will ensure the longevity and beauty of your ChooChoo Console Table.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the paint and melamine veneer.
- **Spills:** Promptly wipe up any spills to prevent staining, especially on the wood top.
- **Protection:** Use coasters under drinks and placemats under decorative items to protect the tabletop from scratches and moisture rings.
- **Stability Check:** Periodically check all screws and fasteners to ensure they are tight. Retighten as necessary to maintain the table's stability.
- **Floor Protection:** The non-slip design at the bottom of the legs helps protect your floor from scratches. Avoid dragging the table; lift it when moving.
- **Sunlight Exposure:** Avoid prolonged exposure to direct sunlight, which can cause fading or discoloration of the finish.

Troubleshooting

If you encounter any issues with your console table, refer to the following common troubleshooting tips:

Problem	Possible Cause	Solution
Table is wobbly or unstable.	Loose fasteners; uneven floor.	Ensure all screws and bolts are fully tightened. Adjust leg levelers if applicable, or place shims under legs on uneven surfaces.
Drawers do not slide smoothly or are misaligned.	Improperly installed drawer slides; obstruction in the track; drawer not fully assembled.	Remove the drawer and inspect the slides for proper alignment and any obstructions. Ensure the drawer itself is correctly assembled and square.
Surface scratches or minor damage.	Impact from objects; abrasive cleaning.	For minor scratches, a furniture repair marker or touch-up paint matching the finish may be used. Avoid abrasive materials for cleaning.
Missing or damaged parts upon arrival.	Shipping damage; packaging error.	Contact ChooChoo customer service immediately with your purchase details for replacement parts.

Specifications

Feature	Detail
Brand	ChooChoo
Model Name	ST2401-1TWL
Product Dimensions (D x W x H)	11.81"D x 47.24"W x 31.5"H
Item Weight	41.89 Pounds
Maximum Weight Recommendation	30 Kilograms
Color	Soft White and Brown
Material Type	Engineered Wood
Furniture Finish	Painted, Soft White and Brown
Number of Drawers	3
Recommended Uses	Dining (Note: Commonly used as console/entryway/sofa table)
Tools Recommended For Assembly	Screw Driver

Warranty and Support

ChooChoo is committed to providing quality products and excellent customer service. For any questions regarding your console table, including assembly assistance, missing parts, or product concerns, please contact our customer service team.
Please refer to your purchase documentation for specific warranty details. For direct support, you may visit the official ChooChoo store or contact the seller through the platform where the purchase was made.
Seller: ChooChoo Furniture
For more information, visit: ChooChoo Store on Amazon

© 2025 ChooChoo. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0D47GR3JR

More documents and user manuals: **https://manuals.plus/**