

[Manuals.plus](#) /

› [Asixxsix](#) /

› Asixxsix Portable Electric Air Duster User Manual

Asixxsix Asixxsix7qw9ipg5bo

Asixxsix Portable Electric Air Duster User Manual

Model: Asixxsix7qw9ipg5bo

1. INTRODUCTION

Thank you for choosing the Asixxsix Portable Electric Air Duster. This device is designed for efficient cleaning of various electronics and surfaces, offering powerful airflow in a compact, cordless design. Please read this manual thoroughly before use to ensure proper operation and maintenance.



Figure 1: Asixxix Portable Electric Air Duster

2. SAFETY INFORMATION

- Use only a 5V2A power adapter for charging.
- Do not charge the device for more than 12 hours to prevent battery damage from overcharging.
- Do not use the device while it is charging.
- Keep the product away from fire sources, flammable, and explosive materials.
- Avoid directing airflow directly at eyes or sensitive body parts.
- Keep out of reach of children.

3. PACKAGE CONTENTS

Verify that all items are present in the package:

- 1 x Portable Air Blower
- 1 x Nozzle
- 1 x USB Cable
- 1 x User Manual



Figure 2: Included accessories and main unit

4. PRODUCT OVERVIEW

The Asixxsix Portable Electric Air Duster features a compact design with a powerful brushless motor. It includes a magnetic nozzle for focused airflow and a side-mounted power button and speed adjustment knob.



Figure 3: Nozzle detail



Figure 4: Fan intake detail

5. SETUP

5.1 Charging the Device

1. Connect the provided USB cable to the charging port on the air duster.
2. Plug the other end of the USB cable into a 5V2A power adapter (not included).
3. Allow the device to charge fully. Do not exceed 12 hours of charging time.

5.2 Attaching the Nozzle

- Align the magnetic nozzle with the air outlet of the blower.
- The nozzle will securely attach magnetically, focusing the airflow for precise cleaning.

6. OPERATING INSTRUCTIONS

1. **Power On/Off:** Press the power button once to turn the device on or off.
2. **Adjusting Airflow:** Once powered on, manually rotate the infinite speed adjustment knob to start blowing. Continue rotating to adjust the wind speed to your desired level. The device features 3 adjustable gears for varied cleaning needs.



Figure 5: Speed adjustment feature

Applications:

- Cleaning computer keyboards, laptops, and cameras.
- Dusting car seats and blinds.
- Inflating small items like inflatable beds or lifeboats.
- Assisting with campfires or cleaning pet hair.

7. MAINTENANCE

- **Cleaning:** Wipe the exterior of the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.
- **Storage:** Store the air duster in a cool, dry place away from direct sunlight and extreme temperatures. Ensure the device is turned off before storing.
- **Battery Care:** For optimal battery life, avoid completely draining the battery frequently. Charge the device regularly, but adhere to the maximum 12-hour charging limit.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Device does not turn on.	Battery is depleted.	Charge the device using a 5V2A adapter.
Weak airflow.	Low battery or speed setting is too low.	Charge the device or adjust the speed knob to a higher setting.
Nozzle detaches easily.	Nozzle not properly aligned.	Ensure the nozzle is correctly aligned with the magnetic outlet.

9. SPECIFICATIONS

Feature	Detail
Model	Asixxsix7qw9ipg5bo
Material	ABS, Brass
Battery	2 x 2000mAh Rechargeable Lithium Batteries (Total 4000mAh)
Highest Rotation Speed	130,000 RPM
Wind Pressure	180 grams (approx. 1765 Pascal)
Peak Wind Speed	Over 52 m/s
Adjustable Speeds	3 Gears Adjustable
Dimensions (Approx.)	14.2 cm (5.59 in) length, 3.8 cm (1.5 in) width



14.2cm / 5.59in



Figure 6: Product dimensions

Ultra long battery life, up to 4H in one gear!

Built in two 21700 lithium batteries, battery capacity 7.4V-4000mAh use long lasting!




Figure 7: Battery capacity detail



130000 rpm Output Speed Per Minute

Constant Pressure 180G

Wind Speed 52 m/s

High Speed Brushless Motor

Everything can be blown

Figure 8: Performance specifications

10. WARRANTY AND SUPPORT

Asixxsix is committed to providing high-quality products and customer satisfaction. If you encounter any issues or have questions regarding your Portable Electric Air Duster, please contact our professional after-sale service. We aim to provide a satisfactory response as soon as possible.

For support, please refer to the contact information provided with your purchase or visit the official Asixxsix store page.

© 2026 Asixxsix. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question