

TOSOT 60,00BTU-50ft

TOSOT 60,000 BTU (5 Ton) Ducted Central Air Conditioner Heat Pump System

Model: 60,00BTU-50ft

Brand: TOSOT

1. INTRODUCTION

This manual provides comprehensive instructions for the installation, operation, and maintenance of your TOSOT 60,000 BTU (5 Ton) Ducted Central Air Conditioner Heat Pump System. Please read this manual thoroughly before installation and use to ensure proper function and safety. Keep this manual for future reference.

Important Safety Information

- **Professional Installation Required:** This system requires installation by a certified HVAC technician for optimal performance and safety. DIY installation is not recommended.
- **Electrical Safety:** Ensure all electrical connections comply with local codes and standards. Disconnect power before any service or maintenance.
- **Refrigerant Handling:** This system uses R-32 refrigerant. Only qualified personnel should handle refrigerant.
- **Read All Warnings:** Pay close attention to all warning labels on the unit and throughout this manual.

2. PRODUCT OVERVIEW

The TOSOT 60,000 BTU (5 Ton) Ducted Central Air Conditioner Heat Pump System is an inverter split system designed for efficient heating and cooling. It features advanced technology for reliable operation in various climates.

Included Components

- Outdoor Condenser Unit

- Indoor Air Handler Unit
- 50-foot Copper Line Set
- Installation Kit (includes sealing gum, wall cap, wall sleeve, tapes, and user manual)



Figure 2.1: Complete TOSOT Central Air Conditioner Heat Pump System with included components.

Video 2.1: Overview of the TOSOT Central Air Conditioner Heat Pump System, highlighting its main units and features.

3. KEY FEATURES

3.1. UltraCool & UltraHeat Technology

This system provides efficient heating and cooling across a wide temperature range, from -22°F to 130°F, ensuring comfort in extreme conditions.


UltraCool™ & UltraHeat™ Tech

—■— TQSDT

—●— B Brand(SEER18)

—●— G Brand(SEER18)


Cooling Capacity



Reduces Performance Decline in Extreme Temps from

130°F

Heating Capacity




-22°F

Figure 3.1: Performance capabilities of UltraCool and UltraHeat technology in varying outdoor temperatures.

3.2. Self-Developed Inverter Compressor

The system utilizes a triple-cylinder two-stage rotary compressor with enhanced vapor injection technology. This design optimizes low-temperature heating, maintaining 100% heating capacity at -5°F and 100% cooling performance at 115°F.



DC Inverter Compressor

Self-Developed Three-cylinder Two-Stage Compressor
(IFIA Best Invention Award)



Figure 3.2: Details of the DC Inverter Compressor, highlighting its efficiency and low noise operation.

Video 3.1: Demonstration of the Central AC Heat Pump with Inverter Technology, showcasing its operational benefits.

Video 3.2: Visual explanation of the Central AC Split System Heat Pump with Inverter, detailing its components and function.

3.3. Energy Efficiency

With ratings up to 18.5 SEER2 and 10.5 HSPF2, this system offers significant energy savings. Inverter technology can provide up to 30% more energy savings compared to non-inverter systems with the same SEER2 rating. It is Energy Star certified and may qualify for federal tax credits.

Superior Energy Efficiency

Heat Pump Delivers 3X Efficiency Compared to Gas Furnaces



Figure 3.3: Energy Star and other certifications for the TOSOT Heat Pump System.

3.4. Upgraded Condenser Design

The slim design of the outdoor condenser unit requires less space, making it suitable for constricted areas. Its side discharge design minimizes debris accumulation and keeps noise levels below 63 dB.



Figure 3.4: Comparison of TOSOT APEX Condenser design with traditional condensers.

3.5. High Static Pressure Design

The TOSOT unitary central AC adapts to actual static pressure, making it ideal for areas requiring long-distance airflow. It offers eight adjustable fan speeds to meet the needs of various living spaces.



Figure 3.5: Benefits of the High Static Pressure Fan for optimized airflow.

3.6. Multipositional Air Handler

The indoor air handler unit can be installed horizontally or vertically, providing flexible installation options for basements, attics, and both residential and commercial spaces.



Figure 3.6: Flexible installation configurations for the indoor air handler.

4. SPECIFICATIONS

Feature	Specification
Brand	TOSOT
Model	60,00BTU-50ft
Capacity	5 Tons (60,000 BTU)
Cooling Power	53,000 British Thermal Units
Seasonal Energy Efficiency Ratio (SEER2)	18.5
Heating Seasonal Performance Factor (HSPF2)	10.5
Noise Level	63 Decibels (Outdoor Condenser)

Feature	Specification
Operating Temperature Range	-22°F to 130°F
Compressor Type	Inverter, Triple-Cylinder Two-Stage Rotary
Refrigerant	R-32
Voltage	230 Volts
Wattage	16,120 watts
Outdoor Condenser Dimensions (D x W x H)	13.4" x 35.4" x 49.6"
Indoor Air Handler Dimensions (D x W x H)	21.3" x 24.8" x 52.0"
Item Weight	241 pounds
Floor Area Coverage	Up to 3000 Square Feet
Line Set Length	50 feet (Copper)
Certifications	Energy Star, ETL, AHRI Certified

5. SETUP AND INSTALLATION

The TOSOT Central Air Conditioner Heat Pump System is a complex appliance that requires professional installation. Attempting to install this unit without proper certification and tools can lead to serious injury, property damage, and void the product warranty.

5.1. Pre-Installation Considerations

- **Location:** Choose appropriate locations for both the outdoor condenser and indoor air handler, considering airflow, noise, and accessibility for maintenance. The multipositional air handler allows for vertical or horizontal installation.
- **Electrical Requirements:** Ensure the electrical supply meets the 230V requirement and is properly grounded.
- **Ductwork:** Verify existing ductwork is compatible and in good condition for efficient air distribution. The high static pressure design is suitable for long-distance airflow.
- **Thermostat:** This system is compatible with universal 24V thermostats (not included).



Figure 5.1: Universal 24V thermostat compatibility.

5.2. Professional Installation Steps (Summary)

1. Mount the indoor air handler in the chosen vertical or horizontal position.
2. Position the outdoor condenser unit, ensuring adequate clearance for airflow.
3. Connect the 50-foot copper line set between the indoor and outdoor units.
4. Perform all necessary electrical wiring connections.
5. Connect the thermostat wiring.
6. Evacuate the refrigerant lines and charge the system with R-32 refrigerant.
7. Test the system for proper operation, including airflow and temperature control.



Figure 5.2: Professional installation is crucial for system integrity and safety.

6. OPERATING INSTRUCTIONS

Once professionally installed, your TOSOT Heat Pump System is controlled via a compatible 24V thermostat. Refer to your thermostat's user manual for specific programming and operation details.

6.1. Basic Operation

- **Power On/Off:** Use your thermostat to turn the system on or off.
- **Mode Selection:** Select desired operating mode (Cool, Heat, Fan, Auto) on your thermostat.
- **Temperature Setting:** Adjust the desired temperature using the thermostat controls.

6.2. Fan Speed Adjustment

The system features eight adjustable fan speeds. Your installer can configure these settings to optimize airflow and comfort for your specific ductwork and living space. Consult your installer or thermostat manual for how to adjust fan speeds if accessible to the user.

7. MAINTENANCE

Regular maintenance is essential to ensure the longevity and efficient operation of your TOSOT Heat Pump System. It is recommended to schedule annual professional maintenance.

7.1. Filter Replacement

Regularly check and replace the air filter in your indoor air handler. A dirty filter restricts airflow and reduces efficiency. The recommended filter size is 20x23 inches, though some documentation may

incorrectly state 20x20 inches. Verify the actual size of your installed filter.

7.2. Outdoor Condenser Cleaning

Keep the area around the outdoor condenser unit clear of debris, leaves, and vegetation to ensure proper airflow. The side discharge design helps minimize accumulation, but periodic inspection is still advised.

7.3. Professional Servicing

Schedule annual maintenance with a certified HVAC technician. This includes checking refrigerant levels, inspecting electrical components, cleaning coils, and verifying overall system performance.

8. TROUBLESHOOTING

If you experience issues with your system, perform the following basic checks before contacting a service technician:

- **No Power:** Check the circuit breaker for the unit. Ensure the thermostat is set to the desired mode and temperature.
- **Insufficient Cooling/Heating:** Verify the thermostat settings. Check if the air filter is clean. Ensure outdoor unit is free of obstructions.
- **Unusual Noises:** Minor operational noises are normal. If you hear loud or unusual sounds, contact a technician.
- **Water Leaks:** Check the condensate drain line for blockages.

For any persistent issues or complex problems, contact a certified HVAC technician for diagnosis and repair.

9. WARRANTY AND SUPPORT

9.1. Warranty Information

The TOSOT 60,000 BTU Ducted Central Air Conditioner Heat Pump System comes with **afive-year warranty**. Please retain your proof of purchase and installation records for warranty claims. The warranty covers defects in materials and workmanship under normal use and service.

For specific terms and conditions of the warranty, refer to the warranty card included with your product or contact TOSOT customer support.

9.2. Customer Support

For technical assistance, troubleshooting, or warranty inquiries, please contact TOSOT customer support:

- **Website:** [Insert TOSOT Support Website Here]
- **Phone:** [Insert TOSOT Support Phone Number Here]
- **Email:** [Insert TOSOT Support Email Here]

When contacting support, please have your model number (60,00BTU-50ft) and date of purchase readily available.

Related Documents - 60,00BTU-50ft

	TOSOT Split Type Air Conditioner Specifications and Dimensions Detailed technical specifications, performance data, and physical dimensions for TOSOT split-type air conditioning models TM18HMO, TM24HMO, TM30HMO, TM36HMO, and TM42HMO.
	TOSOT RV Air Conditioner Installation Guide Step-by-step instructions for installing a TOSOT RV Air Conditioner, covering sealing, unit mounting, duct plate installation, ceiling frame, wiring, and grille assembly.
	TOSOT 8,000 BTU Window Air Conditioner User Manual Installation, Operation & Troubleshooting Comprehensive user manual for the TOSOT 8,000 BTU Window Air Conditioner (Model GJC08BU-A6NRNJ2A). Covers installation, operation, remote control, cleaning, maintenance, troubleshooting, and safety instructions.
	TOSOT Clivia Deluxe TH-SCD Air Conditioner User Manual Comprehensive user manual for the TOSOT Clivia Deluxe TH-SCD series air conditioners, covering features, operation, specifications, maintenance, and safety. Includes R32 refrigerant information and WiFi connectivity details.
	TOSOT Split-Type Floor-Standing Air Conditioner User Manual Comprehensive user manual for the TOSOT Split-Type Floor-Standing Air Conditioner, covering installation, operation, maintenance, safety precautions, and troubleshooting. Includes model SU-COSMO36FS/I.



[\[pdf\]](#) Instructions Catalog

Tosot 2018 indd catalog tosot Index of my templates instructions light climagroup ua |||

20 Gree Electric Appliances . -- , , -- . Gree Electri ... PI Free Match Premium S
SMPS SMPS 1 TOSOT c SMPS 3 . 0,5 85 265 180 **260** 85 - 265 TOSOT c SMPS 180
- **260** , 29 28 27 26 25 , , 23 22 21 19 , 0 2 ...

lang:it **score:34** filesize: 20.32 M page_count: 40 document date: 2019-06-05




[\[pdf\]](#) Instructions Catalog

catalog tosot 2020 Index of my templates instructions climagroup ua |||

20 , Gree Electric Appliances , . -- , , , . Gree Electri ... PI - Free Match Premium S
SMPS SMPS 1 TOSOT c SMPS 3 . 0,5 85 265 180 **260** 85 - 265 TOSOT c SMPS 180
- **260** , 29 28 27 26 25 , , 23 22 21 19 , 0 2 ...

lang:it **score:33** filesize: 22.37 M page_count: 48 document date: 2021-03-18



[TOSOT KJ350G Air Purifier User Manual](#)

User manual for the TOSOT KJ350G Air Purifier, covering safety instructions, installation, operation, cleaning, maintenance, troubleshooting, and warranty information.

lang:en **score:31** filesize: 2 M page_count: 16 document date: 2023-02-20




[\[pdf\]](#) Instructions

Безымянный 2 Настенные сплит системы U Might 69124 с о k ru library instructions toso kondicionery bytovye 20869 |||

- U-Might , TOSOT. , 5 / .// / / 2 2 C C T09H-SUEu/I / T09H-SUEu/O 2600 3904000 3000 5604800 4,33 /3,75 1/220240/50 600 951500 800 1001630 2,7 3,5 T09H-SUEu/...


lang:i-klngon score:30 filesize: 3.84 M page_count: 32 document date: 2020-11-07



[\[pdf\]](#) User Manual Instructions Troubleshooting Guide Parts List Specifications Warranty Catalog

350A User Manual images thdstatic instructions before use and save this user manual for future reference A digital version can be obtained from Customer Support Only your air purifier in an upright position Make sure the angle of inclination 0b28b182-cec3-43c5-a20e-2daabc77133b catalog Images 0b User Manual Air Purifier Before using your TOSOT Portable Air Conditioner please read this user manu ... ng on a damaged cord or electrical plugin. Electrical Safety Warning Always plug into a fixed 120V 60 Hz AC outlet. Your air purifier should be plugged directly into a power outlet. Power outlets sh...

lang:en score:30 filesize: 2.01 M page_count: 16 document date: 2020-03-30




[\[pdf\]](#) User Manual Quick Start Guide Instructions Guide Warranty

TOSOT 4L Humidifiers User Manual Tosot SCWA 4006 Ultrasonic Humidifier Manuals Clip manualsclip 2023 02 |||

User Manual Ultrasonic Humidifier READ AND SAVE THESE INSTRUCTIONS MODEL NUMBER SCWA-4006 Welcome ... put SCWA-4006 24 V DC 20W 1.06Gal / 4.0 L 4.5L/24h 38dB A 7.5 in x 7.5 in x 12.7 in 100-240V-, 50/60Hz, 1.0 A 24V 1.5A Notes: Humidifying volume will change according to the changes in indoor tempe...

lang:en score:29 filesize: 230.89 K page_count: 16 document date: 2023-02-20



[pdf] Instructions

Безымянный 2 Кондиционер воздуха 48389 с o k ru library instructions tosos kondicionery bytovye 14476 |||

TOSOT AIRCONDITONERS 72627 , . , . , . , . . . ; 8 , 1 . 700 200 644 30 30 120 120 570 006 220 170 160 220 1. 55 , ...

lang:i-klngon score:29 filesize: 4.07 M page_count: 30 document date: 2020-11-06



[pdf]

OUT FM4 indd yatsuk Инструкция на Tosot T21H O entero ru 80 manuals 55132

UHH0DWFK 7OSO73 6,43 8,47 9,67 11,27 15,42 16,43 5,24 6,88 7,68 10,12 11,05 15,20 16,22 3/ 2600 3200 3200 4000 4000 5200 5500 55 56 56 58 58 57 54 899596378 955700396...

lang:i-klngon score:27 filesize: 3.63 M page_count: 32 document date: 2015-01-28




[pdf] User Manual

Инструкция по эксплуатации TOSOT GV 09W2S 12W2S 18W2S 24W2S tosos kiev ua Инструкции lyra two stage manual rus proficlimat upload manuals |||

RU - LYRA TWO STAGE : GV-09W2S GV-12W2S GV-18W2S GV-24W2S , R32. . . . 30 50 2 1. . , . . . , . 2. . 3. . , , , 60 .. QC: 150 55 150 55 QD: 150 55 ...

lang:i-klngon score:27 filesize: 6.42 M page_count: 32 document date: 2023-02-21




[\[pdf\]](#) User Manual Owner's Manual Instructions Troubleshooting Guide Parts List Specifications Warranty

TOSOT KJ350G Air Purifier User Manual Owner Tosot Personal with True HEPA Filter for 310 Cubic Feet
tsto1025 TST AP 350A
Tosot 350Aowner manualsecure img1 ag wfdcn dm document 80a2f372 ca5b 460c aca9 7dd9cdc9c69a owner manual |||

User Manual Air Purifier Before using your TOSOT Air Purifier please read this user manual in its en ... ng on a damaged cord or electrical plugin. Electrical Safety Warning Always plug into a fixed 120V **60** Hz AC outlet. Your air purifier should be plugged directly into a power outlet. Power outlets sh...

lang:en **score:27** filesize: 8.26 M page_count: 16 document date: 2020-09-29



[\[pdf\]](#) User Manual Owner's Manual Installation Guide Instructions Guide

Tosot by GREE Inverter Vloer Plafond airco FTS 18R R32 5 kW set Mr Airco81001468 Manualmr
cdn shop files 81001468 Manual v 9668142411956098593 HandbuchTOSOT 0kW Boden Decke Set
KlimasaleTosot Aircomaxicool nl static pictures original other ||| ||| Owner s Manual Original Instructions
Air Conditioners DC Inverter U-match Series Floor Ceiling Type Unit Models: Indoor Unit Outdoor Unit
FTS-12R2 UTS-12R2 FTS-18R2 UTS-18R2 FTS-24R2 UTS-24R2 To Users Thank you for selecting
TOSOT product.

Owner s Manual Original Instructions Air Conditioners DC Inverter U-match Series Floor Ceiling Type ... G UTS-12R2 732 330 553 455 310 675 285 UTS-18R2 802 350 555 512 331 745 300 UTS-24R2 958 402 **660** 570 371 889 340 10 DC Inverter U-match Series Floor Ceiling Type Unit 2.1.4 Diagram of Unit In...

lang:en **score:27** filesize: 2 M page_count: 68 document date: 2024-10-04



[\[pdf\]](#)

OM G TECH 2020 191224 indd yatsuk Кондиционер воздуха настенного типа серия TECH○ Прибор
заполнен горючим газом R32 При ремон те строго следуйте Интернет сайт TM TOSOT в
Российской Федерации и Республике Беларусь tosot rutosot t09h sgt i o 1768490cdn vseinstrumenti ru
instruction nomenclaturecontent 202107 7284165 1768490 |||

G-TECH R32 5 - . // / 2 2
1/220/50 **600** 1401400 875 1401400 715 1801650 952 1801650 2,8 4 3,3 4,3 6,4 6,8
200/360/470/...

lang:it **score:26** filesize: 2.63 M page_count: 36 document date: 2021-02-08



[pdf]

Инструкция на Tosot T56H FMS O2 entero ru 80 manuals 55158


- Free Match Super , TOSOT. ,3 5 70 30 15 4,95 30

GREE 34 31,5 21,5 41,5 32 18... 48 10... 24 T48H-FMS/O 28 14 000 15 500

2,86/3,60 1/220/50 4900 4300 21 22,5 6400 57 9001350375 9831398443 116/125

5/8 15,8 3/8 9,5 145 70 30 1...

lang:i-klngon score:26 filesize: 7.37 M page_count: 44 document date: 2014-06-16



[pdf] User Manual Owner's Manual


Tosot Lyra Two Stage GV 18W2S Инструкция Кондиционер сплит система vencon ua tosot lyra two

stage gv 18w2s manual goods 218354 |||

Tosot Lyra Two Stage GV-18W2S RU OWNER S MANUAL -. LYRA : GF-09W GF-

12W GF-18W GF-24W , ... 30 50 22 1. . , . . 2. . 3. , , , 60 . . 09 - 12K Wall Mark in the middle of it Space to the wall above 150mm Left 5...

lang:i-klngon score:26 filesize: 6.42 M page_count: 40 document date: 2023-11-30



[pdf] User Manual Owner's Manual


Tosot Lyra Two Stage GV 09W2S Инструкция Кондиционер сплит система vencon ua tosot lyra two

stage gv 09w2s manual goods 218352 |||

Tosot Lyra Two Stage GV-09W2S RU OWNER S MANUAL -. LYRA : GF-09W GF-

12W GF-18W GF-24W , ... 30 50 22 1. . , . . 2. . 3. , , , 60 . . 09 - 12K Wall Mark in the middle of it Space to the wall above 150mm Left 5...

lang:i-klngon score:26 filesize: 6.42 M page_count: 40 document date: 2023-11-30



[TOSOT Каталог 2022: Системы кондиционирования воздуха](#)

Полный каталог TOSOT 2022 от Gree Electric Appliances Inc. of Zhuhai,

представляющий широкий ассортимент бытовых и полупромышленных систем

кондиционирования воздуха, включая инверторные сплит-системы,

мультисплит-системы и аксессуары.

lang:i-klngon score:25 filesize: 41.06 M page_count: 68 document date: 2022-04-06



[\[pdf\]](#) User Manual

MANUAL Керівництво з експлуатації та монтажу TOSOT GL 09ZS2 12ZS2 18ZS2 24ZS2 tosot kiev ua
 Инструкции hansol inverter manual ukr rus eng proficlimat upload manuals |||

UK HANSOL INVERTER : GL-09ZS2 GL-12ZS2 GL-18ZS2 GL-24ZS2 / 2637 15
 12000 / 7032 20 18000 / 527 25 24000 / 7032 25 28000 / 8204 30 36000 / 10548 30
 42000 / 12306 30 48000 / 14064 30 4. . 10 5...

lang:sw **score:25** filesize: 40.97 M page_count: 111 document date: 2023-02-21



[\[pdf\]](#)

TOSOT 2016 каталог grag Каталог оборудования Tosotбеспроводные пульты управления YB1FA

Этот же пульт как опция доступен для канальными блоками Для канальным кондиционером
 пультом оборудования Tosotentero ru manuals 55130 Tosot srsltid AfmBOooBIPhBT

dtcl9ZvgdYWEksaEfcLdSdiNFE50 ZlpXD 4eqlw4G |||

500 , 300 000 000 , . , . , -- , . , . , ... REE MATCH SUPER 34 42 43 - 44 45 46 EXV- 48
 49 TOSOT - 54 - 60 - 62 - 64 - 66 - - 68 TOSOT MULTI VARIABLE 70 80 84 90 ...

lang:es **score:25** filesize: 27.76 M page_count: 116 document date: 2016-03-11



[Руководство пользователя TOSOT T07H-SnN2 / T09H-SnN2 / T12H-SnN2 / T18H-SnN2 / T24H-SnN2 / T28H-SnN2 Кондиционер воздуха](#)

Подробное руководство пользователя для кондиционеров TOSOT серии SnN2, включая инструкции по установке, эксплуатации, обслуживанию и устранению неполадок. Информация о технических характеристиках, функциях пульта дистанционного управления и схемах подключения.

lang:i-klingon **score:25** filesize: 14.09 M page_count: 34 document date: 2021-11-18



[\[pdf\]](#)

Lord outdoor indd abakumov ke Инструкция на внешний блок Tosot T09H SLEu I O entero ru 80 manuals 54698

LORD EURO - , TOSOT. , 0,45-3,23 2,8 0,45-4,10 3,23/3,71 1/220/50 0,8 0,2-1,4 0,75 0,2-1,2 6,3 6,9 T09H-SLEu/I 330-560 26-39 0,8 790275200 863268352 9,0/11,0 T09H-SLEu/O 52 776540320 848360580 28/31 GREE 3/8 9,52 ...


lang:i-klngon **score:25** filesize: 1.86 M page_count: 12 document date: 2015-12-16



[TOSOT LORD EURO Внутренний блок настенного типа - Руководство пользователя](#)

Полное руководство пользователя для кондиционера TOSOT LORD EURO, включая установку, эксплуатацию, обслуживание, устранение неисправностей и коды ошибок. Информация о спецификациях, функциях пульта дистанционного управления и мерах безопасности.

lang:i-klngon **score:25** filesize: 1.88 M page_count: 24 document date: 2015-12-11




[TOSOT Evaporative Air Cooler User Manual KSWA-04S63Dg](#)

User manual for the TOSOT Evaporative Air Cooler, model KSWA-04S63Dg.

Provides comprehensive instructions on safety, installation, features like ice pack and aromatherapy, operation, maintenance, troubleshooting, and warranty information.

lang:en **score:24** filesize: 1.72 M page_count: 18 document date: 2023-06-07



[TOSOT RV Air Conditioner User Manual](#)

Comprehensive user manual for the TOSOT RV Air Conditioner, detailing installation, operation, safety precautions, maintenance, troubleshooting, and warranty information for models GRH15DC-A6NNA1A/I and GRH15DC-A6NNA1A/O.

lang:en score:24 filesize: 8.39 M page_count: 34 document date: 2023-11-17



[\[pdf\] User Manual Quick Start Guide Instructions Guide Warranty Catalog](#)

08 26 TST HMD 4L User Manual images na ssl amazon The Ultrasonic Cool Mist Humidifier is designed to quietly provide visible cool moisture Water released from the water tank into transducer nebulizer where it turned a fine mist through action of ultrasonic sound waves B1RZPtWOLS I Read and save these instructions This symbol throughout manual points out potentially hazardous situation that if not 160c8f7c c921 4e73 bc9f 84177ce3eba6 homedepot static catalog Images 16 READ AND SAVE THESE INSTRUCTIONS Please read all before use this user for future Missing We re extremely happy welcome you as new member our family! To thank we giving warranty extension Are interested All need 2630159 secure img1 ag wfcnd docresources 48845 263 fg

User Manual Ultrasonic Humidifier READ AND SAVE THESE INSTRUCTIONS
MODEL NUMBER SCWA-4006 Welcome ... put SCWA-4006 24 V DC 20W 1.06Gal / 4.0 L 4.5L/24h 38dB A 7.5 in x 7.5 in x 12.7 in 100-240V-, 50/60Hz, 1.0 A 24V 1.5A
Notes: Humidifying volume will change according to the changes in indoor tempe...

lang:en score:24 filesize: 2.14 M page_count: 16 document date: 2019-08-26



[\[pdf\]](#)

Каталог оборудования Tosotна новый экологичный хладагент R32 Представлена улучшенная версия модели Natal 2021 Корпорация Gree Electric Appliances взяла уверенный курс на полныйоборудования Tosotentero ru manuals 262699 Tosot srsltid AfmBOorbhKQYx19Mm 1ZPPDY20F9fdxelyzzjO PTz0GC6RIGaTpYsID |||
Gree Electric Appliances Inc. of Zhuhai ... 15.08.11. 2 2 9 57 200 570 5 000 8 000 14 000 70 000 5 500 000 60 000 000 300 000 000 ...

lang:i-klnglon score:24 filesize: 43.08 M page_count: 67 document date: 2022-04-15




[\[pdf\]](#)

yatsuk Инструкция на Tosot T60H LF I LU O2 entero ru 80 manuals 55348

70S07 , . - O T18H-LU/O; T24H-LU/O T30H-LU/O; T36H-LU/O 1 / 220 / 50
T36H-LU/O2 T42H-LU/O2 T48H-LU/O2 **T60H-LU/O2** 3 / 380 / 50 3.1 - T12H-LC/I
T18H-LC/I T24H-LC/I T30H-LC/I T36H-LC/I T42H-LC...

lang:i-klngon **score:24** filesize: 705.57 K page_count: 32 document date: 2014-04-03



[\[pdf\]](#) User Manual Quick Start Guide Instructions Guide Warranty

cdn shopify s files 1 2651 6306 No information is available for this page TOSOT 4L Humidifiers User Manual v 1593671921 |||

User Manual Ultrasonic Humidifier READ AND SAVE THESE INSTRUCTIONS
MODEL NUMBER SCWA-4006 Welcome ... put SCWA-4006 24 V DC 20W 1.06Gal /
4.0 L 4.5L/24h 38dB A 7.5 in x 7.5 in x 12.7 in 100-240V-, 50/60Hz, 1.0 A 24V 1.5A
Notes: Humidifying volume will change according to the changes in indoor tempe...

lang:en **score:24** filesize: 2.21 M page_count: 16 document date: 2020-06-30



[\[pdf\]](#) User Manual

User Manual Cloudfront netBefore installing and using your TOSOT Air Conditioner please read this user manual in its entirety foreign matter the refrigerant circuit canB1z4Jbs2I1Lm media amazon images I B1z4Jbs2I1L |||

User Manual SPLIT AIR CONDITIONER Before installing and using your TOSOT Air Conditioner, please rea ... Tightening Torque ft-lbs N-m 10 to 13 15 to 20 25 to 30 30 to 40 36 to 45 45 to 55 50 to **60 60** to 65 Connect the drain hose to the outlet pipe of the indoor unit and secure the joint wit...

lang:en **score:24** filesize: 2.25 M page_count: 49 document date: 2021-04-25




[pdf]

нов Duct indd yatsuk Инструкция на Tosot T21H FD I Внутренний блок мультисплит системы купить
Россия resprofi ru upload manuals |||

UHH0DWFK 7OSO7 , . - . , , , 18 . 6. 6,35 9,52 12 15,9 15--30 35--40 45--50
60--65 , . 1 ; , . 2 , ...

lang:i-klngon score:24 filesize: 1.18 M page_count: 40 document date: 2014-02-03




[pdf] User Manual

User Manual SPLIT AIR CONDITIONER Before installing and using your TOSOT Air Conditioner please
read this user manual in its entirety MODEL NUMBERS Mini Spilt AC 221116 manualsclip 2023 02 |||

User Manual SPLIT AIR CONDITIONER Before installing and using your TOSOT Air
Conditioner, please rea ... Tightening Torque ft-lbs N-m 10 to 13 15 to 20 25 to 30 30
to 40 36 to 45 45 to 55 50 to 60 60 to 65 Connect the drain hose to the outlet pipe of
the indoor unit and secure the joint wit...


lang:en score:24 filesize: 2.02 M page_count: 49 document date: 2023-02-20



[\[pdf\]](#) User Manual Owner's Manual Quick Start Guide Instructions Guide Warranty
 08 26 TST HMD 4L Owner Manual Tosot 1 06 Gallons Cool Mist Ultrasonic Tabletop Humidifier with
 Adjustable Humidistat for 1000 Cubic Feet tsto1019 4LTosot 4Lowner manualesecure img1 ag wfcndn dm
 document d38badea d3fe 47b4 b37e e8e8c905acbd owner manual 4LTOSOT SCWA 4006 User
 Manualesecure manualmanual internal 2022 09 TOSOT |||
 User Manual Ultrasonic Humidifier READ AND SAVE THESE INSTRUCTIONS
 MODEL NUMBER SCWA-4006 Welcome ... put SCWA-4006 24 V DC 20W 1.06Gal /
 4.0 L 4.5L/24h 38dB A 7.5 in x 7.5 in x 12.7 in 100-240V-, 50/60Hz, 1.0 A 24V 1.5A
 Notes: Humidifying volume will change according to the changes in indoor tempe...
 lang:en **score:23** filesize: 2.14 M page_count: 16 document date: 2019-08-26



[Каталог систем кондиционирования TOSOT: Бытовые и Бизнес Решения](#)
 Полный каталог продукции TOSOT от Gree Electric Appliances. Ознакомьтесь с
 бытовыми и полупромышленными кондиционерами, мультизональными
 системами, аксессуарами и техническими характеристиками.
 lang:i-klngon **score:23** filesize: 18.29 M page_count: 92 document date: 2014-07-29



[\[pdf\]](#) User Manual Owner's Manual
 Owners Manual Tosot Multi Zone System AC Outlet Thank you for selecting air conditioner Before use
 please read this manual carefully and keep it properly furthur reference theacoutlet documents
 TM12HKDI TM18HKDI 36 000 Btu 21 Seer 3 Ductless Mini Split Heat Pump 12K TM36H4O
 TW12HQ2C2DI |||
 TM12HKDI TM18HKDI User Notice When operating, the entire capacity of the
 cooperating indoor unit ... surface 20 H Wall surface 1500 Wall surface 1500 2500
 unit:mm Model H TM12HKDI TM18HKDI **260** Ground surface Fig.1 2.2 Select install
 location of the indoor unit 1 . Obstruct should put awa...
 lang:en **score:23** filesize: 12.58 M page_count: 144 document date: 2019-04-23



[\[pdf\]](#) User Manual Catalog

User Manual Before installing and using your TOSOT Air Conditioner please read this user manual in its entirety MODEL NUMBERS Indoor Unit Outdoor GWH09AFC A3DNA2A 3df09201 cbd2 4667 9f57 11795012ac49 images thdstatic catalog Images 3d |||

User Manual SPLIT AIR CONDITIONER Before installing and using your TOSOT Air Conditioner, please rea ... Tightening Torque ft-lbs N-m 10 to 13 15 to 20 25 to 30 30 to 40 36 to 45 45 to 55 50 to 60 60 to 65 Connect the drain hose to the outlet pipe of the indoor unit and secure the joint wit...

lang:en score:23 filesize: 2.25 M page_count: 49 document date: 2021-04-25



[\[pdf\]](#)

freeMatch кассета indd yatsuk Инструкция на Tosot T18H FC I4 Внутренний блок мультисплит системы купить Россия resprofi.ru upload manuals |||


UHH0DWFK 7OSO7 , . - . , , . . . 5000 5500 1/220/50 T24H-FC/I 7100 8000 1/220/50 680 33/37 840840190 963x963x273 25/33 04 950x950x60 1043x1028x130 6,5/10 3/8 9,5 1/4 6,35 41,5 500 30 680 33/37 840840190 963x963x273 25/33 04... lang:i-klngon score:23 filesize: 1.25 M page_count: 40 document date: 2014-01-17



[TOSOT Split Air Conditioner User Manual](#)

Comprehensive user manual for TOSOT Split Air Conditioners, covering installation, operation, maintenance, and troubleshooting. Includes safety precautions and parts list.

lang:en score:23 filesize: 7.54 M page_count: 52 document date: 2023-09-27



[pdf] User Manual

mini split user manualassets wfcndm document 43304bbc 6507 4a4a 9be2 c3392e83b0c1 manual Mini User Manual Tosot 9000 BTU Wi Fi Connected Ductless Split Air Conditioner for with Heater and Remote Included tsto1046 TST SU MUSE 09K110 WFMMini 12000 tsto1060 12K110 TOSOT 12 000 Compatible Alexa tsto1043 18 tsto1047 18K230 9 tsto1044 09K230 WFTosot WFmini manualmini manualsecure img1 ag ||| ||| User Manual SPLIT AIR CONDITIONER Before installing and using your TOSOT Air Conditioner, please read this user manual in its entirety. MODEL NUMBERS Indoor Unit GWH09AFCXB-A3DNA2B/I GWH09AFCXB-D3DNA2B/I GWH12AFCXB-A3DNA2C/I GWH12AFCXB-D3DNA2C/I Outdoor Unit GWH09GCXB-A3DNA2B/I GWH09GCXB-D3DNA2B/I GWH12GCXB-A3DNA2C/I GWH12GCXB-D3DNA2C/I User Manual SPLIT AIR CONDITIONER Before installing and using your TOSOT Air Conditioner, please rea ... Tightening Torque ft-lbs N-m 10 to 13 15 to 20 25 to 30 30 to 40 36 to 45 45 to 55 50 to 60 60 to 65 Connect the drain hose to the outlet pipe of the indoor unit and secure the joint wit...

lang:en score:22 filesize: 7.55 M page_count: 52 document date: 2023-08-03



[pdf] User Manual


Untitled Manual Tosot by GREE Versati IV Monobloc warmtepomp 230v R32 6 kW 81001754 Econox be econox static pictures original other ||| M O N O B L O C T Y P E Gebruikershandleiding Lucht/water-warmtepomp TH-V06EM1 Tosot - GRS-CQ6.0Pd/N ... 43 2.99 3.45 1.62 2.06 2.49 3.09 3.57 COP, W/W 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 4.60 4.40 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 4.60 4.40 Model GRS-CQ4.0Pd/NhG3-E TH-V06... lang:nl score:22 filesize: 3.86 M page_count: 81 document date: 2024-10-04



[pdf] User Manual

TADIRAN TOSOT 10A 15 21 28 כאשר המזגן פועל לחץ על מפסק ההפעלה הראשי של המפסקיכיוי הידני Manual switch is lost witch d fan at the ency operation eration Manual switch 62480f34a110b340c771960473057fe9 1492193550 d3m9l0v76dty0 cloudfront net system photos 170549 original TADIRAN TOSOT 10A, 15, 21, 28 . 4 5. ... 11 , . 150 . .2 . .3 60 . 55 . 1 . ; .2 . , .1 ...

lang:en score:22 filesize: 2.66 M page_count: 28 document date: 2016-03-14



[TOSOT Каталог 2022: Системы кондиционирования воздуха](#)

Ознакомьтесь с полным каталогом систем кондиционирования воздуха TOSOT 2022 от Gree Electric Appliances Inc. of Zhuhai. Включает модели для дома и бизнеса, с подробными характеристиками и технологиями.

lang:i-klngon **score:22** filesize: 41.06 M page_count: 68 document date: 2022-04-06



[\[pdf\] User Manual](#)

Untitled Manual NL2 Tosot by GREE Versati IV Monobloc warmtepomp 230v R32 8 kW 81001755 Econox be econox static pictures original other |||

M O N O B L O C T Y P E Gebruikershandleiding Lucht/water-warmtepomp TH-V06EM1 Tosot - GRS-CQ6.0Pd/N ... 43 2.99 3.45 1.62 2.06 2.49 3.09 3.57 COP, W/W 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 **4.60** 4.40 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 **4.60** 4.40 Model GRS-CQ4.0Pd/NhG3-E TH-V06...

lang:nl **score:22** filesize: 3.86 M page_count: 81 document date: 2024-10-04



[\[pdf\] User Manual](#)

Untitled Manual NL Tosot by GREE Versati IV Monobloc warmtepomp 400v R32 12 kW 81001757 Econox be econox static pictures original other |||

M O N O B L O C T Y P E Gebruikershandleiding Lucht/water-warmtepomp TH-V06EM1 Tosot - GRS-CQ6.0Pd/N ... 43 2.99 3.45 1.62 2.06 2.49 3.09 3.57 COP, W/W 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 **4.60** 4.40 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 **4.60** 4.40 Model GRS-CQ4.0Pd/NhG3-E TH-V06...

lang:nl **score:22** filesize: 3.86 M page_count: 81 document date: 2024-10-04



[\[pdf\]](#) User Manual

Untitled Manual NL2 Tosot by GREE Versati IV Monobloc warmtepomp 400v R32 10 kW 81001756

Econox be econox static pictures original other |||

M O N O B L O C T Y P E Gebruikershandleiding Lucht/water-warmtepomp TH-V06EM1 Tosot - GRS-CQ6.0Pd/N ... 43 2.99 3.45 1.62 2.06 2.49 3.09 3.57 COP, W/W 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 4.60 4.40 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 4.60 4.40 Model GRS-CQ4.0Pd/NhG3-E TH-V06...

lang:nl score:22 filesize: 3.86 M page_count: 81 document date: 2024-10-04



[\[pdf\]](#) User Manual

Untitled Manual NL Tosot by GREE Versati IV Monobloc warmtepomp 400v R32 14 kW 81001758

Econox be econox static pictures original other |||

M O N O B L O C T Y P E Gebruikershandleiding Lucht/water-warmtepomp TH-V06EM1 Tosot - GRS-CQ6.0Pd/N ... 43 2.99 3.45 1.62 2.06 2.49 3.09 3.57 COP, W/W 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 4.60 4.40 5.40 5.40 5.32 5.05 4.93 4.75 4.55 5.06 4.95 4.81 4.60 4.40 Model GRS-CQ4.0Pd/NhG3-E TH-V06...

lang:nl score:22 filesize: 3.86 M page_count: 81 document date: 2024-10-04



[TOSOT TWIST Inverter Air Conditioner User Manual and Specifications](#)


Comprehensive guide for TOSOT TWIST Inverter air conditioners, detailing model specifications, remote control operation (YAA1FB, Y1F), installation, maintenance, and troubleshooting. Features include Turbo, Sleep, I FEEL modes, and energy efficiency information.

lang:i-klngon score:22 filesize: 8.64 M page_count: 28 document date: 2014-12-23




[TOSOT Split Air Conditioner User Manual and Installation Guide](#)

Comprehensive user manual and installation guide for TOSOT split air conditioners, covering safety, operation, maintenance, troubleshooting, and model information.
lang:en score:22 filesize: 2.57 M page_count: 49 document date: 2022-11-16



[TOSOT Central Heat Pump System User Manual](#)

Comprehensive user manual for TOSOT Central Heat Pump Systems (Models HP-A36/I, HP-A60/I, HP-A36/O, HP-A60/O), covering installation, operation, maintenance, troubleshooting, and warranty information.
lang:en score:22 filesize: 5.19 M page_count: 41 document date: 2024-04-30



[\[pdf\] User Manual Owner's Manual Installation Guide Instructions Guide](#)

Manual Tosot by GREE Inverter Vloer Plafond airco FTS 18R R32 5 0 kW set 81001468 Econox be econox static pictures original other |||
Owner s Manual Original Instructions Air Conditioners DC Inverter U-match Series Floor Ceiling Type ... G UTS-12R2 732 330 553 455 310 675 285 UTS-18R2 802 350 555 512 331 745 300 UTS-24R2 958 402 660 570 371 889 340 10 DC Inverter U-match Series Floor Ceiling Type Unit 2.1.4 Diagram of Unit In...
lang:en score:22 filesize: 2 M page_count: 68 document date: 2024-10-04