

- [Manuals.plus](#) /
- › [Homy Casa](#) /
  - › Homy Casa Ergonomic Kids' Desk Chair Instruction Manual (Model B0D47KX9Q6)

Homy Casa B0D47KX9Q6

# Homy Casa Ergonomic Kids' Desk Chair

INSTRUCTION MANUAL - MODEL B0D47KX9Q6

## 1. Product Overview

---

The Homy Casa Ergonomic Kids' Desk Chair (Model B0D47KX9Q6) is designed to provide comfortable and supportive seating for children and students. It features a streamlined backrest, adjustable height, 360-degree swivel functionality, and durable construction suitable for various home and study environments.



Image of the Homy Casa Ergonomic Kids' Desk Chair in Peppery color, positioned at a desk.

## 2. Safety Information

---

- Ensure all components are securely fastened before use.
- Do not stand on the chair.
- Keep hands and fingers clear of moving parts during adjustment.
- This chair is designed for indoor use only.
- Maximum weight capacity: 250 lbs. Do not exceed this limit.
- Supervise children during initial use and assembly.

## 3. Package Contents

---

Verify that all parts are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Backrest (1)

- Seat Cushion (1)
- Gas Lift Cylinder (1)
- Base with Wheels (1)
- Hardware Pack (Screws, Washers, Allen Wrench) (1)
- User Manual (1)

## 4. Assembly Instructions

---

Assembly typically takes 10-15 minutes. Follow these steps carefully.

1. **Attach Wheels to Base:** Insert each wheel caster into the holes on the chair base until it clicks securely into place.
2. **Insert Gas Lift:** Place the gas lift cylinder into the center hole of the assembled base.
3. **Attach Seat Cushion to Backrest:** Align the seat cushion with the backrest and secure them using the provided screws and Allen wrench.
4. **Connect Seat Assembly to Gas Lift:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring it is centered and stable.



Diagram showing the dimensions of the Homy Casa Ergonomic Kids' Desk Chair, including height, width, and depth, along with its 250 lbs weight capacity and 10-15 minute assembly time.

## 5. Operating Instructions

---

### 5.1 Height Adjustment

To adjust the chair's height, locate the lever under the seat on the right side. While seated, pull the lever up to lower the chair. To raise the chair, stand up slightly to relieve weight from the seat, then pull the lever up. Release the lever at the desired height.

### 5.2 Swivel Function

The chair supports a full 360-degree rotation. Simply rotate the seat to face any direction. Note that the chair does not automatically return to its original position.

# BREATHABILITY

- the latest trendy colors
- skin-friendly comfort



Image illustrating the curved hollow backrest design and integrated armrest of the Homy Casa Ergonomic Kids' Desk Chair.

## 6. Maintenance

---

### 6.1 Cleaning

- Wipe metal and plastic parts with a soft, damp cloth.
- For fabric surfaces, use a mild fabric cleaner or a damp cloth. Avoid harsh chemicals.
- Ensure the chair is dry before use.

### 6.2 General Care

- Periodically check all screws and bolts to ensure they are tight.
- The PU wheels are designed to be gentle on floor surfaces and reduce noise. Keep them free of debris for optimal

performance.



Close-up of the chair's upgraded PU wheels, designed for noise reduction and to prevent floor scratching.



**Weight Capacity**  
**250LBS**



**10-15 Minutes**  
**Easy Assembly**



Close-up image of the chair's seat cushion, emphasizing its breathable, skin-friendly fabric.

## 7. Troubleshooting

---

- **Chair does not adjust height:** Ensure the gas lift lever is fully engaged and that there is no obstruction. If the issue persists, the gas lift cylinder may need replacement.
- **Chair wobbles:** Check all screws and bolts to ensure they are tightened. Ensure the chair is on a flat, even surface.
- **Wheels do not roll smoothly:** Inspect wheels for hair, dust, or debris. Clean as necessary. Ensure wheels are properly inserted into the base.

## 8. Specifications

---

- **Model Number:** B0D47KX9Q6
- **Brand:** Homy Casa
- **Color:** Peppery
- **Material:** Metal frame, Polyurethane seat, Foam fill
- **Product Dimensions (D x W x H):** 15" x 18.5" x 29.9" - 34.8" (Adjustable Height)
- **Item Weight:** 19.84 Pounds
- **Recommended Uses:** Office, Study, Vanity

- **Age Range Description:** Child
- **Surface Recommendation:** Hard Floor
- **Additional Features:** Ergonomic, 360-Degree Swivel, Adjustable Height, Noise-Reducing PU Wheels

## 9. Warranty and Support

---

For warranty information or technical support, please contact Homy Casa customer service through the retailer where the product was purchased or visit the official Homy Casa website. Please have your model number (B0D47KX9Q6) and purchase date available when contacting support.

© 2026 Homy Casa. All rights reserved.

### ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

#### Name

Anonymous

#### Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

#### Question

Example: How do I reset this device or fix this error?

#### Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

---

Open the live page

<https://manuals.plus/asin/B0D47KX9Q6>

More documents and user manuals: <https://manuals.plus/>