

[Manuals.plus](#) /

> [Bewinner](#) /

> Bewinner HD 1080P Bike Camera User Manual - Model Bewinnerwtxhavic3qf

Bewinner Bewinnerwtxhavic3qf

Bewinner HD 1080P Bike Camera User Manual

Model: Bewinnerwtxhavic3qf

INTRODUCTION

This manual provides detailed instructions for the setup, operation, and maintenance of your Bewinner HD 1080P Bike Camera. This camera is designed for outdoor sports, offering 1080P HD recording with a 120-degree wide-angle lens and anti-shake technology. Its waterproof design makes it suitable for various environments, including cycling and motorcycling.



Image: The Bewinner Bike Camera displaying its live feed on a smartphone, highlighting its real-time interconnection feature.

The camera supports charging while recording, loop recording, and offers real-time interconnection with a mobile application for live viewing without using mobile data. Its adjustable rotatable mounting bracket enhances versatility for various recording angles, especially during night rides.

WHAT'S IN THE BOX

Please verify that all components are present in your package:

- Bewinner HD 1080P Bike Camera
- Adjustable Rotatable Mounting Bracket
- USB Charging Cable
- User Manual (this document)
- Battery
- Additional Mounting Accessories (e.g., base, screw adapter)



Image: All included components of the Bewinner Bike Camera package, including the camera, various mounts, and charging cable.

PRODUCT COMPONENTS

Familiarize yourself with the camera's main parts and controls:




Image: A detailed diagram illustrating the various components of the Bewinner Bike Camera, including the microphone,

lens, mode key, indicators, USB port, and memory card slot.

1. Microphone
2. Lens
3. Mode Key
4. Camera Light
5. Video Indicator Light
6. WiFi Indicator
7. Power Source (Button)
8. USB Port
9. Charging Light
10. Reset Hole
11. Memory Card Slot
12. Multifunctional Base

SETUP INSTRUCTIONS

1. Charging the Camera

Before first use, fully charge the camera. Connect the USB charging cable to the camera's USB port and a power source. The charging light will indicate charging status.

2. Inserting a Memory Card

The camera supports memory cards up to 256GB (not included). Carefully insert the memory card into the memory card slot until it clicks into place. Ensure the camera is powered off before inserting or removing the card.

3. Mounting the Camera

Attach the camera to your desired location (e.g., bicycle handlebars, helmet) using the adjustable rotatable mounting bracket and other provided accessories. Ensure the camera is securely fastened to prevent movement during activity.



Image: The Bewinner Bike Camera securely mounted on bicycle handlebars, demonstrating a typical installation scenario.

4. Connecting to the Mobile App (Real-Time Interconnection)

To view footage in real-time, download the dedicated mobile application (refer to the packaging or included documentation for app name/QR code). Turn on the camera's WiFi. Connect your smartphone to the camera's WiFi hotspot. Open the app to establish a connection and view the live feed.



Image: A smartphone screen displaying a live view from the Bewinner Bike Camera, illustrating the wireless connection feature.

1. Power On/Off

Press and hold the Power Source button (7) to turn the camera on or off.

2. Recording Video

Once powered on, the camera typically starts recording automatically. The video indicator light (5) will flash to confirm recording is in progress. Press the Mode Key (3) to switch between recording modes if available (e.g., video, photo). Press the Power Source button (7) briefly to stop recording.

3. Loop Recording

The camera features loop recording. When the memory card is full, the camera will automatically overwrite the oldest files, ensuring continuous recording without interruption. This function prevents the camera from stopping recording due to a full memory card.



Image: An illustration depicting the loop recording process, where older video segments are replaced by new ones once the memory card capacity is reached.

4. Using the Mobile App

After connecting via WiFi, use the mobile app to:

- View live footage.
- Start/stop recording.
- Adjust camera settings.
- Download recorded videos to your smartphone.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the camera body and lens. Avoid abrasive materials or harsh chemicals.
- **Water Resistance:** The camera is designed to resist rain and splashes. However, avoid submerging it in water or exposing it to high-pressure water jets.
- **Storage:** Store the camera in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** For optimal battery life, avoid fully discharging the battery frequently. Charge it regularly, even if not in use for extended periods.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Camera does not power on.	Low battery; faulty battery; power button issue.	Charge the camera fully. Ensure the battery is correctly inserted. If the issue persists, contact support.
Cannot record video.	No memory card; full memory card; memory card error.	Insert a compatible memory card. Format or replace the memory card. Check if loop recording is enabled.
Poor video quality.	Dirty lens; low light conditions; camera shake.	Clean the lens. Ensure adequate lighting. Securely mount the camera to minimize shake.
Cannot connect to mobile app.	WiFi not enabled on camera; incorrect WiFi password; app issue.	Ensure camera WiFi is on. Verify WiFi password. Restart camera and phone. Reinstall app if necessary.
Recorded files are unplayable.	Corrupted files; incompatible player.	Try playing files on a different media player (e.g., VLC). Format the memory card and re-record. If issue persists, the camera may be faulty.

If you encounter problems not listed here or if the suggested solutions do not resolve the issue, please contact Bewinner customer support.

SPECIFICATIONS

- **Model Name:** Bewinnerwtxhavic3qf
- **Video Resolution:** 1080P HD
- **Wide Angle:** 120 degrees
- **Image Stabilization:** Electronic Image Stabilization

- **Memory Card Support:** Up to 256GB (not included)
- **Connectivity:** WiFi (for real-time app connection)
- **Features:** Loop Recording, Charging while Recording, High Fidelity Microphone, Waterproof (rain and splash resistant)
- **Dimensions:** Approximately 4.57 x 4.45 x 1.77 inches (Item Package Dimensions)
- **Weight:** Approximately 0.15 Kilograms (Package Weight)

OFFICIAL PRODUCT VIDEO

Your browser does not support the video tag.

Video: An official demonstration video showcasing the features and usage of the Bewinner HD 1080P Bike Camera, including its waterproof capabilities and wide-angle view.

WARRANTY AND SUPPORT

Bewinner products typically come with a standard manufacturer's warranty. Please refer to the product packaging or the official Bewinner website for specific warranty terms and conditions. For technical support, troubleshooting assistance, or warranty claims, please contact Bewinner customer service through their official channels.

Contact Information: Refer to the Bewinner brand store on Amazon or the contact details provided in your product packaging.