

[manuals.plus](#) /› [Koss](#) /› [Koss CL/2 Clear Transparent On-Ear Headphone User Manual](#)

## Koss CL/2

# Koss CL/2 Clear Transparent On-Ear Headphone User Manual

Model: CL/2 | Brand: Koss

## 1. INTRODUCTION

This manual provides essential information for the proper use, setup, and maintenance of your Koss CL/2 Clear Transparent On-Ear Headphones. Designed for balanced and accurate audio reproduction, these lightweight headphones offer universal compatibility and a distinctive retro aesthetic.

## 2. KEY FEATURES

- **Crystal Clear Sound:** The Koss CL/2 delivers balanced, accurate audio reproduction through lightweight yet durable full-size circumaural earcups.
- **Retro Inspired Design:** Clear transparent earcups and headband showcase the inner workings of the CL/2 while maintaining a vintage aesthetic.
- **Comfortable Fit:** Soft, foam earpads sit comfortably on the ears to provide hours of enjoyable listening.
- **Durable Construction:** Constructed with lightweight yet durable materials, it can withstand demanding environments.
- **Universal Connectivity:** Easily connect to laptops, tablets, and gaming devices with a 3.5mm standard headphone jack connector.





Figure 2.1: The Koss CL-2 Clear Transparent On-Ear Headphones, showcasing their lightweight design and transparent earcups.

### 3. SETUP

1. **Unpack:** Carefully remove the headphones from their packaging.

2. **Inspect:** Check the headphones and cable for any visible damage.
3. **Connect:** Insert the 3.5mm audio jack firmly into the headphone port of your audio device (laptop, tablet, smartphone, gaming console, etc.). Ensure the connection is secure to prevent audio interruptions.



Figure 3.1: The 3.5mm audio jack, ready for connection to your device.

## 4. OPERATING INSTRUCTIONS

- **Wearing the Headphones:** Place the earcups over your ears, ensuring the soft foam earpads sit comfortably. The headband is adjustable; gently slide the earcups up or down along the headband to achieve a snug and comfortable fit.
- **Audio Playback:** Once connected, play audio from your device. Adjust the volume directly on your connected device. The headphones do not feature inline volume controls.
- **Cable Management:** The 6-foot cord provides ample length for various uses. Avoid excessive pulling or tangling of the cable to prevent damage.



Figure 4.1: Koss CL/2 headphones positioned on a desk, illustrating typical usage with a computer.

## Official Product Video

Your browser does not support the video tag.

Video 4.1: An official product video showcasing the Koss CL/2 Clear Transparent Headphones, highlighting their features and design.

## 5. MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to wipe down the earcups and headband. For the foam earpads, gently dab with a slightly damp cloth if necessary, and allow them to air dry completely before use. Avoid using harsh chemicals or abrasive cleaners.
- **Storage:** Store the headphones in a clean, dry place away from extreme temperatures and direct sunlight. Avoid tightly coiling the cable to prevent damage.
- **Handling:** Always grasp the 3.5mm jack when plugging or unplugging the headphones, rather than pulling on the cable.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
No sound	Cable not fully inserted. Device volume too low or muted. Incorrect audio output selected on device.	Ensure 3.5mm jack is fully inserted. Increase device volume and check mute settings. Verify audio output settings on your device.
Distorted sound	Volume too high. Damaged cable or jack. Poor audio source quality.	Lower the volume on your device. Inspect cable and jack for damage. Try with another device. Test with a different audio source.
Headphones uncomfortable	Improper headband adjustment.	Adjust the headband to find a comfortable fit.

## 7. SPECIFICATIONS

Feature	Detail
Model Name	CL/2
Brand	Koss
Connectivity Technology	Wired
Headphones Jack	3.5 mm Jack
Ear Placement	On Ear
Form Factor	On Ear
Color	Clear
Material	plastic and/or metal, plastic and/or rubber
Item Weight	2.89 ounces
Cable Feature	Retractable
Frequency Range	20 Hz - 20,000 Hz
Compatible Devices	Cellphones, Gaming Consoles, Telephones, Laptops, Computers, Tablets
Recommended Uses	Music, Podcasts
Manufacturer	Koss Corporation
Country of Origin	China
UPC	021299140963

## 8. WARRANTY AND SUPPORT

---

For warranty information and technical support, please refer to the official Koss website or contact Koss customer service directly. Keep your purchase receipt for warranty claims.

For additional resources and product details, visit the product page on Amazon.com.

[Product Page Link](#)

© 2024 Koss Corporation. All rights reserved.