

[Manuals.plus](#) /

› [ACCOHOHO](#) /

› ACCOHOHO 6 Drawer Dresser Instruction Manual

ACCOHOHO 6 Drawer Dresser

ACCOHOHO 6 Drawer Dresser Instruction Manual

Model: 6 Drawer Dresser (B0D48Q75M5)

INTRODUCTION

Thank you for choosing the ACCOHOHO 6 Drawer Dresser. This manual provides detailed instructions for the safe assembly, setup, operation, and maintenance of your new furniture. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

SAFETY INFORMATION

Your safety is paramount. Please observe the following safety guidelines:

- **Anti-Tipping Device:** It is critical to install the included anti-tipping device to prevent serious injury from furniture tip-over. Always secure the dresser to a wall using the provided hardware.
- **Assembly:** Assembly should be performed by two adults. Ensure all parts are correctly aligned and all fasteners are securely tightened before use.
- **Weight Limits:** Do not exceed the maximum weight capacity for the tabletop (150 lbs) or individual drawers (30 lbs). Overloading can compromise stability and cause damage.
- **Placement:** Place the dresser on a flat, level surface to ensure stability. Avoid placing heavy items on top that could cause imbalance.
- **Children:** Keep children away from the assembly area. Do not allow children to climb on or play with the dresser.



Figure 1: Anti-Tipping Device Installation. This diagram illustrates the importance of securing the dresser to the wall using the anti-tipping device to prevent accidental tip-over, especially with children present.

PARTS LIST

Before assembly, carefully unpack all components and verify against the detailed parts list provided in your packaging. Each component is labeled with a serial number for easy identification. If any parts are missing or damaged, please contact ACCOHOHO customer support.

- Main frame panels (top, bottom, sides, back)
- Drawer panels (front, back, sides, bottom)
- Drawer slides (metal)
- Handles and associated hardware
- Assembly hardware (screws, cams, dowels, etc.)
- Anti-tipping device and hardware

ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults and can be completed within 40-50 minutes. Follow the step-by-step instructions and diagrams included in your product packaging. Ensure you have a clear, spacious area for assembly.

1. **Unpack and Identify:** Lay out all parts on a soft, clean surface to prevent scratches. Match each part to the corresponding label in the instruction manual.
2. **Assemble the Frame:** Begin by connecting the side panels to the bottom and top panels using the designated hardware. Ensure all connections are secure.
3. **Install Drawer Slides:** Attach the metal drawer slides to the interior of the dresser frame and to the drawer side panels as indicated. Ensure they are level and facing the correct direction for smooth operation.
4. **Assemble Drawers:** Construct each drawer by connecting the front, back, and side panels. Insert the drawer bottom and secure it. Attach the handles to the drawer fronts.
5. **Insert Drawers:** Carefully slide each assembled drawer into its designated slot in the dresser frame. Test for smooth operation.
6. **Attach Back Panel:** Secure the back panel to the dresser frame.

7. **Install Anti-Tipping Device:** Follow the specific instructions for installing the anti-tipping device to a wall stud or appropriate anchor point. This step is crucial for safety.



Figure 2: Product Dimensions. This image provides an overview of the dresser's overall dimensions (31.5" W x 15.5" D x 44" H) and individual drawer sizes, including weight capacity for the tabletop (150 lbs) and drawers (30 lbs).



Figure 3: Key Features. Details on the 1.2" thickened tabletop for maximum load, wider and longer metal handles for ease of use and durability, and the thickened beveled base for enhanced stability.

SETUP

Once assembled, position your dresser carefully:

- **Location:** Choose a stable, level surface in your bedroom, living room, nursery, or walk-in closet. Ensure adequate space for opening drawers.
- **Wall Anchoring:** Securely attach the anti-tipping device to a wall stud or use appropriate wall anchors. This step is non-negotiable for safety.
- **Leveling:** If the floor is uneven, adjust the leveler pegs on the base of the dresser to ensure it stands firmly without wobbling.



Figure 4: Dresser in a Bedroom Setting. This image shows the dresser positioned in a bedroom, demonstrating its aesthetic integration and functional placement.

OPERATING THE DRESSER

The ACCOHOHO 6 Drawer Dresser is designed for efficient storage:

- **Drawer Use:** Open and close drawers smoothly using the metal handles. Avoid forcing drawers if they feel stuck.
- **Weight Distribution:** Distribute items evenly within drawers. Do not exceed the 30 lbs weight limit per drawer.
- **Tabletop Use:** The spacious tabletop can hold lamps, decor, or photos, with a maximum weight capacity of 150 lbs.



Figure 5: Organized Drawers. This image demonstrates the internal capacity of the top two smaller drawers, suitable for organizing various personal items.



Figure 6: Drawer Storage Capacity. This image illustrates the storage potential of the larger drawers, capable of holding approximately 20-25 t-shirts or 15-20 pairs of jeans.

MAINTENANCE

Proper care will extend the life and appearance of your dresser:

- **Cleaning:** Wipe the dresser surfaces with a dry, soft cloth. Avoid abrasive cleaners or harsh chemicals that can damage the finish.
- **Spills:** Clean spills immediately with a dry cloth to prevent staining or damage to the engineered wood.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten as necessary.
- **Drawer Slides:** If drawers become stiff, ensure the metal slides are clean and free of debris. Lubrication is generally not required for ball-bearing slides.

TROUBLESHOOTING

- **Drawers not sliding smoothly:**
 - Check that the drawer slides are correctly installed and aligned.
 - Ensure no objects are obstructing the slides.
 - Verify that the drawer is not overloaded.
- **Dresser wobbles:**
 - Ensure the dresser is on a level surface. Adjust the leveler pegs if necessary.
 - Check that all assembly screws are fully tightened.
- **Missing or damaged parts:**
 - Refer to the parts list in your packaging. Contact ACCOHOHO customer support for replacements.

SPECIFICATIONS

Brand	ACCOHOHO
-------	----------

Model	6 Drawer Dresser
Material	Engineered Wood
Finish Type	Painted (Off White)
Overall Dimensions (D x W x H)	39.4D x 80W x 111.8H cm (15.5" D x 31.5" W x 44" H)
Number of Drawers	6
Drawer Type	Ball Bearing Slide
Item Weight	106 Pounds
Max Tabletop Load	150 lbs
Max Drawer Load	30 lbs
Assembly Required	Yes
Care Instructions	Wipe with Dry Cloth

WARRANTY AND SUPPORT

For warranty information, replacement parts, or any questions regarding your ACCOHOHO 6 Drawer Dresser, please refer to the contact information provided in your product packaging or visit the official ACCOHOHO website. Our customer support team is available to assist you.

© 2026 ACCOHOHO. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question