



Manuals.plus /

› GOOJODOQ /

› GOOJODOQ Professional Projector User Manual

GOOJODOQ AC1041

GOOJODOQ Professional Projector User Manual

Model: AC1041

Brand: GOOJODOQ

Proyector inteligente Full HD de 1080p



Bluetooth 5.0



Wifi 6

1080

FULL HD



13000 lúmenes



A grey GOOJODOQ projector with a black fabric top, displaying a bright projection of a yellow flower. A black remote control is placed next to it. The image highlights features like Bluetooth 5.0, WiFi 6, 1080P Full HD, and 13000 lumens.

1. INTRODUCTION

Thank you for choosing the GOOJODOQ Professional Projector. This portable projector is designed to deliver a superior viewing experience with its Native 1080P Full HD resolution, advanced connectivity options, and user-friendly features. This manual provides detailed instructions to help you set up, operate, and maintain your projector for optimal performance.

2. PRODUCT FEATURES

- **Native 1080P Full HD Resolution:** Experience crisp and clear images with a resolution of 1920 x 1080 pixels.


- **High Brightness:** Boasts 15000 lumens for vivid and bright projections.
- **Electronic Focus & Auto Keystone Correction:** Automatically adjusts image shape and focus for a perfect rectangular display, even at an angle.
- **Advanced Connectivity:** Equipped with WiFi 6 for smooth online streaming and Bluetooth 5.0 for seamless audio connections.
- **Wide Compatibility:** Connects effortlessly with smartphones, tablets, laptops, PCs, gaming consoles, and more via HDMI, USB, and AV ports.
- **Smart Design:** Features fabric-covered buttons for durability and a sophisticated look, efficient heat dissipation for quiet operation, and a built-in speaker for immersive sound.
- **Large Projection Size:** Supports projection sizes up to 200 inches, suitable for various viewing environments.

Imágenes más claras




A split image showing a parrot. The left side, labeled "GOOJODOQ," displays a vibrant, high-brightness 1080P Full HD image with intense colors. The right side, labeled "Others," shows a duller, lower-brightness 1080P image with less intense colors.

Diseños inteligentes



Botones recubiertos de tela

Evita arañazos y huellas dactilares



Dispositivo de disipación del calor

Menos ruido del ventilador y generación de calor



Altavoz con bocina

Excelentes sonidos estéreo

A close-up view of the projector's design elements, including fabric-covered buttons, efficient heat dissipation, and a built-in speaker.



600 ANSI Native 1080P Full HD Proyecto



1080P Full HD



WiFi 6



Bluetooth 5.0



Enfoque Electrónico



Auto keystone



HDMI



soporta 4k



600 ANSI

A wide banner image showing the GOOJODOQ projector from the front, with icons representing its main features: 1080P Full HD, WiFi 6, Bluetooth 5.0, Electronic Focus, Auto Keystone, HDMI, 4K support, and 600 ANSI lumens.

Amplia compatibilidad



A close-up composite image detailing the projector's smart design, showing the fabric-covered control buttons, heat dissipation vents, and a cross-section of the internal speaker.

3. PACKAGE CONTENTS

Please check the package contents carefully. If any items are missing or damaged, please contact customer support.

- GOOJODOQ Professional Projector (AC1041)
- Remote Control
- Power Cable
- User Manual

4. SETUP GUIDE

4.1 Placement

Place the projector on a stable, flat surface. Ensure there is adequate ventilation around the projector. The projection distance will determine the screen size. Refer to the table below for recommended distances.

Projection Distance	Screen Size (Approx.)
1.0 m (3.3 ft)	35 inches
2.5 m (8.2 ft)	90 inches
5.0 m (16.4 ft)	200 inches

Disfrute de la gran pantalla a su antojo

El tamaño máximo de proyección de 200" le permite mejorar la experiencia de visualización y satisfacer sus distintas necesidades.



An image demonstrating the flexible projection sizes of the GOOJODOQ projector, showing 35, 90, and 200-inch projections.

4.2 Power Connection

1. Connect the power cable to the projector's power input port.
2. Plug the other end of the power cable into a power outlet.

4.3 Initial Power On

Press the power button on the projector or the remote control to turn on the device. The indicator light will illuminate.

4.4 Focus Adjustment

The projector features electronic focus. Use the focus buttons on the remote control (usually marked with 'F+' and 'F-') to adjust the image clarity until it is sharp.

4.5 Keystone Correction

The projector supports automatic keystone correction. If the image appears trapezoidal, the projector will automatically adjust it to a rectangular shape. Manual adjustment may also be available via the remote control if needed.

Enfoque electrónico y corrección trapezoidal $\pm 30^\circ$

Garantiza que las imágenes siempre se enfoquen y proyecten en el lugar correcto, proporcionando una experiencia excelente.



A projector displaying a video game scene on a wall, illustrating how electronic focus and $\pm 30^\circ$ keystone correction ensure a perfectly clear and rectangular image.



An image showing a projected scene with smaller images illustrating the automatic keystone correction process for a perfect rectangular display.

5. OPERATING INSTRUCTIONS

5.1 Remote Control Navigation

Use the arrow keys (Up, Down, Left, Right) on the remote control to navigate through menus. Press the 'OK' button to confirm selections. The 'Back' button returns to the previous screen.

5.2 Connecting to Wi-Fi

1. From the main menu, navigate to 'Settings' or 'Network Settings'.
2. Select 'Wi-Fi' and turn it ON.
3. Choose your desired Wi-Fi network from the list.
4. Enter the Wi-Fi password using the on-screen keyboard and confirm.

5.3 Bluetooth Pairing

1. From the main menu, navigate to 'Settings' or 'Bluetooth Settings'.
2. Select 'Bluetooth' and turn it ON.
3. The projector will search for available Bluetooth devices.
4. Select your Bluetooth speaker or headphone from the list to pair.

5.4 Screen Mirroring (Android/iOS)

The projector supports wireless screen mirroring from Android and iOS devices via WiFi 6. Ensure both your device and the projector are connected to the same Wi-Fi network.

- **For Android:** Select the 'Android Cast' or 'Miracast' option on the projector. On your Android device, enable 'Wireless Display', 'Screen Mirroring', or 'Smart View' and select the projector from the list.
- **For iOS:** Select the 'iOS Cast' or 'AirPlay' option on the projector. On your iOS device, open Control Center, tap 'Screen Mirroring', and select the projector from the list.

Smooth WiFi 6 y Bluetooth 5.0

Reduce la latencia de la transmisión en línea o de los juegos y favorece la sincronización entre pantallas para garantizar imágenes fluidas en todo momento.



A projector displaying a game on a large screen, with a smartphone mirroring its content, highlighting low-latency wireless transmission.



A living room scene where a GOOJODOQ projector is casting a mobile phone screen onto a large wall, emphasizing no additional software download is needed.



A scene depicting a person playing a first-person shooter game projected onto a large screen, highlighting smooth, low-latency performance.

5.5 Connecting External Devices

The projector offers multiple input ports for various devices:

- **HDMI:** Connect laptops, TV sticks, DVD players, computers, PS4/PS5, and other HDMI-enabled devices.
- **USB:** Insert USB drives for media playback, or connect a USB mouse/keyboard for easier navigation.
- **AV:** Connect older devices using an AV cable.
- **Headphone Jack:** Connect external headphones or speakers.



A detailed view of the projector's rear panel, clearly labeling its input ports (USB, HDMI, AV) and illustrating compatible devices.

5.6 Selecting Input Sources

After connecting an external device, navigate to the 'Input Source' menu on the projector (usually accessible via a dedicated button on the remote or main menu) and select the corresponding input (e.g., HDMI1, USB, AV).

Amplia compatibilidad



Inicio Cinama



Juegos




TV en directo




Entretenimiento al aire libre

Four panels illustrating different uses: Home Cinema, Gaming, Live TV, and Outdoor Entertainment.

Diseños inteligentes



Botones recubiertos de tela
Evita arañazos y huellas dactilares



Dispositivo de disipación del calor
Menos ruido del ventilador y generación de calor



Altavoz con bocina
Excelentes sonidos estéreo

A person is comfortably seated on a sofa, watching a large projected image of a movie on a wall, demonstrating the projector's suitability for creating an immersive home cinema experience.



A professional setting where several people are gathered around a table, with the GOOJODOQ projector displaying a business presentation on a wall.



A group of friends enjoying an outdoor movie night on a patio, with the GOOJODOQ projector casting a large image onto a screen.

6. MAINTENANCE

6.1 Cleaning the Lens

Use a soft, lint-free cloth specifically designed for optical lenses to gently wipe the projector lens. Do not use abrasive cleaners or excessive force, as this can scratch the lens.

6.2 Cleaning the Vents

Regularly check and clean the air vents to prevent dust buildup, which can affect cooling and performance. Use a soft brush or a can of compressed air to remove dust from the vents.

6.3 Storage

When not in use for extended periods, store the projector in a cool, dry place, away from direct sunlight and extreme temperatures. It is recommended to use the original packaging or a protective case to prevent dust and damage.

6.4 Power Off Procedure

Always power off the projector correctly by pressing the power button and confirming shutdown. Do not unplug the power cable directly without proper shutdown, as this may damage the device.

7. TROUBLESHOOTING

If you encounter any issues with your projector, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; Power outlet issue	Ensure power cable is securely connected; Try a different power outlet.
No image	Incorrect input source; Cable connection issue	Select the correct input source (HDMI, USB, AV); Check all cable connections.
Blurry image	Focus not adjusted; Projector too close/far	Adjust focus using the remote control; Adjust projection distance.
No sound	Volume too low; Incorrect audio output; Bluetooth not connected	Increase volume; Check audio settings; Ensure Bluetooth device is paired.
Wi-Fi/Bluetooth connection issues	Network interference; Incorrect password; Device too far	Restart projector and router; Re-enter password; Move devices closer.
Remote control not working	Low battery; Obstruction	Replace batteries; Remove any obstructions between remote and projector.

If the problem persists after trying these solutions, please contact GOOJODOQ customer support for further assistance.

8. SPECIFICATIONS

Feature	Specification
Model	AC1041
Brand	GOOJODOQ
Display Technology	LCD, LED
Native Resolution	1920 x 1080 (Full HD)
Brightness	15000 Lumens
Connectivity	WiFi 6, Bluetooth 5.0, HDMI, USB, AV
Compatible Devices	Smartphone, Tablet, Laptop, PC, Android, Gaming Consoles
Special Features	Electronic Focus, Auto Keystone Correction, Fabric Top Cover, Temperature Control
Dimensions	33.1 x 24.7 x 19 cm
Weight	2.54 kg

9. WARRANTY AND SUPPORT

The GOOJODOQ Professional Projector comes with a standard manufacturer's warranty. Please refer to the warranty card included in your package for specific terms and conditions. For technical support, troubleshooting assistance, or

warranty claims, please contact GOOJODOQ customer service through the contact information provided on our official website or your purchase platform.