

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Suicoey](#) /

› [Suicoey P80 Android Tablet User Manual](#)

## Suicoey P80

# Suicoey P80 Android Tablet User Manual

Model: P80 | Brand: Suicoey

## INTRODUCTION

---

This manual provides essential information for the setup, operation, and maintenance of your Suicoey P80 Android Tablet. Please read this manual thoroughly before using your device to ensure optimal performance and longevity.

## WHAT'S IN THE BOX

---

Verify that all items are present in the package:

- 1 x 11-inch Tablet
- 1 x Keyboard
- 1 x Mouse
- 1 x Stylus
- 1 x Case
- 1 x User Manual
- 1 x USB Charger
- 1 x Type-C Cable



Image: The Suicoey P80 Android Tablet and its included accessories, such as the keyboard, mouse, stylus, protective case, charger, and USB-C cable.

## PRODUCT FEATURES

### Display and Visuals

The tablet features an 11-inch IPS display with a resolution of 1280x800 pixels, providing clear and vivid images. It supports Widevine L1 for high-definition streaming content.

# 11" Bigger and Vivid Display



11" IPS screen



1280\*800 HD



Adaptive  
brightness



*Image: The tablet's 11-inch IPS display, highlighting its vivid colors and HD resolution.*

## Operating System and Performance

Equipped with the Android 15 operating system, the tablet offers optimized privacy settings, improved multitasking management, and a faster octa-core processor for efficient performance. It is GMS certified, allowing access to a wide range of applications from the Google Play Store.

# Newest Android 15

Android 15 is more responsive, fully meets customers's individual needs and protects privacy better



**Smoother system**



**More customized**



**Safer data**



**Higher efficiency**



**Parental control**

*Image: The Android 15 operating system interface on the tablet, showcasing its features and app compatibility.*

## Memory and Storage


The tablet comes with 24GB (4GB + 20GB expandable) RAM and 128GB of internal storage (ROM). Storage can be expanded up to 1TB using a TF card (not included), providing ample space for applications, media, and files.

## Large Space for Storage

 24GB (4+20)  
RAM

 128GB  
ROM

 1TB  
Expand



## GMS Certified Tablet

A large number of popular apps for your choice



*Image: Visual representation of the tablet's memory and storage capabilities.*

## Battery and Charging

An 8000mAh battery provides extended usage, with up to 17 hours of video playback. The tablet supports 18W fast charging via its Type-C port.

# 8000mAh Battery & Fast Charging



17hrs  
videos



14hrs  
videos



720hrs  
standby



Type C




Image: Details on the tablet's 8000mAh battery and fast charging capabilities.

## Cameras

Capture moments with the 13MP rear camera and 5MP front camera, suitable for photos, video calls, and online meetings.

# Seize your precious life moments



**13MP**  
Rear camera



**5MP**  
Front camera

*Image: Overview of the tablet's front and rear cameras.*

## Connectivity

Supports 2.4G and 5G WiFi for stable and fast internet access, and Bluetooth V5.0 for connecting wireless peripherals. A 3.5mm headphone jack is also included.

## 2-in-1 Functionality

The tablet can be used as a laptop replacement with the included keyboard and mouse, enhancing productivity for work or study. It also supports Face Unlock for convenient and secure access.



*Image: The tablet configured with its keyboard and mouse, demonstrating its use for video conferencing.*

## SETUP GUIDE

---


### 1. Initial Power On and Setup

1. Press and hold the power button located on the side of the tablet until the screen lights up.
2. Follow the on-screen prompts to select your language, connect to a Wi-Fi network, and set up your Google account.
3. Review and accept the terms and conditions to complete the initial setup.

### 2. Connecting the Keyboard and Mouse

The keyboard and mouse connect via Bluetooth.

1. Ensure the keyboard and mouse are charged and powered on.
2. On your tablet, navigate to **Settings > Connected devices > Bluetooth**.
3. Turn on Bluetooth and scan for available devices.
4. Select the keyboard and mouse from the list to pair them. Follow any on-screen prompts for pairing codes if necessary.



*Image: The tablet connected to its keyboard and mouse, demonstrating a typical desktop setup.*

## OPERATING INSTRUCTIONS

---

### Basic Navigation

- **Touch Screen:** Use your finger or the included stylus to tap, swipe, pinch-to-zoom, and long-press on the screen.
- **Home Screen:** Access your installed applications and widgets. Swipe left or right to navigate between home screens.

- **Notifications:** Swipe down from the top of the screen to view notifications and quick settings.
- **App Drawer:** Swipe up from the bottom of the home screen to access all installed applications.

## Installing Applications

As a GMS certified device, you can download and install applications from the Google Play Store:

1. Open the **Play Store** app from your home screen or app drawer.
2. Search for the desired application using the search bar.
3. Tap **Install** to download and automatically install the app.

## Split-Screen Multitasking

To use two apps simultaneously:

1. Open the first app.
2. Tap the square button (recent apps) at the bottom of the screen.
3. Long-press the icon of the first app at the top of its card, then select **Split screen**.
4. Choose the second app from your recent apps or app drawer to fill the other half of the screen.




Image: Instructions for using the split-screen feature to run two applications concurrently.

## MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid abrasive cleaners or solvents.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the tablet using the provided charger and cable.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security. Go to **Settings > System > System update**.
- **Storage Management:** Periodically clear unnecessary files and uninstall unused apps to free up storage space and maintain performance.

## TROUBLESHOOTING

Problem	Possible Cause / Solution
---------	---------------------------

Problem	Possible Cause / Solution
Tablet does not turn on	Battery may be depleted. Connect the charger and wait a few minutes before attempting to power on.
Cannot connect to Wi-Fi	Ensure Wi-Fi is enabled in settings. Restart your router and the tablet. Verify the Wi-Fi password.
Keyboard/Mouse not pairing	Ensure Bluetooth is on for both devices and the tablet. Make sure devices are charged. Try unpairing and re-pairing.
Slow performance	Close unused apps. Clear cache. Check for system updates. Consider a factory reset if issues persist (backup data first).

## SPECIFICATIONS

Feature	Detail
Model	P80
Operating System	Android 15
Screen Size	11 Inches
Screen Resolution	1280 x 800 pixels (IPS)
RAM	24 GB (4 GB + 20 GB Expand)
Internal Storage (ROM)	128 GB
Expandable Storage	Up to 1 TB (TF card)
Rear Camera	13 MP
Front Camera	5 MP
Battery Capacity	8000 mAh
Battery Life (Video)	Up to 17 Hours
Charging	18W Fast Charging (Type-C)
Wireless Connectivity	2.4G & 5G WiFi, Bluetooth V5.0
Processor Brand	Unisoc
Item Weight	3.14 pounds
Product Dimensions	11.3 x 7.8 x 2.7 inches

## OFFICIAL PRODUCT VIDEO

Watch this video for a detailed overview of the Suicoey 11-inch Android Tablet's features and functionality.

Your browser does not support the video tag.

*Video: An overview of the Suicoey 11-inch Android Tablet, demonstrating its features and accessories.*

## WARRANTY AND SUPPORT

---

For warranty information and technical support, please refer to the contact details provided on the product packaging or visit the official Suicoey website. Keep your purchase receipt for warranty claims.

© 2025 Suicoey. All rights reserved.