

Suicoey P80

Suicoey P80 11-inch Android 15 Tablet User Manual

Model: P80

1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions carefully before using your tablet. Keep this manual for future reference.

- Do not expose the tablet to extreme temperatures, direct sunlight, or high humidity.
- Avoid dropping or subjecting the tablet to severe impact.
- Use only approved chargers and accessories to prevent damage and ensure safety.
- Do not attempt to disassemble or repair the tablet yourself. Contact qualified service personnel.
- Keep the tablet away from water and other liquids.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- 1 x Suicoey P80 11-inch Tablet
- 1 x Keyboard
- 1 x Mouse
- 1 x Stylus
- 1 x Tablet Case
- 1 x User Manual
- 1 x USB Charger
- 1 x Type-C Cable



Image: The Suicoey P80 tablet displayed with its included accessories: keyboard, mouse, stylus, case, charger, and cable.

3. DEVICE OVERVIEW

3.1 Physical Components

Familiarize yourself with the tablet's buttons, ports, and features.

- **Power Button:** Located on the side, press and hold to power on/off or restart.
- **Volume Buttons:** Adjust audio volume.
- **USB-C Port:** For charging and data transfer.
- **3.5mm Headphone Jack:** Connect wired headphones.
- **MicroSD Card Slot:** Expand storage up to 1TB.
- **Front Camera:** For video calls and selfies (5MP).
- **Rear Camera:** For photos and videos (13MP).

2 in 1 Tablet



Image: The Suicoey P80 tablet in its case with keyboard and mouse, highlighting key features such as Android 15, 11-inch IPS screen, RAM, ROM, expandable storage, WiFi, cameras, Bluetooth, and battery capacity.

4. SETUP

4.1 Initial Power On

1. Press and hold the Power button until the screen lights up.
2. Follow the on-screen prompts to select your language, region, and accept the terms and conditions.

4.2 Connecting to Wi-Fi

1. From the home screen, swipe down from the top to open the Quick Settings panel.
2. Tap the Wi-Fi icon to enable it.
3. Go to **Settings > Network & internet > Wi-Fi**
4. Select your desired Wi-Fi network from the list and enter the password if prompted.

4.3 Pairing Accessories (Keyboard, Mouse, Stylus)

The tablet supports Bluetooth V5.0 for connecting wireless accessories.

1. Ensure the accessory (keyboard, mouse) is powered on and in pairing mode. Refer to the accessory's

individual manual for specific instructions.

2. On your tablet, go to **Settings > Connected devices > Pair new device**
3. Select the accessory from the list of available devices to pair.
4. The stylus typically does not require Bluetooth pairing and functions directly with the screen.

4.4 Google Mobile Services (GMS) Setup

As a GMS certified tablet, you can access Google services.

1. During initial setup, sign in with your Google account or create a new one.
2. This allows access to the Google Play Store, Gmail, YouTube, and other Google applications.

5. OPERATING YOUR TABLET

5.1 Basic Navigation

- **Tap:** Select items or open applications.
- **Swipe:** Scroll through screens or lists.
- **Pinch:** Zoom in or out on images and web pages.
- **Long Press:** Access contextual menus or move icons.

5.2 Android 15 Features

Your tablet runs on Android 15, offering enhanced privacy, customization, and efficiency.

- **Privacy Dashboard:** Monitor and manage app permissions.
- **Improved Multitasking:** Utilize split-screen mode for multiple applications simultaneously.
- **Personalized Interface:** Customize themes, widgets, and notifications.

Newest Android 15

Android 15 is more responsive, fully meets customers's individual needs and protects privacy better



Image: A visual representation of the Android 15 operating system interface on the Suicoey P80 tablet, showcasing its features like smoother system, more customization, safer data, higher efficiency, and parental control.

5.3 App Management

Download, install, and manage applications from the Google Play Store.

- **Download:** Open the Play Store app, search for your desired app, and tap 'Install'.
- **Uninstall:** Long-press an app icon on the home screen or app drawer, then drag it to 'Uninstall' or go to **Settings > Apps > See all apps** select the app, and tap 'Uninstall'.

Large Space for Storage






24GB (4+20)
RAM



128GB
ROM



1TB
Expand



GMS Certified Tablet

A large number of popular apps for your choice



Image: The Suicoey P80 tablet displaying various popular applications, indicating its GMS certification and access to a wide range of apps from the Play Store.

5.4 Storage Management

Your tablet comes with 128GB of internal storage, expandable up to 1TB via a MicroSD card.

- **Insert MicroSD Card:** Locate the card slot, gently insert the MicroSD card until it clicks into place.
- **Manage Storage:** Go to **Settings** > **Storage** to view usage and manage files.

8000mAh Battery & Fast Charging



17hrs
videos



14hrs
videos



720hrs
standby



Type C



Image: An illustration detailing the storage capabilities of the Suicoey P80 tablet, including 24GB RAM (4GB+20GB Expand), 128GB ROM, and 1TB expandable storage.

5.5 Camera Usage

Capture photos and videos using the tablet's front (5MP) and rear (13MP) cameras.

1. Open the Camera app.
2. Tap the shutter button to take a photo or switch to video mode to record.
3. Use the toggle to switch between front and rear cameras.

Seize your precious life moments



Image: The Suicoey P80 tablet highlighting its 13MP rear camera and 5MP front camera, accompanied by example photos taken with the device.

5.6 Battery Management

The 8000mAh battery provides extended usage. Charge using the included Type-C cable and charger.

- Connect the Type-C cable to the tablet's port and the charger to a power outlet.
- The tablet supports 18W fast charging.
- To optimize battery life, adjust screen brightness, close unused apps, and disable unnecessary connectivity features.

2 in 1 Tablet



Image: The Suicoey P80 tablet showcasing its 8000mAh battery and 18W fast charging capability, with icons indicating battery life for videos, gaming, and standby time.

5.7 Connectivity

The tablet supports 2.4G & 5G Wi-Fi and Bluetooth V5.0.

- **Wi-Fi:** Connect to wireless networks for internet access.
- **Bluetooth:** Connect to wireless headphones, speakers, keyboards, and mice.

6. MAINTENANCE

- **Cleaning:** Use a soft, lint-free cloth to clean the screen and body. Avoid abrasive cleaners.
- **Software Updates:** Regularly check for and install system updates to ensure optimal performance and security. Go to **Settings > System > System update**
- **Data Backup:** Periodically back up important data to cloud storage or an external device to prevent data loss.

7. TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Issue	Possible Solution
Tablet does not power on	Ensure the battery is charged. Connect the charger and try again. If unresponsive, press and hold the power button for 10-15 seconds.
Wi-Fi connection issues	Restart the tablet and your Wi-Fi router. Check Wi-Fi settings to ensure the correct network is selected and password entered.
Bluetooth accessories not pairing	Ensure the accessory is in pairing mode and fully charged. Restart Bluetooth on the tablet and try pairing again.
Slow performance	Close unused applications. Clear cache from apps. Check available storage space. Restart the tablet.
Screen is unresponsive	Restart the tablet. Ensure the screen is clean and free of debris.

8. SPECIFICATIONS

Feature	Detail
Model	P80
Operating System	Android 15
Screen Size	11 Inches
Screen Resolution	1280 x 800 pixels (IPS)
RAM	24GB (4GB + 20GB Expand)
Internal Storage	128GB
Expandable Storage	Up to 1TB (MicroSD card not included)
Rear Camera	13 MP
Front Camera	5 MP
Battery Capacity	8000mAh
Wireless Connectivity	2.4G & 5G WiFi, Bluetooth V5.0
Dimensions	11.3 x 7.8 x 2.7 inches
Weight	3.32 pounds

9. WARRANTY AND SUPPORT

Your Suicoey P80 tablet is covered by a limited warranty. Please refer to the warranty card included in your package for specific terms and conditions.

For technical support, troubleshooting assistance, or warranty claims, please contact Suicoey customer service through the contact information provided on the official Suicoey website or your purchase platform.