

- Manuals.plus /
- › Futanwei /
- › Instruction Manual for Futanwei Smartwatch Screen Protector for Fitonus G127

Futanwei for Fitonus G127 Screen Protector

Instruction Manual

Futanwei Smartwatch Screen Protector
Model: for Fitonus G127 Screen Protector

INTRODUCTION

This manual provides comprehensive instructions for the installation, use, and maintenance of your Futanwei Smartwatch Screen Protector, designed specifically for the Fitonus G127 Smartwatch. This product is a high-quality PET film screen protector engineered to offer superior protection, maintain touch sensitivity, and ensure crystal-clear display quality. Each package contains 5 screen protectors, providing multiple replacements for long-term use. The material is Thermoplastic Polyurethane (TPU), known for its durability and flexibility.



Image: A pack of five screen protectors displayed over a Fitonus G127 smartwatch, illustrating the product's purpose.

SETUP AND INSTALLATION

Follow these steps for a hassle-free and bubble-free installation of your screen protector:

1. **Clean the Smartwatch Screen:** Ensure the Fitonus G127 smartwatch screen is completely clean and free of dust, smudges, or fingerprints. Use a microfiber cloth to wipe the screen thoroughly.
2. **Align the Protector:** Carefully peel off the protective layer from the screen protector. Align the protector precisely with the edges of your smartwatch screen.
3. **Apply and Smooth:** Gently place the screen protector onto the smartwatch screen. Use a soft card or your finger to smooth out any air bubbles from the center outwards.
4. **Final Wipe:** Once applied, give the screen a final wipe with a clean cloth to remove any remaining smudges.



Image: A screen protector being carefully peeled and applied to the surface of a smartwatch, demonstrating the installation process.

Note: Immediately after application, you may observe small wavy patterns or residual air bubbles. These are normal and will naturally disappear within a few hours due to the self-healing properties of the film.

OPERATING AND FEATURES

The Futanwei Smartwatch Screen Protector is designed to enhance your user experience while providing robust protection:

- **High Touch Sensitivity:** The ultra-thin design ensures that the original touch sensitivity of your Fitonus G127 smartwatch screen is fully maintained. You can slide and interact with the screen comfortably and responsively.
- **Crystal Clear Display:** With 99% high transparency, the screen protector offers an ultra-clear view, preserving the bright and colorful image quality of your smartwatch display. It provides an original visual experience without distortion.

- **Oleophobic & Hydrophobic Coating:** An advanced coating protects against sweat, oil residue, and fingerprints, keeping your screen clean and clear.

High Responsive & Touch Friendly



TOUCH
SENSITIVE



ANTI
BUBBLES



FINGERPRINT
PROOF



Anti-Fingerprint



Image: A graphic illustrating the key features of the screen protector, including touch sensitivity, anti-bubble properties, fingerprint resistance, and an oleophobic coating, with a smartwatch in the background.

MAINTENANCE AND CARE

To ensure the longevity and optimal performance of your screen protector, follow these simple maintenance guidelines:

- **Cleaning:** Due to the oleophobic and hydrophobic coating, fingerprints and smudges are easily wiped away. Use a soft, lint-free cloth (like a microfiber cloth) to gently clean the screen. Avoid harsh chemicals or abrasive materials.
- **Protection:** While the protector is highly durable, avoid sharp objects that could scratch the film.
- **Replacement:** If the screen protector becomes heavily scratched or damaged, replace it with a new one from the 5-pack to maintain optimal screen protection and clarity.



Image: A close-up of a smartwatch with a screen protector perfectly applied, showing its seamless integration and clear display.

TROUBLESHOOTING

Here are solutions to common issues you might encounter:

- **Bubbles After Installation:**

If small air bubbles or wavy patterns appear immediately after application, do not worry. The PET film has self-healing properties. These bubbles will naturally disappear within a few hours (typically 12-24 hours). Avoid trying to forcefully push them out, as this may damage the adhesive.

- **Dust Under the Protector:**

If dust particles are trapped under the protector, it indicates the screen was not thoroughly cleaned before application. Carefully lift one corner of the protector, use a dust-removal sticker or tape to remove the dust, and reapply. If this is difficult, it may be best to use a new protector from the pack.

• **Protector Not Sticking Properly:**

Ensure the screen is completely dry and clean before application. If the edges are lifting, gently press them down. If the issue persists, the protector might be misaligned or damaged, and a new one should be used.

SPECIFICATIONS

Attribute	Detail
Compatible Model	Fitonus G127 Smartwatch (2.01 Inches) ONLY
Material	Thermoplastic Polyurethane (TPU)
Screen Size	2.01 Inches
Number of Items	5 Screen Protectors
Special Features	HD Clear, Anti-Fingerprint, Anti-Scratch, Bubble Free, Case Friendly, Oleophobic & Hydrophobic Coating, High Touch Sensitivity, Self-healing Film
Finish Type	Glossy
Product Dimensions	3 x 2 x 0.5 inches (Packaging)
Manufacturer	Futanwei

WARRANTY AND SUPPORT

While specific warranty details are not provided, Futanwei is committed to customer satisfaction. If you encounter any issues with your screen protectors, or have questions regarding installation or performance, please do not hesitate to contact the manufacturer or seller.

The manufacturer aims to resolve any problems quickly and efficiently to ensure you have a positive experience with their products.

For support, please refer to the contact information provided with your purchase or on the product's retail page.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D49DDZ63>

More documents and user manuals: <https://manuals.plus/>