K&F CONCEPT MS19

K&F Concept MS19 Magnetic Selfie Stick Tripod User Manual

Model: MS19 | Brand: K&F CONCEPT

1. Introduction

This manual provides detailed instructions for the safe and effective use of your K&F Concept MS19 Magnetic Selfie Stick Tripod. Please read this manual thoroughly before operating the device and retain it for future reference.

The K&F Concept MS19 is a versatile and portable accessory designed for mobile photography and videography. It functions as both a selfie stick and a tripod, featuring a magnetic phone mount and a detachable wireless remote control for enhanced convenience and flexibility.

2. What's in the Box

- K&F Concept Magnetic Selfie Stick Tripod (MS19) x 1
- Wireless Remote Control x 1
- User Manual x 1

3. Product Overview

Familiarize yourself with the main components and features of your K&F Concept MS19 Magnetic Selfie Stick Tripod.



Figure 1: Overview of the K&F Concept MS19 Magnetic Selfie Stick Tripod.

Key Features:

- **Compact & Portable Design:** The tripod is lightweight at 0.93 lbs (420g) and folds down to 11.81 inches (30cm) for easy transport.
- **Flexible Height & Angles:** Extends up to 63.8 inches (1620mm) with 7 sections of height adjustment. Offers 270° tilt and 360° rotation for diverse shooting angles.
- **Magnetic Sheet Compatibility:** Features a magnetic mount compatible with iPhone 12 series and newer (without case or with MagSafe case). An included adhesive magnetic ring allows compatibility with other phones.
- **Wireless Remote:** A detachable magnetic wireless remote control provides a 33-foot (10m) effective range for remote photography and video recording.
- **Stable and Solid Construction:** Features a wider fixing structure, non-slip silicone pads on the base, and a built-in shock-absorbing rubber ring in the foot tube for enhanced stability.

4. Setup Instructions

4.1 Unfolding the Tripod/Selfie Stick

1. Hold the handle firmly.
2. Gently pull the top section upwards to extend the stick. The tripod legs will automatically unfold at the

base.

3. To use as a selfie stick, keep the legs folded and extend the pole to the desired length.
4. To use as a tripod, ensure the legs are fully spread on a flat, stable surface.



Figure 2: The MS19 in its compact, folded state, demonstrating portability.

4.2 Attaching Your Phone

The MS19 features a magnetic mount for quick and secure phone attachment.

1. Ensure your phone is compatible with MagSafe (iPhone 12 series or newer, without a case or with a MagSafe-compatible case).
2. Align the back of your phone with the magnetic mount on the tripod head. The magnets will securely attach the phone.
3. For non-MagSafe phones, use the provided adhesive magnetic ring. Attach the ring to the center of your phone's back or phone case. Once attached, your phone can be magnetically mounted to the tripod head.



Figure 3: Magnetic phone attachment mechanism.

4.3 Pairing the Wireless Remote Control

1. The remote control is magnetically attached to the handle. Detach it by gently pulling it off.
2. Press and hold the button on the remote control for 3-5 seconds until the indicator light starts flashing, indicating it's in pairing mode.
3. On your smartphone, go to Bluetooth settings and search for available devices.
4. Select "K&F Remote" (or similar name) from the list to pair. The indicator light on the remote will stop flashing and remain solid once paired.
5. The remote is now ready to use for capturing photos or starting/stopping videos.



Figure 4: Detachable Bluetooth remote control for convenient shooting.

5. Operating Instructions

5.1 Adjusting Height

The MS19 offers 7 levels of height adjustment.

1. To extend the height, pull the telescopic pole upwards from the base.
2. To retract, push the pole downwards. Ensure all sections are securely locked at the desired height.



Figure 5: Height adjustment levels, up to 162cm (63.8 inches).

5.2 Adjusting Angles

The magnetic head allows for flexible positioning.

- **360° Rotation:** The magnetic phone mount can be rotated 360 degrees horizontally to switch between portrait and landscape modes or to adjust the horizontal angle.
- **270° Tilt:** The neck of the mount can be tilted up to 270 degrees vertically to achieve various upward or downward shooting angles.



Figure 6: Adjustable angles for versatile shooting.

5.3 Using the Wireless Remote

Once paired, simply press the button on the remote control to trigger your phone's camera shutter. This allows for hands-free photography and videography from a distance.

6. Maintenance

- Clean the tripod and remote with a soft, dry cloth. Do not use abrasive cleaners or solvents.
- Avoid exposing the device to extreme temperatures, moisture, or direct sunlight for prolonged periods.
- Ensure the magnetic mount and phone are free of debris before attachment to maintain a secure connection.
- When not in use, fold the tripod to its compact size and store it in a dry, safe place.

7. Troubleshooting

7.1 Remote Control Not Pairing

- Ensure the remote control has sufficient battery power. The remote uses 1 Lithium Metal battery (included).
- Make sure Bluetooth is enabled on your smartphone.
- Restart the remote control by turning it off and on again, then re-attempt pairing.
- If previously paired, try unpairing and re-pairing the device in your phone's Bluetooth settings.

7.2 Phone Not Attaching Securely to Magnetic Mount

- Verify your phone is MagSafe compatible or has the adhesive magnetic ring properly attached.
- Ensure there are no obstructions (e.g., thick phone cases not designed for MagSafe) between the phone and the magnetic mount.

- Clean both the phone's back/case and the magnetic mount surface to remove any dust or debris.

7.3 Tripod Instability

- Ensure the tripod legs are fully extended and spread on a flat, stable surface.
- Avoid placing the tripod on uneven or slippery ground.
- Do not overload the tripod with accessories beyond its intended capacity.

8. Specifications

Feature	Specification
Model Number	MS19
Brand	K&F CONCEPT
Material	Aluminum
Folded Size	11.81 inches (30 cm)
Maximum Height	63.8 inches (162 cm)
Minimum Height	11.81 inches (30 cm)
Item Weight	14 ounces (398 grams)
Remote Control Range	Up to 33 feet (10 meters)
Battery (Remote)	1 Lithium Metal battery (included)
Compatible Devices	Smartphones, iPhone 16 Pro Max/15/14/13/12 Series, and other phones with magnetic function or adhesive magnetic ring.

9. Warranty and Support

K&F Concept products are designed for reliability and performance. For warranty information, technical support, or service inquiries, please refer to the official K&F Concept website or contact their customer service directly. Please retain your proof of purchase for warranty claims.

© 2025 K&F CONCEPT. All rights reserved.