

[Manuals.plus](#) /

› [CrossBeats](#) /

› CrossBeats Everest 2.0 Smart Watch User Manual

CrossBeats CB-Everest-Black-2.0

CrossBeats Everest 2.0 Smart Watch User Manual

Model: CB-Everest-Black-2.0

1. PRODUCT OVERVIEW

The CrossBeats Everest 2.0 Smart Watch is a rugged and feature-rich wearable designed for active lifestyles. It features a vibrant 1.43-inch True AMOLED display, Bluetooth calling capabilities, and comprehensive health monitoring. Built to withstand challenging environments, it offers extended battery life and a wide array of sports tracking modes.



Image: Front view of the CrossBeats Everest 2.0 Smart Watch, showcasing its round display and rugged design.

2. SAFETY INFORMATION

- Do not attempt to disassemble or modify the device. This may void the warranty and cause damage.
- Keep the device away from extreme temperatures, direct sunlight, and strong magnetic fields.
- Avoid exposing the watch to corrosive chemicals or strong detergents. Clean with a soft, dry cloth.
- Ensure the charging contacts are clean and dry before charging to prevent corrosion or short circuits.
- Consult a medical professional before starting any new exercise regimen or if you have pre-existing health conditions, as the health data provided by the watch is for reference only and not for medical diagnosis.

3. SETUP

3.1. Package Contents

Verify that all items are present in the package:

- CrossBeats Everest 2.0 Smart Watch
- Charging Cable
- Warranty Card
- Instruction Manual (this document)

3.2. Charging the Device

Before first use, fully charge the smart watch. Connect the magnetic charging cable to the charging contacts on the back of the watch and plug the USB end into a compatible USB power adapter (not included) or computer USB port. A full charge takes approximately 90 minutes.



Image: Illustration showing the CrossBeats Everest 2.0 Smart Watch being charged, highlighting its battery life of up to 15 days.

3.3. Pairing with Your Smartphone

1. **Download the App:** Search for the official CrossBeats companion app on your smartphone's app store (Google

Play Store for Android, Apple App Store for iOS). Install the app.

2. **Enable Bluetooth:** Ensure Bluetooth is enabled on your smartphone.
3. **Open the App:** Launch the CrossBeats app and follow the on-screen instructions to create an account or log in.
4. **Add Device:** In the app, navigate to the "Add Device" or "Pair Device" section. The app will search for nearby CrossBeats Everest 2.0 devices.
5. **Connect:** Select your watch from the list of discovered devices. Confirm the pairing request on both your watch and smartphone if prompted.

Once paired, the watch will synchronize time and data with your smartphone, and you can begin customizing settings and receiving notifications.

4. OPERATING THE SMART WATCH

4.1. Basic Navigation

- **Touchscreen:** Swipe left/right, up/down to navigate through menus and widgets. Tap to select items.
- **Side Buttons:** The watch features multiple physical buttons. Typically, one button serves as a power/home button, while others may be customizable shortcuts for sports modes or specific functions. Refer to the on-screen prompts for specific button assignments.

4.2. Bluetooth Calling

With Bluetooth 5.3 connectivity, the Everest 2.0 allows you to make and receive calls directly from your wrist when connected to your smartphone. Ensure the watch is within Bluetooth range of your phone.

- **Answering Calls:** When a call comes in, tap the green answer icon on the watch screen.
- **Making Calls:** Access the dialer or contact list on the watch to initiate a call.



Image: A collage highlighting key features of the CrossBeats Everest 2.0, including its 1.43-inch AMOLED display, Bluetooth calling capability, extended battery life, built-in torch, and advanced health sensors.

4.3. Sports Modes

The watch supports over 100 sports modes to track various physical activities. Select your desired activity from the sports menu to begin tracking metrics such as duration, calories burned, heart rate, and distance.

Unleash Limitless Adventures

100+ Sports Modes



Image: The CrossBeats Everest 2.0 Smart Watch showcasing its extensive range of over 100 sports modes, with a visual of a snowboarder.

4.4. Health Monitoring

The Everest 2.0 is equipped with advanced bio-sensors to monitor your health metrics. Access these features through the watch interface or the companion app:

- **Heart Rate (HR):** Continuous or on-demand heart rate monitoring.
- **Blood Oxygen (SpO2):** Measure your blood oxygen saturation levels.
- **Sleep Tracking:** Monitors sleep patterns, including deep sleep, light sleep, and awake times.
- **Steps and Calories:** Tracks daily steps taken and estimated calories burned.

4.5. Flashlight Function

The watch includes a built-in flashlight feature for convenience in low-light conditions. Activate it through the quick settings menu or a designated button, if available.



Image: The CrossBeats Everest 2.0 Smart Watch with its flashlight feature illuminated, demonstrating its utility in dark environments.

4.6. Customizing Watch Faces

The Everest 2.0 offers over 200 dial options to personalize your watch face. You can change watch faces directly on the device by long-pressing the screen or through the companion app for a wider selection.

200+

Dials Options



Image: The CrossBeats Everest 2.0 Smart Watch displaying various customizable dial options, indicating over 200 choices available.

5. MAINTENANCE

5.1. Cleaning the Watch

Regularly clean your watch to maintain its appearance and functionality. Use a soft, lint-free cloth to wipe the screen and body. For stubborn dirt, slightly dampen the cloth with water. Avoid using abrasive materials or harsh chemicals.

5.2. Water and Dust Resistance (IP68)

The CrossBeats Everest 2.0 is IP68 rated, meaning it is resistant to dust and can withstand immersion in water up to 1.5 meters for 30 minutes. While it is designed to be rugged, avoid prolonged exposure to water, hot water, or steam. Dry the watch thoroughly after exposure to water.

Rugged. Sturdy. Dependable.

Water and dust proof



Image: The CrossBeats Everest 2.0 Smart Watch shown in a rugged, snowy environment, emphasizing its IP68 water and dust resistance.

5.3. Battery Care

To maximize battery lifespan, avoid fully discharging the battery frequently. Charge the watch when the battery level is low. Store the watch in a cool, dry place if not used for extended periods.

6. TROUBLESHOOTING

Problem	Possible Solution
Watch does not turn on.	Ensure the watch is fully charged. Connect it to the charger for at least 10 minutes.

Problem	Possible Solution
Cannot pair with smartphone.	Ensure Bluetooth is enabled on your phone and the watch. Make sure the watch is in pairing mode. Restart both the watch and the smartphone. Clear Bluetooth cache on your phone (Android) or forget the device and re-pair (iOS).
Inaccurate health data.	Ensure the watch is worn snugly on your wrist, not too tight or too loose. Clean the sensor on the back of the watch.
Short battery life.	Reduce screen brightness. Disable Always-On Display if not needed. Limit frequent heart rate monitoring or GPS usage. Ensure background app refresh is optimized.

7. SPECIFICATIONS

Feature	Detail
Brand	CrossBeats
Model Name	Everest 2.0 Black
Model Number	CB-Everest-Black-2.0
Display	1.43" True AMOLED, 466x466 pixels, 850 nits peak brightness, Always ON Display
Connectivity	Bluetooth 5.3
Battery Capacity	320 mAh
Battery Life	Up to 15 days (typical use), 30 days (standby)
Charging Time	Approx. 90 minutes
Water Resistance	IP68 (Dust and Water Resistant)
Sports Modes	100+
Health Monitoring	Heart Rate, SpO2, Sleep Tracking, Steps, Calories
Dimensions (LxWxH)	2.4 x 8 x 19 cm
Item Weight	200 g
Included Components	Smart Watch, Charging Cable, Warranty Card, Instruction Manual

8. WARRANTY AND SUPPORT

8.1. Warranty Information

The CrossBeats Everest 2.0 Smart Watch comes with a **12-month warranty** from the date of purchase. This warranty covers manufacturing defects. Please retain your purchase receipt as proof of purchase. The warranty does not cover damage caused by misuse, accidents, unauthorized repairs, or normal wear and tear.

For detailed warranty terms and conditions, please refer to the Warranty Card included in your package.

8.2. Customer Support

For any questions, technical assistance, or warranty claims, please contact CrossBeats customer support:

- **Phone:** +91 8050056565
- **Email:** support@crossbeats.com
- **Manufacturer:** SELLBRITE DIGITAL LLP, Ground Floor Brigade Towers 135 Brigade Road Bangalore India - 560025

9. IMPORTANT NOTE ON VIDEOS

While product videos may be available online, this manual does not include embedded video content due to the format of the provided video links, which appear to be static image thumbnails rather than playable video files (e.g., .m3u8 or .mp4). For official product videos, please visit the CrossBeats official website or their official channels on video platforms.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does my CrossBeats Everest 2.0 smart watch only vibrate and not ring for incoming calls?

If your CrossBeats Everest 2.0 is only vibrating and not ringing during incoming calls, it is likely due to the sound settings on the watch or the Bluetooth connection status. Please try the following...

[Read full answer](#)