

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Activplay Lower Kit 1

ACTIVPLAY Modular Jungle Gym Set - User Manual

Model: Lower Kit 1

INTRODUCTION

Welcome to the ACTIVPLAY Modular Jungle Gym Set, Lower Kit 1. This outdoor playset is designed to provide a safe, engaging, and customizable play experience for children. Featuring a robust, rust-resistant steel frame, adjustable play platforms, and safety-focused design elements like no-pinch joints, this playset encourages active play and imaginative adventures in your backyard.



Image: The complete ACTIVPLAY Modular Jungle Gym Set, Lower Kit 1, showcasing its various play elements including the jungle gym structure, slide, monkey bars, and swing set.

SAFETY INFORMATION

Your child's safety is our utmost priority. Please read and adhere to all safety guidelines before assembly and use.

- **Adult Supervision Required:** Always ensure children are supervised by a responsible adult while using the playset.

- **Weight Limit:** Each adjustable play platform supports up to 105 lbs. The overall playset has a maximum weight recommendation of 100 pounds per user.
- **No Pinch Joints:** The design incorporates no-pinch covers on all connection joints to prevent accidental pinching during play.
- **Secure Installation:** Ensure all components are securely fastened according to the assembly instructions to prevent instability.
- **Clearance Area:** Maintain a safe clearance area around the playset, free from obstacles, fences, or other structures.
- **Surface:** Install the playset on a level surface with appropriate shock-absorbing material (e.g., wood chips, sand, rubber mulch) to minimize injury from falls.
- **Regular Inspection:** Periodically inspect the playset for loose bolts, worn parts, or signs of damage. Replace or repair as necessary.



Image: Visual representation of key safety features including rust-resistant steel, no-pinch joints, reinforced slide support, and the weight capacity of the platforms.

COMPONENTS LIST

The ACTIVPLAY Modular Jungle Gym Set, Lower Kit 1, includes the following main components:

1 x Jungle Gym Base: The core modular structure.

1 x Monkey Bars: Overhead climbing element.


1 x Slide: Green wave slide for descent.

1 x Swing Set: Frame with two swings.

8 x Platforms: Adjustable, textured platforms for climbing and resting.

BASECAMP KIT + MONKEY BARS

INCLUDES:



1-Jungle Gym Base



1-Monkey Bars



1-Slide



1-Swing Set



8-Platforms

Image: An illustration detailing the main components included in the ACTIVPLAY Modular Jungle Gym Set, Lower Kit 1.

SETUP AND ASSEMBLY

Assembly of the ACTIVPLAY Modular Jungle Gym Set requires two adults and basic tools (not included). Please follow the step-by-step instructions provided in the separate assembly manual for detailed guidance.

- 1. Unpack and Verify:** Carefully unpack all components and verify against the components list.
- 2. Prepare the Area:** Choose a level outdoor area with adequate clearance.
- 3. Assemble the Jungle Gym Base:** Connect the main steel frame components, ensuring all no-pinch joints are correctly aligned and secured.
- 4. Attach Monkey Bars:** Securely fasten the monkey bar section to the top of the jungle gym base.
- 5. Install Slide:** Mount the slide to the designated opening on the jungle gym structure, ensuring the reinforced slide support is in place.
- 6. Erect Swing Set:** Assemble the swing set frame and attach it to the main structure. Install the swings with their encased chains.
- 7. Position Platforms:** Place the 8 adjustable platforms onto the jungle gym frame at desired heights. The textured grooves provide traction.
- 8. Final Inspection:** Before first use, double-check all bolts, nuts, and connections to ensure they are tight and secure.




Image: Dimensional overview of the assembled playset, indicating its overall footprint and height for planning installation space.

OPERATING INSTRUCTIONS

The ACTIVPLAY Modular Jungle Gym Set is designed for active outdoor play.

- **Climbing:** Children can climb the jungle gym structure using the horizontal and vertical bars.
- **Platform Use:** The 8 adjustable platforms can be moved to different locations on the jungle gym to create varied climbing paths and resting spots. Ensure platforms are securely seated in the grooves before use.
- **Sliding:** Use the slide feet-first, one child at a time.
- **Swinging:** The swing set accommodates two users. Ensure proper grip on the encased chains.
- **Monkey Bars:** Children can use the monkey bars for overhead climbing and swinging.



Image: Children actively using the slide and swing components of the playset.



CUSTOMIZABLE FOR EVERY AGE

Image: An adult and child demonstrating the adjustability of the platforms, highlighting the "Customizable for Every Age" feature.

MAINTENANCE

Regular maintenance will extend the life and ensure the safety of your ACTIVPLAY Modular Jungle Gym Set.

- **Cleaning:** Clean the playset periodically with mild soap and water. Avoid abrasive cleaners.
- **Rust Prevention:** The playset is crafted from rust-resistant powder-coated steel. However, inspect for any scratches or chips in the coating and touch up with rust-inhibiting paint if necessary to prevent corrosion.
- **Joint Inspection:** Regularly check all connection joints and bolts for tightness. Re-tighten any loose fasteners.
- **Swing Chains:** The swing chains are encased for safety and grip. Inspect the chains and swing seats for wear or damage. Replace if necessary.
- **Platform Condition:** Check the adjustable platforms for cracks or excessive wear, especially the textured grooves.
- **Ground Anchoring:** Ensure the playset remains securely anchored to the ground, especially after heavy winds or

rain.



ENCASED CHAINS FOR ULTIMATE GRIP AND SAFETY

Image: Detail of the swing chains, showing the protective encasing designed for enhanced grip and safety.

TROUBLESHOOTING

If you encounter any issues with your ACTIVPLAY Modular Jungle Gym Set, consider the following:

- **Playset Wobbles:** Ensure the playset is on a level surface. Check all bolts and connections for tightness. Re-tighten as needed.
- **Difficulty Adjusting Platforms:** Ensure the platforms are aligned correctly with the grooves on the frame. Clean any debris from the grooves.
- **Squeaking Noises:** Apply a small amount of silicone lubricant to moving parts or joints if squeaking occurs.
- **Missing Parts:** If any parts were missing upon delivery, contact customer support immediately with your purchase details.

SPECIFICATIONS

Brand	Activplay
Model	Lower Kit 1
Material	Alloy Steel (Powder-Coated, Rust-Resistant)
Color	Green
Maximum Weight Recommendation	100 Pounds (per user)
Assembly Required	Yes
Dimensions (Approx. Assembled)	13.2 ft (Width) x 7.6 ft (Height) x 6.2 ft (Depth - Jungle Gym) / 7 ft (Width - Swing Set)
Platform Weight Capacity	105 lbs per platform

WARRANTY AND SUPPORT

For warranty information, replacement parts, or further assistance, please contact Activplay customer support. Refer to your purchase receipt for specific warranty terms and contact details.

Manufacturer: Activplay

Seller: Skywalker Holdings (as per product information)

© 2024 Activplay. All rights reserved.

For more information, visit www.activplay.com