

[Manuals.plus](#) /

› [ROBUD](#) /

› ROBUD Wooden Baby Doll Crib Instruction Manual - Model RB-WRP06

ROBUD RB-WRP06

ROBUD Wooden Baby Doll Crib Instruction Manual

Model: RB-WRP06

Brand: ROBUD

1. PRODUCT OVERVIEW

The ROBUD Wooden Baby Doll Crib is a delightful accessory designed for dolls up to 18 inches. Crafted from natural wood, this crib offers durability and encourages imaginative role-play. It comes complete with a pillow, sheet, and quilt, providing a cozy sleeping environment for your child's doll.

Key Features:

- **Doll Compatibility:** Designed for dolls up to 18 inches.
- **Natural Wood Construction:** Ensures durability for extended play.
- **Complete Bedding Set:** Includes a pillow, sheet, and quilt for enhanced play experience.
- **Easy Assembly:** Simple 3-step assembly process, typically completed in 5-10 minutes.
- **Educational Value:** Encourages role-play, language skills, and coordination.



Image 1: The ROBUD Wooden Baby Doll Crib, featuring its white wooden frame and floral bedding.

Product Dimensions:



Baby Dolls

For 18inch/45cm Baby Doll



Image 2: A visual representation of the doll crib's dimensions: 21.1 inches (length), 13.4 inches (width), and 12.6 inches (height).

Specification	Detail
Product Dimensions	21.26 x 13.38 x 12.6 inches
Item Weight	6.93 pounds
Item Model Number	RB-WRP06
Manufacturer Recommended Age	3 years and up
Release Date	August 23, 2023

2. SAFETY INFORMATION

Please read and follow all safety instructions carefully to ensure safe use of the product.

- **Choking Hazard:** Contains small parts. Not suitable for children under 3 years.
- **Adult Assembly Required:** This toy must be assembled by an adult.
- **Packaging Safety:** Keep the packaging items such as plastic film or bags away from babies and children to avoid danger of suffocation.
- **Fire Safety:** Keep the product away from naked flame or direct heat sources.
- **Environmental Conditions:** Keep away from fire, substances flammable, and humid environments to prevent damage.

3. ASSEMBLY INSTRUCTIONS

The ROBUD Wooden Baby Doll Crib is designed for quick and easy assembly. All necessary hardware and tools are included.

What's in the Box:

- Wooden crib panels (various pieces)
- Mattress, pillow, and quilt
- 8 screws (F)
- 1 Allen wrench

Assembly Steps:

1. Attach the two end panels (A and B) to the side panels (C and E) using the provided screws.
2. Insert the bottom panel (D) into the grooves of the assembled frame.
3. Secure the remaining side panels.
4. Place the mattress, pillow, and quilt inside the assembled crib.

For a visual guide, please refer to the assembly instructions provided in the packaging or the video below.

Video 1: A detailed review showing the unboxing and assembly instructions for the doll crib.

4. OPERATING INSTRUCTIONS

The doll crib is designed for interactive play, allowing children to care for their dolls. Its rocking feature provides a realistic experience for putting dolls to sleep.

Usage:

- Place your doll (up to 18 inches) gently into the crib.
- Arrange the included mattress, pillow, and quilt for comfort.
- Gently rock the crib to simulate soothing a baby.




Image 3: A doll comfortably resting in the crib with its floral bedding.



With comforter and pillow



Heart-shaped hollow
(easy to be moved)



Smooth corners



Retro patterns

Image 4: A child engaging in imaginative play with the ROBUD Wooden Baby Doll Crib.

Video 2: An official ROBUD video showcasing the features and use of the Wooden Baby Doll Crib.

5. MAINTENANCE

To ensure the longevity and cleanliness of your ROBUD Wooden Baby Doll Crib, follow these simple maintenance guidelines:

- **Cleaning:** Wipe the wooden surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- **Bedding Care:** The fabric bedding (mattress, pillow, quilt) can be spot cleaned or hand washed with mild soap and water. Air dry thoroughly.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Tighten if necessary to maintain stability.

- **Storage:** Store the crib in a dry environment away from direct sunlight or extreme temperatures to prevent warping or fading of the wood.

6. TROUBLESHOOTING

If you encounter any issues with your doll crib, please refer to the following common solutions:

- **Crib is Wobbly:** Check all assembly screws. Ensure they are fully tightened using the provided Allen wrench.
- **Parts Missing:** If any parts were missing upon arrival, please contact customer support immediately.
- **Damage During Shipping:** If the product arrived damaged, please contact customer support with details and photographic evidence.

7. CUSTOMER SUPPORT

For any questions, concerns, or assistance, please contact ROBUD customer service:

- **Email:** shop@robud.com
- **Manufacturer:** ROBUD

Please provide your model number (RB-WRP06) and a detailed description of your inquiry for faster service.

© 2023 ROBUD. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D49S658M>

More documents and user manuals: <https://manuals.plus/>