

## BLU G0930WW

# BLU G73L Smartphone User Manual

Model: G0930WW

## INTRODUCTION

---

Welcome to the user manual for your new BLU G73L smartphone. This guide provides essential information to help you set up, operate, maintain, and troubleshoot your device. Please read this manual carefully to ensure optimal performance and longevity of your smartphone.

## SAFETY INFORMATION

---

Always follow basic safety precautions when using your BLU G73L to reduce the risk of fire, electric shock, and injury.

- Do not expose the device to extreme temperatures or direct sunlight.
- Avoid contact with liquids.
- Use only BLU-approved chargers and accessories.
- Do not attempt to disassemble or repair the device yourself.
- Dispose of batteries and the device according to local regulations.

## SETUP

---

### What's in the Box

- BLU G73L Smartphone
- USB Cable

*Note: Contents may vary by region or retailer.*

### Inserting SIM Card and MicroSD Card

The BLU G73L supports dual SIM cards and a MicroSD card for expandable storage up to 64GB.

1. Locate the SIM/MicroSD card tray on the side of the phone.
2. Insert the SIM ejector tool (if provided) or a small paperclip into the small hole next to the tray to eject it.
3. Carefully pull out the tray.
4. Place your Nano-SIM card(s) and MicroSD card into the designated slots on the tray, ensuring the gold contacts face down.
5. Gently push the tray back into the phone until it clicks into place.



Front and back view of the BLU G73L smartphone, showing its design and camera module.

## Charging the Battery

Your BLU G73L comes with a built-in 5000mAh Lithium Ion battery.

1. Connect the USB Type-C cable to the charging port at the bottom of the phone.
2. Connect the other end of the USB cable to a compatible power adapter and plug it into a power outlet.
3. Allow the phone to charge fully before first use. A charging indicator will appear on the screen.



Angled view of the BLU G73L smartphone, highlighting its design and the included protective case.

## Powering On/Off

- To power on: Press and hold the Power button until the BLU logo appears.
- To power off: Press and hold the Power button, then select "Power off" from the options on the screen.

## OPERATING YOUR BLU G73L

---

### Basic Navigation

The BLU G73L runs on Android 13 (Go Edition).

- **Touch Screen:** Tap, swipe, pinch-to-zoom to interact with the display.
- **Home Screen:** Your central hub for apps and widgets.
- **Notifications Panel:** Swipe down from the top of the screen to access quick settings and notifications.

- **Navigation Bar:** Use the on-screen buttons (Back, Home, Recent Apps) or gesture navigation (if enabled) to move between screens and applications.

## Connectivity

Your device supports various connectivity options:

- **Wi-Fi:** Connect to wireless networks for internet access. Go to *Settings > Network & internet > Internet*
- **Bluetooth:** Pair with other Bluetooth devices like headphones or speakers. Go to *Settings > Connected devices > Connection preferences > Bluetooth*.
- **Mobile Data:** Access the internet via your cellular network. Ensure your SIM card is active and mobile data is enabled in *Settings > Network & internet > SIMs*

## Camera Usage

The BLU G73L features a 13MP triple main camera with flash and an 8MP selfie camera.

1. Open the Camera app from your home screen or app drawer.
2. Select your desired mode (Photo, Video, Portrait, etc.).
3. Tap the shutter button to capture a photo or start/stop video recording.
4. Use the front/rear camera switch icon to change cameras.



Rear view of the BLU G73L smartphone, showcasing the triple camera setup and the texture of the protective case.

## Storage Management

The device has 64GB internal memory, expandable up to 64GB via MicroSD.

- Regularly check your storage usage in *Settings* > *Storage*.
- Move large files (photos, videos) to your MicroSD card to free up internal space.
- Uninstall unused applications.

## MAINTENANCE

---

## Software Updates

Keep your device's software up to date to ensure optimal performance and security.

- Go to *Settings > System > System update* to check for and install available updates.
- Ensure your phone is connected to Wi-Fi and has sufficient battery charge before performing an update.

## Cleaning Your Device

To clean your BLU G73L:

- Power off the device.
- Use a soft, lint-free cloth to wipe the screen and body.
- Avoid using harsh chemicals or abrasive materials.



Front view of the BLU G73L smartphone, showing the display and the protective case.

## Battery Care

To maximize battery life:

- Avoid fully discharging the battery frequently.
- Do not leave the phone charging for extended periods after it's full.
- Reduce screen brightness and disable unnecessary features like GPS or Bluetooth when not in use.

## TROUBLESHOOTING

---

<b>Problem</b>	<b>Solution</b>
Phone not turning on	Ensure the battery is charged. Press and hold the Power button for at least 10 seconds.
Apps freezing or crashing	Close the app and reopen it. Clear the app's cache (Settings > Apps > [App Name] > Storage & cache > Clear cache). Restart the phone.
Poor Wi-Fi connection	Restart your Wi-Fi router. Forget the network on your phone and reconnect. Ensure you are within range of the Wi-Fi signal.
Battery draining quickly	Reduce screen brightness. Close background apps. Disable unnecessary features like GPS or Bluetooth. Check battery usage in Settings to identify power-hungry apps.
Cannot make/receive calls or texts	Check if your SIM card is properly inserted. Ensure you have network signal. Contact your mobile carrier for service issues.



A hand holding the BLU G73L smartphone, demonstrating its ergonomic design and size.

## SPECIFICATIONS

---

Feature	Detail
Model	BLU G73L (G0930WW)
Operating System	Android 13 (Go Edition)
Display	6.8" HD+ Infinity Display (720 x 1600 Resolution, 258ppi)
Internal Storage	64GB
RAM	2GB + 2GB Xtra RAM
Expandable Storage	MicroSD up to 64GB
Rear Camera	13MP Triple Main with Flash
Front Camera	8MP Selfie Camera
Video Capture	1080p@30fps
Battery	5000mAh Lithium Ion (included)
Connectivity	Bluetooth 4.1, Wi-Fi (a/b/g/n), USB Type-C
Network Bands	GSM: Quad Bands   3G: 850/900/1700/1900/2100   LTE: 2/3/4/5/7/12/17/28AB/38/66/71
Dimensions	9.25 x 6.75 x 3.25 inches
Weight	1 pound

## WARRANTY INFORMATION

---

For detailed warranty information regarding your BLU G73L smartphone, please refer to the warranty card included in your product packaging or visit the official BLU website. Warranty terms and conditions may vary by region.

## SUPPORT

---

If you encounter issues not covered in this manual or require further assistance, please contact BLU customer support.

- **Online Support:** Visit the official BLU website for FAQs, support resources, and contact options.
- **Service Centers:** Information on authorized service centers can be found on the BLU website.

*Please have your device model number (G0930WW) and serial number ready when contacting support.*



[\[pdf\]](#) User Manual Instructions Guide

G73L G0930WW Quick Guide Multi V01 docx MORLAB UM BLU Products Inc BLUG73L YHLBLUG73L blug73l

G73L Quick Guide Gua Rpada Gua Rpido Guide Rapide ATTENTION o For instructions or any questions pertaining to phone usage, please click on the BLU page by visiting the following address: [manuals.bluproducts.com](http://manuals.bluproducts.com) o Para obtener instrucciones o preguntas relacionadas con el uso del telefono, por...

lang:en score:27 filesize: 381.3 K page\_count: 33 document date: 2023-12-14