

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [ZONEKIZ](#) /

› [ZONEKIZ Kids Storage Unit with 6 Removable Fabric Bins - Instruction Manual](#)

## ZONEKIZ 311-059V80GN

# ZONEKIZ Kids Storage Unit with 6 Removable Fabric Bins

Model: 311-059V80GN

## 1. INTRODUCTION

This instruction manual provides essential information for the safe assembly, operation, and maintenance of your ZONEKIZ Kids Storage Unit. Please read this manual thoroughly before assembly and retain it for future reference. This storage unit is designed to help organize children's rooms, playrooms, or nurseries, offering a practical solution for storing toys, books, and other items.

The unit features a sturdy frame and six removable non-woven fabric bins, promoting organization and tidiness. It is suitable for children aged 3-8 years.



Image 1: Fully assembled ZONEKIZ Kids Storage Unit with various toys and books.

## 2. SAFETY INFORMATION

Your safety and the safety of your child are paramount. Please adhere to the following safety guidelines:

- The storage unit is constructed from 12mm thick MDF panels and is EN71 certified, meeting strict safety standards for children's toys.
- Ensure all components are securely fastened during assembly. Regularly check all screws and connections to ensure they remain tight.
- Do not allow children to climb on the unit, as this may cause it to tip over, leading to injury.
- Place the unit on a flat, stable surface to prevent wobbling or tipping.
- Keep small parts and assembly hardware out of reach of children during assembly.
- The maximum weight capacity for the entire unit is 5 kg. Do not overload the bins or shelves.



Image 2: Visual representation of the unit's safety features and recommended age range (3-8 years).

### 3. PACKAGE CONTENTS

Before beginning assembly, please verify that all parts are present and undamaged. If any parts are missing or damaged, do not proceed with assembly and contact customer support.

- Main frame components (MDF panels)
- 6 removable non-woven fabric bins (3 small, 2 medium, 1 large)
- Assembly hardware (screws, dowels, etc.)
- Instruction manual (this document)



Image 3: The product is delivered in one package.

#### 4. SETUP AND ASSEMBLY

Assembly requires basic tools, typically a screwdriver (not included). Follow these general steps for assembly:

1. Unpack all components and lay them out on a clean, soft surface to prevent scratches.
2. Identify each part using the provided parts list (if applicable, refer to diagrams).
3. Attach the side panels to the back panel or connecting bars using the provided screws and dowels.  
Ensure all connections are firm.
4. Secure the shelves into place between the side panels.
5. Once the frame is assembled, insert the fabric bins into their designated slots.
6. Double-check all screws and connections to ensure the unit is stable and secure before use.



Image 4: Detailed dimensions of the storage unit and its various bins.

## 5. OPERATING INSTRUCTIONS

The ZONEKIZ Kids Storage Unit is designed for easy use and to encourage children's organization skills.

- **Storage:** Place toys, books, art supplies, and other children's items into the fabric bins. The different bin sizes (3 small, 2 medium, 1 large) allow for versatile storage of various items.
- **Accessibility:** The open design and low height make it easy for children to access and put away their belongings independently.
- **Removable Bins:** The fabric bins are removable, allowing children to take them out for play and then easily return them to the unit.

# UTILISATION POLYVALENTE

Pépinière



Salon



Salle de jeux



Salle de classe



Image 5: The unit offers ample storage space for toys, books, and other items.



Image 6: The fabric bins are easily removable for convenience.

## 6. MAINTENANCE AND CARE

Proper care will extend the life of your storage unit.

- **Cleaning the Frame:** The MDF frame has an easy-to-clean painted surface. Wipe it with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals.
- **Cleaning the Bins:** The non-woven fabric bins can be spot cleaned with a mild detergent and damp cloth. Allow them to air dry completely before returning them to the unit. Do not machine wash or tumble dry.
- **Regular Checks:** Periodically inspect all screws and connections to ensure they are tight. Tighten any loose hardware to maintain stability.
- **Avoid Moisture:** Keep the unit away from excessive moisture or direct sunlight to prevent damage to the wood and fabric.

## 7. TROUBLESHOOTING

If you encounter any issues with your ZONEKIZ Kids Storage Unit, refer to the following common solutions:

- **Unit is Wobbly:** Check all assembly screws and ensure they are fully tightened. Make sure the unit is placed on a level surface.
- **Bins are Damaged:** If fabric bins are torn or significantly damaged, they may need to be replaced. Contact customer support for assistance.
- **Missing Parts:** If you discover missing parts during assembly, do not attempt to force assembly. Contact customer support immediately for replacement parts.

## 8. SPECIFICATIONS

Feature	Specification
Brand	ZONEKIZ
Model Number	311-059V80GN
Color	Green
Overall Dimensions (L x W x H)	63 cm x 30 cm x 66 cm
Small Bin Dimensions (L x W x H)	19 cm x 23 cm x 12 cm (x3)
Medium Bin Dimensions (L x W x H)	29 cm x 23 cm x 12 cm (x2)
Large Bin Dimensions (L x W x H)	59 cm x 25 cm x 23 cm (x1)
Material	Engineered Wood (MDF), Non-woven Fabric
Item Weight	5 Kilograms
Maximum Weight Capacity	5 Kilograms
Recommended Age	3-8 years
Certifications	EN71

## 9. WARRANTY AND SUPPORT

For warranty information, replacement parts, or any other support inquiries, please contact the retailer or manufacturer directly. Keep your purchase receipt as proof of purchase.

Manufacturer: ZONEKIZ