

BOTEX 4656546

User Manual: BOTEX Apple Shape Net Fruits & Vegetables Basket

Model: 4656546

1. PRODUCT OVERVIEW

The BOTEX Apple Shape Net Fruits & Vegetables Basket is designed for convenient and hygienic storage of fruits and vegetables in your kitchen. Its unique apple shape and mesh construction allow for air circulation, helping to keep produce fresh while protecting it from insects.



Image 1.1: The BOTEX Apple Shape Net Fruits & Vegetables Basket, showcasing its design and capacity for holding various fruits.

2. PACKAGE CONTENTS

Upon unboxing, please ensure all components are present and undamaged.

- 1 x BOTEX Apple Shape Net Fruits & Vegetables Basket (Base)
- 1 x Apple Shape Net Cover

The basket is pre-assembled and ready for immediate use.

3. SETUP

The BOTEX Apple Shape Net Fruits & Vegetables Basket requires no assembly. It is designed for countertop placement.

1. **Unpacking:** Carefully remove the basket from its packaging.
2. **Initial Cleaning:** Before first use, wash the basket and its net cover with mild soap and water. Rinse thoroughly and

dry completely. Refer to the "Maintenance" section for detailed cleaning instructions.

3. **Placement:** Place the basket on a stable, flat surface in your kitchen or desired area. Ensure the location is away from direct heat sources or excessive moisture.



Image 3.1: The basket with its net cover lifted, ready to receive produce.

4. OPERATING INSTRUCTIONS

Using your BOTEX Fruit & Vegetable Basket is straightforward:

1. **Loading Produce:** Gently lift the apple-shaped net cover. Place your clean fruits and vegetables into the basket. Avoid overfilling to ensure proper air circulation and to prevent damage to the produce or the basket.
2. **Securing the Cover:** Once loaded, carefully place the net cover back onto the basket. The mesh design allows air to circulate while protecting contents from insects and dust.
3. **Portability:** The lightweight design allows you to easily move the basket. When moving, support the base of the basket to prevent accidental spills.



Image 4.1: The basket in a kitchen setting, demonstrating its use as a countertop storage solution.

5. MAINTENANCE AND CARE

Regular cleaning will ensure the longevity and hygiene of your fruit basket.

- **Cleaning:** The basket and cover are washable. Use mild dish soap and warm water. A soft brush or sponge can be used to clean the mesh.
- **Rinsing:** Rinse thoroughly under running water to remove all soap residue.
- **Drying:** Allow the basket and cover to air dry completely before storing or reusing. Ensure no moisture remains to prevent rust or mildew.
- **Storage:** When not in use, store the basket in a dry place.
- **Avoid Harsh Chemicals:** Do not use abrasive cleaners, steel wool, or harsh chemicals, as these can damage the metal finish.



Image 5.1: The basket being used for washing vegetables, demonstrating its washable feature.

6. TROUBLESHOOTING

Issue	Possible Cause	Solution
Basket appears unstable.	Uneven surface.	Place the basket on a flat, level countertop or table.
Net cover does not sit properly.	Basket is overfilled or cover is misaligned.	Reduce the amount of produce in the basket. Ensure the cover is aligned correctly with the basket's rim.
Signs of rust.	Improper drying after washing or exposure to excessive moisture.	Ensure the basket is completely dry after each wash. Store in a dry environment. Minor rust spots can sometimes be removed with a mild abrasive, but prevention is key.

7. SPECIFICATIONS

Feature	Detail
Brand	BOTEX
Model Number	4656546
Material	Metal
Colour	Red
Special Feature	Lightweight, Washable
Product Dimensions	10D x 5W x 5H Centimeters
Item Weight	350 Grams
Assembly Required	No
Mounting Type	Countertop
Recommended Uses	Storage
Included Components	Basket

8. WARRANTY AND SUPPORT

For any product-related inquiries, support, or concerns, please contact the seller or manufacturer directly through the platform where the purchase was made. Keep your purchase receipt or order details handy for faster assistance. This product is designed for household use and proper care as outlined in this manual will ensure its optimal performance and longevity.