VASAGLE ULET275W01

VASAGLE Record Player Stand ULET275W01 - Instruction Manual

Model: ULET275W01 | Brand: VASAGLE

Introduction

This manual provides detailed instructions for the assembly, operation, and maintenance of your VASAGLE Record Player Stand. Please read this manual carefully before assembly and use to ensure proper setup and safe handling of the product. Keep this manual for future reference.





The VASAGLE Record Player Stand provides a dedicated space for your turntable and vinyl collection.

Safety Information

- **Weight Capacity:** Do not sit on the side table. Do not exceed the maximum weight recommendation of 44 pounds (20 kg) for the top shelf and 22 pounds (10 kg) for the middle shelf to ensure stability.
- **Assembly:** Keep small parts away from children during assembly. Assemble the product on a soft, clean surface to prevent scratches.
- **Stability:** Ensure the stand is placed on a level surface. Periodically check and tighten all fasteners to maintain stability.
- **Damage:** Do not use the product if any part is damaged. Contact customer support for replacement parts.

Package Contents

Please verify that all components listed below are present before beginning assembly. If any parts are missing or

damaged, please contact customer support.


- 1 x Record Player Stand (Main Frame and Shelves)
- 1 x Accessory Kit (includes screws, Allen key, and other small parts)
- 1 x Instruction Manual

Tools Recommended for Assembly: A screwdriver (not included in the accessory kit, but may be required for some fasteners).

Setup and Assembly

The VASAGLE Record Player Stand is designed for straightforward assembly, typically completed in 6 simple steps. Follow the detailed instructions provided in the accessory kit.

1. **Unpack:** Carefully remove all components from the packaging and lay them out on a clean, soft surface to prevent damage.
2. **Identify Parts:** Match each component with the corresponding labels in the instruction diagram.
3. **Follow Steps:** Adhere to the numbered assembly steps provided in the included instruction sheet.
4. **Secure Fasteners:** Ensure all screws and connectors are fully tightened for structural integrity. Do not overtighten.
5. **Final Check:** Once assembled, gently shake the stand to confirm stability.



Detailed dimensions of the record player stand, including width, depth, height, and individual shelf weight capacities (top shelf 44 lbs, middle shelf 22 lbs).


Operating Instructions

This 3-tier stand is designed for versatile use, primarily as a record player stand and vinyl storage unit, or as a general side table.


- **Record Player Placement:** Place your record player on the top shelf. Ensure it is centered and stable. Do not exceed

the 44 lb (20 kg) weight limit for the top shelf.

- **Vinyl Album Storage:** Utilize the two open shelves below for storing vinyl albums. The stand can accommodate up to 100 albums.
- **Customized Organization:** The bottom shelf features removable U-shaped dividers, allowing you to customize the storage space to fit your specific needs and album sizes.
- **Versatile Use:** This unit can also function as a side table in your living room, bedroom, or study, providing convenient storage for books, decor, or daily essentials.



This view demonstrates the 3-tier storage capacity, accommodating a record player and numerous vinyl albums.



Highlights key features such as the removable U-shaped dividers for organizing records and the dense mesh side panels designed to prevent items from falling.



This image showcases the stand's versatility, usable as a dedicated record player stand or a functional side table for various items.

Maintenance

Proper care will extend the life and appearance of your record player stand.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using abrasive cleaners or harsh chemicals, as these can damage the finish.

- **Dusting:** Regularly dust the stand with a dry, soft cloth.
- **Fasteners:** Periodically check all screws and bolts to ensure they remain tight. Retighten as necessary to maintain structural integrity.
- **Environment:** Avoid placing the stand in direct sunlight or near heat sources, which can cause material degradation.

Troubleshooting

If you encounter any issues with your record player stand, refer to the following common solutions:

- **Instability/Wobbling:**
  Solution: Ensure all assembly screws are fully tightened. Verify that the stand is placed on a completely level surface. Adjust any leveling feet if present.
- **Missing Parts:**
  Solution: Double-check the packaging. If parts are genuinely missing, contact VASAGLE customer support with your model number (ULET275W01) and a list of the specific missing components.
- **Difficulty Assembling:**
  Solution: Review the assembly instructions carefully, paying close attention to diagrams and part orientations. Ensure you are using the correct fasteners for each step. Do not force parts together.
- **Damaged Components:**
  Solution: Do not attempt to assemble or use the product if any component is damaged. Contact customer support for replacement parts.

Specifications

Feature	Detail
Brand	VASAGLE
Model Number	ULET275W01
Product Dimensions (D x W x H)	11.8"D x 16.9"W x 27.1"H (30 cm x 43 cm x 69 cm)
Item Weight	13.4 Pounds (6.1 kg)
Maximum Weight Recommendation (Top Shelf)	44 Pounds (20 kg)
Maximum Weight Recommendation (Middle Shelf)	22 Pounds (10 kg)
Color	Rustic White
Material Type	Engineered Wood, Alloy Steel
Number of Shelves	3
Style Name	Regular
Indoor/Outdoor Usage	Indoor
UPC	194343092577

Warranty and Support

For warranty information, technical assistance, or to order replacement parts, please contact VASAGLE customer service. Refer to your purchase documentation or the VASAGLE official website for specific warranty terms and contact details.

Customer Service Contact: Please refer to the contact information provided with your product packaging or visit the official VASAGLE website.

© 2025 VASAGLE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question