

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [LELO](#) /
- › [LELO MIA 3 Personal Massager Instruction Manual](#)

LELO MIA 3

LELO MIA 3 Personal Massager

Instruction Manual

INTRODUCTION

The LELO MIA 3 is a compact and discreet personal massager designed for versatile use. It features a sleek, lipstick-inspired design, eight distinct pleasure settings, and is fully waterproof for use in various environments. This manual provides essential information for the safe and effective use of your device.

sleek, discreet & powerful

MIA 3 is a stylish, **travel-friendly vibrator** designed for pleasure anytime, anywhere. With a smooth, lipstick-inspired design and **powerful yet quiet vibrations**, it's perfect for discreet satisfaction. Available in three elegant colors, MIA 3 fits easily in any bag, so pleasure is always within reach.

Image: The LELO MIA 3 device, highlighting its sleek, discreet, and powerful design.

Key Features

- **8 Pleasure Settings:** Offers a range of vibration patterns from gentle to intense.
- **Travel-Ready & Discreet:** Compact design (22 x 22 x 111 mm / 0.87 x 0.87 x 4.37 in) with a travel lock feature.
- **Sculpted Tip:** Designed for precise targeting.
- **USB Rechargeable & Waterproof:** Fully submersible (IPX7 standard) and easily rechargeable via integrated USB.

SETUP

Initial Charging

Before first use, fully charge your LELO MIA 3 for 2 hours. The device features an integrated USB charger. To access it, gently pull the top section of the device to reveal the USB connector. Insert the USB connector into any standard USB port for charging.

Useful information



CHARGING TIME / USE TIME

up to 2 h / up to 1.5 h



TRAVEL LOCK

to unlock, hold + and – for 3 seconds



USB RECHARGEABLE & WATERPROOF

enjoy unlimited climaxes anytime, anyplace



STAND BY

up to 90 days



Image: The LELO MIA 3 device with key information including charging time, travel lock, USB rechargeability, and standby time.

Preparation for Use

For optimal comfort and experience, apply a liberal amount of LELO Personal Moisturizer or a water-based lubricant to the device and your body before use.



how to use?

STEP 1

Prep

For the smoothest experience, apply a liberal amount of LELO Personal Moisturizer to the device and your body.

Image: Illustration demonstrating the first step of use: applying lubricant to the device.

OPERATION

Turning On/Off

- **To Turn On:** Press the '+' button shortly.
- **To Turn Off:** Press the '-' button.

Adjusting Settings and Intensity

- **To Switch Between 8 Modes:** Double press the '+' or '-' button.
- **To Decrease or Increase Intensity:** Press the '+' and '-' buttons.

How to use

BEFORE FIRST USE

charge for 2 hours

TO TURN IT ON

press + button shortly

TO SWITCH BETWEEN 8 MODES

double press + or - button

TO DECREASE OR INCREASE INTENSITY

press the + and the - buttons

TO TURN IT OFF

press the - button



Image: Detailed instructions on how to turn on, switch modes, and adjust intensity for the LELO MIA 3.

Travel Lock

To activate the travel lock, hold the '+' and '-' buttons simultaneously for 3 seconds. This prevents accidental activation during transport. Repeat the process to unlock the device.

MAINTENANCE

Cleaning

Always clean your LELO MIA 3 thoroughly before and after each use. Wash the device with warm water and a toy cleaner or mild soap. Rinse thoroughly and pat dry with a lint-free cloth. Avoid using cleaners containing alcohol, petroleum, or acetone, as these can damage the silicone material.

Storage

Store your LELO MIA 3 in a cool, dry place, away from direct sunlight and extreme temperatures. Keep it separate from other toys made of different materials to prevent damage. The device comes with a storage pouch for discreet and protected storage.

TROUBLESHOOTING

- **Device does not turn on:** Ensure the device is fully charged. If the issue persists, try unlocking the travel lock by holding '+' and '-' for 3 seconds.
- **Charging issues:** Verify that the USB connector is properly inserted into a functioning USB port. If the device is not charging, try a different USB port or power adapter.
- **Reduced performance:** A low battery can affect vibration intensity. Recharge the device fully.

If you encounter any issues not covered here, please refer to the warranty and support section for further assistance.

SPECIFICATIONS

Feature	Detail
Model Name	MIA 3
Item Model Number	12008
Material	Body-safe Silicone
Dimensions	4.37 x 0.87 x 0.87 inches (111 x 22 x 22 mm)
Weight	1.27 ounces (36 g)
Battery	1 Lithium Ion battery (included)
Charging	USB Rechargeable
Waterproof Rating	IPX7 Standard (fully submersible)
Settings	8 powerful pleasure settings

A purple LELO MIA 3 vibrator is shown at an angle. Four numbered callouts (1, 2, 3, 4) point to different parts of the device: 1 points to the top, 2 to the tip, 3 to the base, and 4 to the side. To the right of the device are four icons: a gear for settings, a padlock for travel lock, a signal tower for precision, and a battery with a lightning bolt for charging. Each icon is accompanied by a numbered heading and a descriptive paragraph.

1 - EIGHT POWERFUL PLEASURE SETTINGS
Choose from eight vibration patterns, ranging from gentle murmurs to intense pulses

2 - TRAVEL READY & DISCREET
Compact and discreet, MIA 3 is easy to take anywhere for pleasure on the go

3 - SCULPTED TIP FOR ACCURATE PLEASURE
Designed to target the outer pleasure spot with precision for fast, intense satisfaction

4 - USB RECHARGEABLE & FULLY WATERPROOF
Perfect for travel with a compact size and a travel lock for safe transport

Image: Overview of LELO MIA 3 features and specifications, including safety certifications and physical dimensions.

WARRANTY AND SUPPORT

Warranty Information

The LELO MIA 3 comes with a **1-year warranty**, alongside a **10-year quality guarantee**. This covers

manufacturing defects and ensures the product meets LELO's high standards of quality and performance.

Customer Support

For any questions, concerns, or warranty claims, please visit the official LELO website or contact their customer support directly. Keep your proof of purchase for warranty validation.

© 2026 LELO. All rights reserved.