

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [GERTZY](#) /

> [GERTZY M-6008 2-in-1 Electric Shaver and Callus Remover User Manual](#)

GERTZY M-6008

GERTZY M-6008 2-in-1 Electric Shaver and Callus Remover User Manual

Model: M-6008 | Brand: GERTZY

1. IMPORTANT SAFETY INSTRUCTIONS

- Read all instructions before using this appliance.
- Keep the appliance away from children.
- Do not disassemble or attempt to repair the appliance yourself. Contact customer support for assistance.
- Ensure the charging port is dry before connecting the USB cable.
- Do not use the appliance on irritated, infected, or broken skin.
- Avoid prolonged use on one area to prevent skin irritation.

2. PRODUCT OVERVIEW

The GERTZY M-6008 is a versatile 2-in-1 device designed for both hair removal and callus removal. It features interchangeable heads, a visible battery indicator, and a compact, fully washable design for convenience and easy maintenance.

Package Contents



This image displays the complete set of components included with your GERTZY M-6008 device. It shows the main body of the device, the interchangeable hair removal head, the interchangeable callus removal head, a USB charging cable, and a small cleaning brush.

1. Main Device Body
2. Callus Remover Head
3. Hair Removal Head
4. USB Charging Cable
5. Cleaning Brush

3. SETUP

Charging the Device

Before first use, fully charge the device. The battery indicator will show the charging status.

多機能USB充電式

2時間の充電時間
使用可能時間90分



USBソケット



車内充電



移動電源



パソコン

This image illustrates the versatile USB charging capabilities of the GERTZY M-6008. The device can be charged using a standard USB socket, a car charger, a mobile power bank, or a computer's USB port. A full charge takes approximately 2 hours and provides up to 90 minutes of usage time.

- Connect the USB charging cable to the device's charging port.
- Plug the other end of the USB cable into a compatible USB power source (e.g., wall adapter, computer, power bank).
- A full charge takes approximately 2 hours and provides up to 90 minutes of operating time.

Attaching/Detaching Heads

- To attach a head: Align the desired head (shaver or callus remover) with the main device body and gently push until it clicks into place.
- To detach a head: Hold the main device body firmly and pull the head straight off.

4. OPERATING INSTRUCTIONS

Power On/Off and Speed Settings



This image highlights the power button and the two-stage speed control of the GERTZY M-6008. Pressing the button cycles through the power settings: off, 1st gear (3300rpm), and 2nd gear (3900rpm).

- Press the power button once to turn on the device at 1st gear (3300rpm).
- Press the power button a second time to switch to 2nd gear (3900rpm).
- Press the power button a third time to turn off the device.

Using the Hair Removal Head



This image provides a close-up view of the GERTZY M-6008 with the hair removal head installed, showcasing its fine blades designed for efficient and gentle hair removal.

- Ensure the hair removal head is securely attached.
- Turn on the device and select your desired speed.
- Gently glide the shaver against the direction of hair growth, holding the skin taut.
- The device can be used for wet or dry shaving. For wet shaving, apply shaving foam or gel.

Using the Callus Remover Head



This image shows a detailed view of the GERTZY M-6008 with the callus remover head attached. The textured roller is visible, designed to gently and effectively remove hardened skin from the feet.

- Ensure the callus remover head is securely attached.
- Turn on the device and select your desired speed.
- Gently move the roller over areas with calluses or hard skin on your feet. Do not apply excessive pressure.
- Stop if you experience any discomfort or pain.

Wet and Dry Use

丸洗い可能



This image visually confirms that the GERTZY M-6008 is fully washable, showing the device being used underwater. This feature allows for convenient cleaning and comfortable wet shaving or callus removal.

The GERTZY M-6008 is designed for both wet and dry use. You can use it in the shower or bath with water and shaving foam/gel for a more comfortable experience, or dry for quick touch-ups.

5. MAINTENANCE

Cleaning the Device

The device is fully washable for easy cleaning.

- After each use, turn off the device and detach the head.
- Use the included cleaning brush to remove any hair or skin debris from the head and main unit.
- Rinse the head and the main unit under running water. Ensure the charging port cover is securely closed before rinsing the main unit.
- Allow all parts to air dry completely before reassembling or storing.

Storage

- Store the device in a cool, dry place, away from direct sunlight and high temperatures.
- Keep the protective cap on the shaver head when not in use to prevent damage.

6. TROUBLESHOOTING

If you encounter any issues with your GERTZY M-6008, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Device does not turn on.	Low battery or no charge.	Charge the device for at least 2 hours.
Poor hair removal/callus removal performance.	Head is dirty or worn out.	Clean the head thoroughly. If performance does not improve, consider replacing the head.
Device stops during use.	Battery is low.	Recharge the device.
Skin irritation after use.	Excessive pressure or prolonged use on one area.	Use gentle pressure and move the device continuously. Avoid using on sensitive or irritated skin.

7. SPECIFICATIONS

Feature	Specification
Model Number	M-6008
Material	High-quality ABS
Power Source	USB Rechargeable
Charging Time	Approx. 2 hours
Usage Time	Approx. 90 minutes
Color	White
Dimensions	15.5 x 5.4 x 3.3 cm
Weight	310 g (packaged)
Battery Type	1 Lithium Ion Battery (included)
Speed Settings	1st Gear: 3300rpm, 2nd Gear: 3900rpm
Water Resistance	Fully Washable (Wet & Dry Use)

8. WARRANTY AND SUPPORT

GERTZY products are manufactured with high-quality standards. For warranty information or technical support, please refer to the documentation included with your purchase or contact GERTZY customer service through the retailer where the product was purchased.

Please retain your proof of purchase for any warranty claims.