

HJH13D

Generic Richmat HJH13D Wireless Remote Control User Manual

Model: HJH13D

1. INTRODUCTION

This manual provides essential information for the proper use, setup, and maintenance of your Generic Richmat HJH13D 7-Button Wireless Remote Control. Please read this manual thoroughly before operating the remote to ensure optimal performance and longevity.

2. PRODUCT OVERVIEW AND COMPATIBILITY

The HJH13D wireless remote is designed as a replacement for specific adjustable bed bases. It features 7 buttons for controlling various bed positions and functions.



Image 2.1: Generic Richmat HJH13D Wireless Remote Control (Grey)

Compatibility: This remote is specifically designed to work with BT2000, FlexEzz, Revive, E300, or

HJH13D/55 7-button bed bases that originally featured an identical remote, whether in white or black. It is crucial that your original remote had the same button layout and icons as pictured. If your original remote had different button icons, additional rows of buttons, or different wording, this replacement remote may not be compatible.



Image 2.2: Examples of compatible and discontinued remote controls. The remote you receive will be similar to the grey BedTech remote shown on the right.

The remote you will receive is typically a white BedTech remote manufactured by the same company, ensuring compatibility with the specified bases.

3. SETUP

3.1 Battery Installation

1. Locate the battery compartment cover on the back of the remote control.
2. Slide or unclip the cover to open the compartment.
3. Insert the required batteries (typically AAA or AA, check the compartment for specific type and polarity) ensuring the positive (+) and negative (-) ends align correctly with the markings inside the compartment.
4. Replace the battery compartment cover, ensuring it clicks securely into place.

3.2 Pairing (If Required)

This remote is often a direct replacement and may not require manual pairing. However, if the remote does not immediately control your bed base after battery installation, pairing may be necessary. Refer to your adjustable bed base's original user manual for specific pairing instructions. Typically, pairing involves pressing a button on the bed base's control box and then a button on the remote within a short timeframe.

4. OPERATING INSTRUCTIONS

The HJH13D remote features 7 distinct buttons for controlling your adjustable bed base:

- **Head Up/Down Buttons:** Control the elevation and lowering of the head section of the bed.
- **Foot Up/Down Buttons:** Control the elevation and lowering of the foot section of the bed.
- **M Button:** Often a memory preset button. Press to save a favorite position or recall a pre-programmed position. Consult your bed base manual for specific memory function details.
- **W Button:** Typically controls a massage or wave function. Press to activate or cycle through massage modes/intensities.
- **FLAT Button:** Returns the bed to a completely flat position. Press and hold until the bed is fully flat.

Press and hold the desired button to move the bed to the desired position. Release the button to stop movement.

5. MAINTENANCE

5.1 Cleaning

To clean the remote control, wipe it with a soft, dry cloth. For stubborn dirt, a slightly damp cloth with mild soap can be used, ensuring no liquid enters the remote. Do not use abrasive cleaners or solvents.

5.2 Battery Replacement

Replace batteries when the remote's performance degrades or it stops responding. Always replace all batteries at the same time with new ones of the same type. Dispose of old batteries according to local regulations.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Remote not responding.	Dead or low batteries.	Replace batteries.
Remote not responding.	Remote not paired with bed base.	Refer to your bed base manual for pairing instructions.
Bed moves erratically or not as expected.	Interference or signal issue.	Ensure no obstructions between remote and bed base. Try re-pairing if issues persist.
Remote buttons feel sticky or unresponsive.	Dirt or debris under buttons.	Clean the remote as per maintenance instructions.

7. SPECIFICATIONS

Model Number: HJH13D

Product Dimensions: 2 x 1 x 6 inches

Color: Grey (as pictured, actual replacement may be white)

Max Number of Supported Devices: 1

Compatible Devices: Tempurpedic Remote - Must match picture, BT2000, FlexEzz, Revive, E300, HJH13D/55 7-button bases.

Manufacturer: Bedremotes.com

Country of Origin: USA

8. WARRANTY AND SUPPORT

For information regarding warranty coverage and technical support for your Generic Richmat HJH13D Wireless Remote Control, please refer to the documentation provided by your original seller or contact the seller directly. Protection plans may be available for purchase separately.