

[manuals.plus](#) /› [SHUWEI](#) /› [SHUWEI Tablet Floor Stand with Tray \(Model LD-077\) Instruction Manual](#)

SHUWEI LD-077

SHUWEI Tablet Floor Stand with Tray (Model LD-077) Instruction Manual

Model: LD-077 | Brand: SHUWEI

1. INTRODUCTION

Thank you for choosing the SHUWEI Tablet Floor Stand with Tray. This versatile and robust stand is designed to provide a hands-free viewing experience for your tablets, phones, and portable monitors. Featuring double self-locking worm gears, adjustable height up to 63 inches, a 360° rotatable clamp, and a stable 7.5lb weighted base, it offers reliable support and flexible positioning for various activities.

2. PACKAGE CONTENTS

Please ensure all the following components are included in your package:

- Base
- Extension Tube
- Telescopic Tube
- Folding Arm
- Tablet Clamp
- Phone Clamp
- User Manual
- Tray

3. SPECIFICATIONS

Model Number	LD-077
Brand	SHUWEI
Color	Black

Form Factor	Tablet Floor Stand with Double Self-Locking Worm Gears
Item Weight	8.03 pounds
Max Load Capacity	11 lbs
Adjustable Height	Up to 63 inches
Compatible Device Size	4.7 to 15.6 inches
Base Weight	7.5 lbs

4. DEVICE COMPATIBILITY

The SHUWEI Tablet Floor Stand is designed for wide compatibility with devices ranging from 4.7 to 15.6 inches.

Compatible Tablets:

iPad 5/6/7/8/9, iPad mini 1/2/3/4/5/6, iPad Air 1/2/3/4/5, iPad Pro 9.7"/10.5"/11" 1st/11" 2nd/11" 3rd; Galaxy Tab S 8.4/S 10.5/S2 8.0/S2 9.7/S2 8.0 2016 /S2 9.7 2016 /S3/S4/S5e/S6/S6 Lite; Galaxy Tab A 8.0 (2015)/A 9.7 (2015)/A 7.0 2016 /A 8.0 (2017)/A 8.0 (2018)/A 10.1 (2019)/A 8.0 (2019)/A 8.0 2019 kids//A Kids 2019 /A 8.4 2020 /A7 10.4 2020); Galaxy Tab 7.0/7.0 Plus/7.7/8.9/2 7.0/3 7.0/3 8.0/3 Lite 7.0/4 7.0/4 8.0/4 10.1; Galaxy Tab Pro 8.4/Pro 10.1; Kindle Fire 1st, Fire 5th, Fire HD 6 4th, Fire 7 7th/9th, Kindle Fire HD 7 2nd/3rd/4th, Kindle Fire HDX 7 3th, Fire HD 8 5th/6th/7th/8th/10th, Fire HDX 8.9 3th/4th, Fire HD 10 5th/11th; Kindle 2/4/5/7/8/10//Keyboard/DX/DX Graphite/Touch/X Migu/Voyage/Kindle 2022, Kindle Paperwhite 1/2/3/4/5, Kindle Oasis/Oasis 2/Oasis 3; Pixel C; Switch(Without joy cons); Other devices with a combined weight of less than 1.5 pounds and a screen larger than 4.7 inches.

Compatible Phones:

iPhone 6/6 Plus/6S/6S Plus/7/7 Plus/8/8 Plus/X/XS/XS Max/XR/11/11 Pro/11 Pro Max/SE 2nd/12/12 Pro/12 mini/12 Pro Max/13/13 mini/13 Pro/13 Pro Max/14/ 14 Plus/ 14 Pro/ 14 Pro Max; Galaxy S9, S9+, S10e, S10, S10+, S10 5G, S10 Lite, S20, S20+, S20 Ultra, S20 FE, S21, S21+, S21 Ultra, S21 FE, S22, S22+, S22 Ultra; Galaxy Note9, Note10, Note10+, Note10 5G, Note10+ 5G, Note10 Lite, Note 20, Note 20 5G, Note 20 Ultra, Note 20 Ultra 5G; Galaxy A8, A8+, A8 Star, A6s, A6, A6+, A8 star, A9 star, A7, A9, A8s, A10e, A10, A10s, A20e, A20, A20s, A30, A30s, A40, M30, A50, A50s, A51, A60, A70, A70s, A71, A80, A90 5G, A01, A01 Core, A02s, A11, A12, A21, A21s, A31, A32 4G 5G, A41, A42 5G, A51, A71, A22 5G, A32, A32 5G, A52, A52 5G, A52s 5G, A72, A03, A33, A53, A73; Pixel, Pixel XL, Pixel 2, Pixel 2 XL, Pixel 3, Pixel 3 XL, Pixel 3a, Pixel 3a XL, Pixel 4, Pixel 4 XL, Pixel 4a, Pixel 4a (5G), Pixel 5, Pixel 5a (5G), Pixel 6, Pixel 6 Pro, Pixel 6a.

5. SAFETY INFORMATION

- Ensure all screws and connections are tightened before use to prevent accidental falls.
- Do not exceed the maximum load capacity of 11 lbs.
- Avoid placing the stand in high-traffic areas where it could be tripped over.
- Keep children and pets away from the stand during adjustment to prevent pinching or injury.
- Do not hang heavy objects on the arm or attempt to use it as a climbing aid.
- Regularly check for any signs of wear or damage. Discontinue use if any components are compromised.

6. SETUP AND ASSEMBLY

Follow these steps to assemble your SHUWEI Tablet Floor Stand:

1. Attach the Base Support Bar to the Metal Stand Base:

Insert the screw through the hole in the metal stand base. Align the two calibration cylindricity at the bottom of the base support bar with the recessed holes in the chassis and press firmly. Tighten the screw using the provided wrench to secure the base support bar to the metal stand base.

Your browser does not support the video tag.

Video: A step-by-step guide demonstrating the assembly of the stand's base components.

2. Connect the Angular Operating Lever:

Insert the angular operating lever into the base support rod and tighten it clockwise until secure. Once mounted, pull the angle operating lever out from underneath and mount it from above.

Your browser does not support the video tag.

Video: Demonstrates connecting the angular operating lever and adjusting its position.

3. Attach the Device Clamp (Tablet or Phone):

Unscrew the nut on the back of the chosen device clamp (tablet or phone). Place the nut onto the ball joint at the top of the crossbar, ensuring the larger mouth of the clamp faces outward. Push the ball joint into the slot on the clamp, then tighten the nut to secure the clamp. Use the small screw wrench to adjust and tighten the clamp's angle for a secure position.

Your browser does not support the video tag.

Video: Illustrates attaching the device clamp and securing it to the stand.

4. Attach the Tray:

If your model includes a tray, attach it to the designated slot on the stand. Ensure it is securely fastened.

WIDE COMPATIBILITY

Fit for 4.7-15.6" Devices



Image: A detailed view of the SHUWEI Tablet Floor Stand with the tray attached, highlighting its dimensions and compatibility.

7. OPERATING INSTRUCTIONS

Adjusting Height:

The stand features double self-locking worm gears for easy height adjustment. Simply press the button on the telescopic tube to release the lock, adjust to your desired height (up to 63 inches), and release the button. The mechanism will automatically lock, securing your device in place.

HEIGHT AND ANGLE ADJUSTABLE



Image: A visual representation of the height adjustment feature, illustrating the maximum height of 63 inches.

Adjusting Angle and Orientation:

The aluminum folding arm allows for flexible angle adjustments. Press and hold the button marked "PRESS" on the joints of the folding arm to adjust the angle. Release the button to lock the arm in position. The device clamp offers 360° rotation, allowing you to switch between portrait and landscape orientations effortlessly. The clamp can also be tilted back and forth 180°.

WEIGHTED BASE FOR EXTRA STABILITY



Image: A close-up of the stand's articulated arm and rotatable clamp, demonstrating the 360° rotation and 180° tilt capabilities.

Inserting/Removing Devices:

Gently pull apart the elastic clips of the device clamp to widen it. Insert your tablet or phone into the clamp, ensuring it is centered and securely held by the clips. To remove, gently pull the clips apart again and take out your device.



Side Table and Tablet Stand

Image: A person using the SHUWEI Tablet Floor Stand with a tablet, demonstrating how the device is held securely.

Using the Tray:

The integrated tray provides a convenient space for small items such as a cup, remote control, or other accessories. Ensure items placed on the tray do not exceed its weight capacity or obstruct the stand's movement.

WIDE COMPATIBILITY

Fit for 4.7-15.6" Devices



Image: A detailed view of the SHUWEI Tablet Floor Stand with the tray attached, showing its utility for holding small items.

General Usage Video:

Your browser does not support the video tag.

Video: Demonstrates various usage scenarios and adjustments of the tablet floor stand in a home setting.

8. MAINTENANCE

- Cleaning:** Wipe the stand with a soft, damp cloth. Avoid using abrasive cleaners or solvents that could damage the finish.
- Storage:** When not in use, the stand can be collapsed for compact storage. Ensure all adjustable parts are securely locked before moving or storing.
- Inspection:** Periodically check all screws and joints to ensure they remain tight. Re-tighten if

necessary.

9. TROUBLESHOOTING

Stand is unstable or tips over:

- Ensure the base is placed on a flat, stable surface.
- Verify that the base support bar is securely tightened to the metal stand base.
- Check that the device's weight does not exceed the maximum load capacity of 11 lbs.
- Ensure the device is centered in the clamp to distribute weight evenly.
- Adjust the arm to a more balanced position, especially if extended far from the base.

Device clamp is loose or not holding device securely:

- Tighten the nut on the back of the device clamp.
- Ensure the small screw wrench adjustment point on the clamp is tightened.
- Verify that your device's size is within the compatible range of 4.7 to 15.6 inches.

Height adjustment mechanism is not locking:

- Ensure the button on the telescopic tube is fully released after adjusting the height.
- Check for any obstructions in the locking mechanism.

10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official SHUWEI website. Keep your purchase receipt as proof of purchase for any warranty claims.