

- Manuals.plus /
- › LEDIARY /
- › LEDIARY Caged Ceiling Fan with Lights and Remote User Manual

LEDIARY 5a6b5c4f-1b03-42ac-bb43-95e935f92b6a

LEDIARY Caged Ceiling Fan with Lights and Remote

Model: 5a6b5c4f-1b03-42ac-bb43-95e935f92b6a

1. INTRODUCTION

Thank you for choosing the LEDIARY Caged Ceiling Fan with Lights and Remote. This product combines a stylish farmhouse industrial design with modern functionality, providing both illumination and air circulation for your living spaces. Its bladeless design ensures safety and space efficiency, making it ideal for various rooms including kitchens, living rooms, bedrooms, and dining rooms. This manual provides detailed instructions for installation, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new ceiling fan.



Figure 1.1: LEDIARY Caged Ceiling Fan with remote control, showcasing its design and functionality.

2. SAFETY INFORMATION

Please read all instructions carefully before beginning installation and keep this manual for future reference. Failure to follow these instructions could result in electric shock, fire, or personal injury.

- Always disconnect power at the circuit breaker or fuse box before installation, cleaning, or servicing.
- All electrical connections must be in accordance with local codes, ordinances, and the National Electric Code (NEC). If you are unfamiliar with proper electrical wiring, consult a qualified electrician.
- Ensure the mounting structure is capable of supporting the weight of the fan (approximately 8 pounds).
- Do not bend the fan blades or cage during installation or cleaning.
- Do not insert fingers or any objects into the fan cage while the fan is operating.

- Use only E26 bulbs as specified. Do not exceed the maximum wattage for incandescent (60W) or LED (10W) bulbs.
- This fan is designed for indoor use only and is not water resistant.

3. PACKAGE CONTENTS

Carefully unpack your ceiling fan and inspect the contents to ensure all parts are present and undamaged. If any parts are missing or damaged, contact customer service immediately.

- Caged Ceiling Fan Unit (with integrated bladeless fan and light fixture)
- Remote Control
- Mounting Hardware (screws, wire nuts, etc. - typically included)
- Instruction Manual

4. SETUP AND INSTALLATION

This ceiling fan is designed for flush mount installation. Follow these steps for proper setup.

4.1 Pre-Installation

- Turn off power at the main circuit breaker.
- Ensure the ceiling junction box is securely mounted and capable of supporting the fan's weight.

4.2 Mounting the Fan

1. Attach the mounting bracket to the ceiling junction box using the provided screws.
2. Make electrical connections: Connect the fan's wires to the household wires (Live to Live, Neutral to Neutral, Ground to Ground) using wire nuts.
3. Secure the fan unit to the mounting bracket.

4.3 Bulb Installation

The fan requires 4 E26 base bulbs (not included). Recommended bulb types include ST21, A19, ST19, T45. Maximum wattage for incandescent bulbs is 60W, and for LED bulbs is 10W.

1. Carefully screw the E26 bulbs into the four bulb bases within the fan cage. The cage does not need to be removed for bulb installation.



Powerful, Quiet & Comfortable

Low **35dB** Operation



Low Noise



Timing Function



Strong Power



Silent Remote Control



Figure 4.1: Key components of the LEDIARY Caged Ceiling Fan, including the E26 bulb bases.

Powerful and Quality Motor

Cool in Summer & Warm in Winter



Figure 4.2: Product dimensions and recommended E26 bulb types for optimal lighting.

5. OPERATING INSTRUCTIONS

Your LEDIARY ceiling fan is controlled by the included remote control, offering various settings for comfort and convenience.

5.1 Remote Control Functions

- **Power On/Off:** Turns the fan and light on or off.
- **Fan Speed:** Select from 6 wind speeds (1-6).
- **Timer:** Set the fan to turn off automatically after 1, 2, or 4 hours.
- **Reversible Mode:** Switch between summer (downward airflow) and winter (upward airflow) modes.
- **Light Control:** Turn the light on/off independently.

- **Beep Button:** Turn off the beep sound from the fan.



6 Speeds Adjustable

Choose the Wind Speed According to Your Need



1-2 Speeds:
For Sleeping Reading



3-4 Speeds:
For Entertainment Party



5-6 Speeds:
For Sports Fitness



Figure 5.1: Guide to 6 adjustable wind speeds for various comfort levels.





Figure 5.2: Overview of the fan's quiet operation, timing, and remote control features.

5.2 Reversible Mode Operation

The reversible motor allows for year-round use:

- **Summer Mode (Downward Airflow):** The fan blades rotate counter-clockwise, pushing cool air downwards to create a cooling effect.
- **Winter Mode (Upward Airflow):** The fan blades rotate clockwise, drawing warm air up towards the ceiling and distributing it evenly throughout the room, helping to reduce heating costs.

18" Size for Saving Space



E26*4 (not included)

Recommended bulbs :



LED Edison Bulb A19




LED Bulb A19



LED Edison Bulb ST19



LED Bulb ST19



Edison LED Bulb T14



Incandescent Light Bulb - Max 60W

LED Light Bulb - Max 10W

Figure 5.3: Explanation of summer and winter modes for optimal air circulation.

6. MAINTENANCE

Regular maintenance will help prolong the life and performance of your ceiling fan.

- **Cleaning:** To avoid damage to the finish, clean the fan with a soft, damp cloth. Do not use abrasive cleaners or solvents. Ensure power is off before cleaning.
- **Tightening Screws:** Periodically check all screws for tightness. Due to the fan's natural movement, some connections may become loose over time.
- **Bulb Replacement:** Ensure the fan is off and bulbs have cooled before replacing them.

7. TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low/dead.	Check circuit breaker/fuse; Verify all wire connections are secure; Replace remote control batteries.
Light does not work	Bulbs are loose or burnt out; Incorrect bulb type/wattage; Loose wire connection.	Tighten or replace bulbs; Ensure bulbs meet specifications (E26, max 60W incandescent/10W LED); Check light wiring.
Remote control not working	Batteries are dead or incorrectly installed; Remote not paired (if applicable).	Replace batteries, ensuring correct polarity; Refer to remote pairing instructions (if provided with fan).
Excessive noise	Loose mounting screws; Fan not properly balanced.	Tighten all mounting screws; Ensure fan is securely attached to the ceiling.

8. SPECIFICATIONS

Feature	Detail
Brand	LEDIARY
Model Number	5a6b5c4f-1b03-42ac-bb43-95e935f92b6a
Color	Black
Material	Iron
Style	Caged, Farmhouse, Rustic, Industrial, Modern, Enclosed
Light Fixture Form	Ceiling
Room Type	Bedroom, Dining Room, Home Office, Kitchen
Indoor/Outdoor Usage	Indoor
Power Source	DC Motor
Installation Type	Flush Mount
Special Feature	Bladeless
Control Method	Remote
Light Source Type	LED (Bulbs not included)
Finish Type	Matte

Feature	Detail
Shade Material	Iron
Number of Light Sources	4
Voltage	120 Volts (AC)
Light Color	Warm White (dependent on bulb)
Included Components	Remote Control
Wattage (Max)	60W (Incandescent), 10W (LED) per bulb
Bulb Base	E26
Unit Count	1.0 Count
Water Resistance Level	Not Water Resistant
Brightness	1000 lumen (dependent on bulb)
Efficiency	High Efficiency DC Motor
Size	18 Inch
Item Weight	7.98 pounds
Product Dimensions	7 x 18 x 7 inches
Number of Blades	3 (internal)
Batteries Required?	Yes (for remote control)

9. WARRANTY AND SUPPORT

LEDIARY stands behind the quality of its products. Your bladeless industrial ceiling fan comes with comprehensive support:

- **Motor Warranty:** 5-year support on the motor.
- **Component Warranty:** 2-year support on all other components.

For any questions, technical assistance, or warranty claims, please contact our customer service team. We are committed to responding within 12 hours to help you solve any problems.



LEDIARY: Providing green, safe, and intelligent lighting solutions.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0D4HHM9Y7>

More documents and user manuals: <https://manuals.plus/>