

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [LanLuk](#) /

› [LanLuk Magnetic Portable Charger 10800mAh Wireless Power Bank User Manual \(Model HX100M7\)](#)

### LanLuk HX100M7

# LanLuk Magnetic Portable Charger 10800mAh Wireless Power Bank User Manual

Model: HX100M7 | Brand: LanLuk

## 1. IMPORTANT SAFETY INFORMATION

Please read all safety instructions before using this product. Failure to follow these instructions may result in fire, electric shock, injury, or damage to the product or property.

- Do not expose the power bank to extreme temperatures, direct sunlight, or high humidity.
- Do not disassemble, modify, or attempt to repair the device.
- Keep away from water and other liquids.
- Avoid dropping or subjecting the device to strong impacts.
- Use only certified charging cables and adapters.
- This power bank is equipped with multiple safety protections: over-charge, over-voltage, over-current, overheat, and short circuit protection.
- The device is airline-approved for safe travel.



Figure 1: Overview of the power bank's integrated safety protections.

If you notice any unusual behavior, such as swelling, overheating, or strange odors, discontinue use immediately and contact customer support.

## 2. PRODUCT OVERVIEW

The LanLuk Magnetic Portable Charger is a versatile power bank designed for convenient on-the-go charging. It features a strong magnetic connection for compatible devices, a foldable stand for hands-free viewing, and a clear LED digital display to show remaining battery capacity.



Figure 2: Front view of the LanLuk Magnetic Portable Charger.

### Key Features:

- **10800mAh Capacity:** Provides multiple charges for compatible devices.
- **Magnetic Wireless Charging:** Up to 15W for MagSafe-compatible iPhones.
- **25W PD USB-C Fast Charging:** For rapid wired charging and recharging.
- **Foldable Stand:** Integrated stand for vertical or horizontal viewing.
- **LED Digital Display:** Shows precise battery percentage.
- **USB-C In/Output & USB-A Output:** Versatile connectivity for various devices.
- **Compact Design:** Lightweight (0.46lbs) and portable (4.0\*2.7\*0.6 inches).

## Package Contents:

- 1 x LanLuk 10800mAh Portable Wireless Charger
  - 1 x USB-C Charging Cable
  - 1 x Dustproof Portable Storage Bag
  - 1 x Magnetic Charger User Manual
  - 1 x 24-Month Customer Service Card
- 

## 3. SETUP

### 3.1 Charging the Power Bank

Before first use, fully charge your LanLuk Magnetic Portable Charger. Use the provided USB-C cable and connect it to a compatible USB power adapter (not included).

1. Connect the small end of the USB-C cable to the USB-C port on the power bank.
2. Connect the other end of the USB-C cable to a USB power adapter.
3. The LED digital display will show the charging progress. The power bank is fully charged when the display shows 100%.

### 3.2 Preparing Your Device for Wireless Charging

For optimal magnetic wireless charging, ensure your device is MagSafe compatible. If your device is not natively MagSafe compatible, or if you use a non-MagSafe case, the magnetic connection may be weak or non-existent, and wireless charging may not function correctly.

# Charge Your iPhone 16/15/14/13/12/ Snap



10800mAh  
High Capacity



Strong Magnetic  
Connection



Note: Not Compatible with Non-magnetic Phone Cases.



Figure 3: Magnetic attachment and case compatibility for wireless charging.

## 4. OPERATING INSTRUCTIONS

### 4.1 Wireless Charging

1. Press the power button once to activate the power bank.
2. Align your MagSafe-compatible iPhone (iPhone 12/13/14/15/16 series) with the magnetic charging area on the power bank. The magnets will snap into place.
3. Wireless charging will begin automatically. The LED display on the power bank will show its remaining charge, and your phone will indicate charging status.

**10,800mAh**  
**All-Day Power**

Compatible with iPhone 12/13/14/15 Series

-  **iPhone 14/15**  
≈ 2.5 Charges
-  **iPhone 15/14 Pro**  
≈ 1.7 Charges
-  **iPhone 15/14 Pro Max**  
≈ 1.2 Charges

Figure 4: Magnetic wireless charging in action.

## 4.2 Wired Charging

The power bank supports 25W PD fast charging via its USB-C port and standard charging via its USB-A port.

1. Press the power button once to activate the power bank.
2. Connect your device to the power bank using a compatible USB-C to USB-C cable (for 25W PD fast charging) or a USB-A to device-specific cable.
3. Charging will begin automatically.

## Charge 3x Faster with Wired Charging



Figure 5: Fast wired charging via USB-C.

### 4.3 Pass-Through Charging

The power bank supports pass-through charging, allowing you to charge both your device and the power bank simultaneously. Connect the power bank to a power source, and then connect your device to the power bank.




Figure 6: Pass-through charging setup.

#### 4.4 Using the Foldable Stand

The integrated foldable stand allows for convenient hands-free viewing while charging.

1. Gently pull out the stand from the back of the power bank.
2. Place your magnetically attached phone onto the stand in either a vertical or horizontal orientation for comfortable viewing.

# Foldable Stand for Easy Viewing

Support both Horizontal and Vertical



Figure 7: Using the foldable stand for hands-free viewing.

## 4.5 LED Digital Display

The smart LED display provides real-time information on the power bank's remaining battery capacity.

- Press the power button once to view the battery percentage.
- The display shows the exact percentage from 1% to 100%.



Figure 8: LED digital display and port identification.

## 5. MAINTENANCE

- Clean the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive materials.
- Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- If not used for extended periods, charge the power bank at least once every three months to maintain battery health.

## 6. TROUBLESHOOTING

### 6.1 Device Not Charging

- Ensure the power bank is sufficiently charged. Check the LED display.
- Press the power button once to activate the power bank before connecting or attaching your device.
- For wireless charging, ensure your device is MagSafe compatible or using a MagSafe-compatible case, and that it is correctly aligned with the charging area.
- For wired charging, try a different cable or port to rule out cable/port issues.

### 6.2 Slow Charging

- Ensure you are using a 25W PD compatible adapter and cable for fast wired charging.
- For wireless charging, ensure no foreign objects are between the power bank and your device. Thick, non-MagSafe cases can impede charging speed.

### 6.3 Power Bank Not Recharging

- Ensure the USB-C charging cable is securely connected to both the power bank and the power adapter.
- Try a different USB-C cable or power adapter.

## 7. SPECIFICATIONS

| Feature                  | Detail   |
|--------------------------|--|
| Model Number             | HX100M7  |
| Battery Capacity         | 10800mAh   |
| Wireless Charging Output | 15W Max  |
| USB-C Input/Output       | 25W PD Fast Charging   |
| USB-A Output             | Standard Charging  |
| Dimensions               | 4.0 x 2.7 x 0.6 inches   |
| Weight                   | 0.46 lbs (7.4 ounces)  |
| Compatibility            | iPhone 12/13/14/15/16 Series (MagSafe compatible or with MagSafe cases)            |
| Special Features         | LED Digital Display, Foldable Stand, Multiple Safety Protections, Airline Approved |

# 10800mAh Magnetic Wireless Portable Charger Power Bank



Size: 4\*2.75\*0.78in



Figure 9: Size and capacity overview of the power bank.

## 8. WARRANTY AND SUPPORT

Your LanLuk Magnetic Portable Charger comes with a **24-Month Customer Service** warranty. If you encounter any issues or have questions about your product, please contact our customer support team for assistance.

Please refer to the contact information provided on the included Customer Service Card or visit the official LanLuk website for support details.