

[Manuals.plus](#) /

› [W-KING](#) /

› W-KING T9-2 Bluetooth Speaker with Wireless Microphone User Manual

W-KING T9-2

W-KING T9-2 Bluetooth Speaker with Wireless Microphone User Manual

Model: T9-2

INTRODUCTION

Thank you for choosing the W-KING T9-2 Portable Bluetooth Speaker with Wireless Microphone. This powerful 80W speaker delivers exceptional sound quality with deep bass and clear highs, perfect for parties, karaoke, and outdoor events. Equipped with a wireless microphone and vibrant LED lights, it promises an immersive audio-visual experience. Please read this manual carefully to ensure proper use and maximize your enjoyment of the product.

WIRELESS MICROPHONE

All in One, Enjoy a Karaoke Party Anytime, Anywhere!



A user enjoying the W-KING T9-2 speaker and wireless microphone for karaoke.

SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures or direct sunlight for prolonged periods.
- Keep the device away from water and liquids, although it has an IPX5 rating, it is not fully submersible.
- Do not disassemble, repair, or modify the device yourself. Refer to qualified service personnel.
- Use only the specified charging cable and adapter to avoid damage.
- Avoid listening at high volume levels for extended periods to prevent hearing damage.
- Ensure proper ventilation when operating the speaker.

PACKAGE CONTENTS

Please check the package for the following items:

- W-KING T9-2 Portable Bluetooth Speaker
- Wireless Microphone
- USB Charging Cable
- 3.5mm AUX Audio Cable
- User Manual

PRODUCT OVERVIEW

Familiarize yourself with the components of your W-KING T9-2 speaker and wireless microphone.





Front view of the W-KING T9-2 speaker with its two full-range drivers and the accompanying wireless microphone.

Speaker Components:

- **Control Panel:** Buttons for power, volume, play/pause, mode, EQ, and light control.
- **Full-Range Drivers:** Two powerful drivers delivering 80W output.
- **Bass Reflex Tube Port:** Enhances deep bass performance.
- **LED Lights:** Dynamic mixed-color disco lights.
- **Input Ports:** USB, TF card slot, 3.5mm AUX input, Charging port.
- **Handle:** For easy portability.



An illustration showing the two full-range drivers and internal components of the W-KING T9-2 speaker, highlighting its 80W output and bass capabilities.

Wireless Microphone Components:

- **Microphone Head:** High-sensitivity dynamic coil.
- **Control Buttons:** Power, volume, and reverb adjustment.
- **Display Screen:** Shows frequency and battery level.
- **Charging Port:** For recharging the microphone.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the USB charging cable to the speaker's charging port and a compatible USB power adapter (not included). The charging indicator will show the charging status and turn off when fully charged.

2. Charging the Wireless Microphone

Connect the microphone to a USB power source using its charging cable. The indicator light will show charging status and turn off when fully charged.

3. Powering On/Off

- **Speaker:** Press and hold the Power button on the speaker's control panel for 2-3 seconds to turn it on or off.
- **Microphone:** Press and hold the Power button on the microphone to turn it on or off.

4. Bluetooth Pairing

When the speaker is powered on, it will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.

1. Enable Bluetooth on your device (smartphone, tablet, etc.).
2. Search for "W-KING T9-2" in the list of available devices.
3. Select "W-KING T9-2" to connect. A voice prompt will confirm successful pairing.

The speaker features Bluetooth 5.3 for stable and long-distance transmission.



5.3
BLUETOOTH

An illustration demonstrating the extended range and stable connection of Bluetooth 5.3, allowing the speaker to connect across different rooms.

5. Connecting the Wireless Microphone

The included wireless microphone is pre-paired with the speaker. Simply turn on both the speaker and the microphone, and they will connect automatically.

OPERATING INSTRUCTIONS

1. Basic Audio Playback

- **Play/Pause:** Press the Play/Pause button on the speaker.
- **Volume Control:** Use the Volume Up (+) and Volume Down (-) buttons on the speaker.
- **Next/Previous Track:** Long press the Volume Up (+) for next track, and Volume Down (-) for previous track.

2. EQ Modes

Press the **EQ** button on the speaker to switch between different equalization modes, enhancing bass or optimizing for different music genres.

3. LED Light Modes

The speaker features vibrant mixed-color LED lights. Press the **Light** button to cycle through various light modes or turn them off.

4. Using the Wireless Microphone

- Ensure the microphone is powered on and connected to the speaker.
- **Microphone Volume:** Adjust the volume directly on the microphone using its dedicated buttons.
- **Reverb Adjustment:** The microphone has an independent reverb control. Use the dedicated button/dial on the microphone to adjust the echo effect for singing or speaking.

5. True Wireless Stereo (TWS) Pairing (Optional)

If you have two W-KING T9-2 speakers, you can pair them together for a true wireless stereo experience, doubling the sound output to 160W.

1. Ensure both speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), long press the TWS button (if available, or a designated pairing button).
3. The speakers will search for each other and connect automatically. A voice prompt will confirm successful TWS pairing.
4. Once paired, connect your device to the primary speaker via Bluetooth as described in the "Bluetooth Pairing" section.



Two W-KING T9-2 speakers connected via True Wireless Stereo (TWS) for an enhanced 160W audio experience.

6. Using AUX/TF Card/USB Playback

The speaker supports multiple input sources:

- **AUX Input:** Connect an external audio device using the included 3.5mm AUX cable to the AUX port. The speaker will automatically switch to AUX mode.
- **TF Card:** Insert a Micro TF card (up to 32GB, not included) with audio files into the TF card slot. The speaker will automatically play music from the card.
- **USB Playback:** Insert a USB flash drive (up to 32GB, not included) with audio files into the USB port. The speaker will automatically play music from the drive.



The W-KING T9-2 speaker, with its IPX5 water resistance, is suitable for outdoor use near water, such as by a pool, but should not be submerged.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the speaker and microphone. Do not use abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures when not in use.
- **Battery Care:** To prolong battery life, fully charge the speaker and microphone at least once every three months if not used regularly. Avoid completely draining the battery frequently.
- **Water Resistance (IPX5):** The speaker is IPX5 splash-proof, meaning it can resist a sustained, low-pressure water jet spray. Do not immerse it in water. Ensure all port covers are securely closed before exposure to water.



The W-KING T9-2 speaker, with its IPX5 water resistance, is suitable for outdoor use near water, such as by a pool, but should not be submerged.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not turn on.	Low battery.	Charge the speaker fully.
Cannot pair via Bluetooth.	Speaker not in pairing mode; device Bluetooth off; too far from speaker.	Ensure speaker is in pairing mode. Turn device Bluetooth off/on. Move device closer to speaker.
No sound from speaker.	Volume too low; incorrect input mode; device not playing.	Increase volume. Check input mode (Bluetooth, AUX, USB, TF). Ensure audio is playing on connected device.

Problem	Possible Cause	Solution
Microphone not working.	Microphone off; low battery; not paired with speaker.	Turn on microphone. Charge microphone. Ensure microphone is automatically connected to speaker.
Sound distortion at high volume.	Volume too high; audio source quality.	Reduce volume. Try a different audio source.

SPECIFICATIONS

Feature	Detail
Model Name	T9-2
Brand	W-KING
Speaker Type	Outdoor, Portable
Output Power	80W (160W with TWS pairing)
Sound Level	Up to 105dB
Drivers	2 Full-Range Drivers
Connectivity Technology	Bluetooth 5.3, AUX, TF Card, USB
Special Features	Wireless Microphone, EQ Modes, LED Lights, DSP Technology, TWS Pairing, Bass Reflex Tube
Waterproof Rating	IPX5
Power Source	Battery Powered
Material	Aluminum (microphone)
Included Components	Microphone



The W-KING T9-2 speaker is capable of producing a huge 105dB sound, ideal for loud party environments.

WARRANTY AND SUPPORT

W-KING products come with a standard manufacturer's warranty. For specific warranty terms and conditions, please refer to the warranty card included in your package or visit the official W-KING website. If you encounter any issues or have questions regarding your W-KING T9-2 speaker, please contact W-KING customer support for assistance. Contact information can typically be found on the product packaging or the official brand website.

Online Support: For the latest FAQs, troubleshooting guides, and product information, please visit the W-KING official website.

